SP500

Ultra HD Drone

USER MANUAL

Please read this manual carefully before flying and keep it well for future reference.

14+

US：support@snaptain.com
CA：support@snaptain.com
UK：support.uk@snaptain.com
ES：support.es@snaptain.com

ENGLISH

CONTENTS

DISCLAIMER AND SAFETY GUIDELINES 01
MAINTENANCE AND CARE 03
PACKING LIST 04
PRODUCT OVERVIEW 05
FLIGHT PREPARATION 07
FLIGHT OPERATION GUIDE 11
REMOTE OPERATION GUIDE 11
Pair the Remote with the Drone 11
Flight Calibration 12
1. Compass Calibration 12
2. Gyro Calibration 13
GPS Satellites Searching 13
Flight Instructions 14
Take-off 14
Flight Directions 15
Return-to-Home (RTH) 16
Smart RTH 16
Failsafe RTH 18
Low Battery RTH 19
Photo/Video 20
Headless Mode 20
Speed Switch 21
Altitude (ATTI Mode 21
Landing 22
Emergency Stop 23
APP OPERATION GUIDE 23
App Downloading and Installation 23
App Launch 24
Function Overview of the App 25
Take Off 26
Point of Interest (POI) 27
Follow Me 29
Waypoints 30
Photo/Video 31
Record Videos with the Preloaded Music 31
Landing 31
One Key Smart RTH 31
Settings 32
Other Functions 33
LED INDICATORS DESCRIPTION 35
PARAMETERS 36
TROUBLESHOOTING 37

DISCLAIMER AND SAFETY GUIDELINES

Please read the disclaimer carefully before using this product. By using it, you hereby agree to this disclaimer and signify that you have read them fully.

1. Before flying, please make some practice with a simulator or seek for the instruction from a professional.

2. DO NOT fly above or near obstacles, crowds, open water, public events, high voltage power lines or roads.

3. DO NOT use the drone in severe weather conditions, such as a rainy day or windy (wind speed is less than 5.5m/s), snow, hail, lightning, tornadoes, hurricanes, etc.

4. DO NOT fly the drone in the magnetic interference area, radio interference area and government regulated no-fly zones.

5. The fast-rotating propellers and propellers are a potential hazard to cause serious damage and injury. A safe distance of 2m must be maintained from the drone at all times while it is operational. Fly with responsibility.

DISCLAIMER AND SAFETY GUIDELINES

6. Please maintain the line of sight of your drone at all times after it is powered up. Do not rely on the camera image to control your drone.

7. This product is not a toy and is not recommended for users under age 14.

8. This product is not intended for professional aerial drone photography.

9. All parts must be kept out of the reach of children to avoid CHOKE HAZARD.

10. CAUTION: Dispose of the drone and batteries in accordance with local regulations. DO NOT insert in a household waste.

11. Be sure to observe all local regulations, obtain appropriate authorizations and understand risks. Please note it is solely your responsibility to comply with all flight regulations.

SNAPTAIN accepts no liability for damage, injury or any legal responsibility incurred directly or indirectly from the use of this product. The user shall observe safe and lawful common principles, including but not limited to, those set forth in these Disclaimer and Safety Guidelines. SNAPTAIN reserves the right to update this user manual.

FLIGHT PREPARATION

1. Charge the remote. It may take 1 hour to reach a full charge.

2. Unfold the **Remote Handle**.

3. Unfold the **Phone Clamp** when using the mobile device to fly the drone.

FLIGHT PREPARATION

4. Replace the propeller when it's needed. (Optional)

1. Remove the cap on the propeller.
2. Unscrew the nut and remove the propeller.
3. Put the spare propeller into the screw. Make sure the mark (A,B) on the propeller is the same as the mark on the arm of the drone.
4. Tighten the screw and install the cap.

LED INDICATORS DESCRIPTION

Function	Front LEDs	Rear LEDs
Color	Red	Green
Power On	Flash slowly	
Pairing	Flash quickly	
Compass Calibration	Horizontal Calibration: Solid on Vertical Calibration: Flash quickly Solid on	Horizontal Calibration: Flash quickly Off Vertical Calibration: Flash quickly Solid on
Gyro Calibration	Start Calibrating: Flash quickly for 4s Calibrated: Solid on	
GPS Mode	Solid On	Solid on
Failsafe RTH	Flash quickly	
Low Battery Status	Low Battery: Flash slowly Critical Low Battery: Flash quickly	

PARAMETERS

Motor	8*1407 coreless
Control Range	≤ 220m
FPV Range	≤ 120m
Maximum Flight Relative Height	120m
Flight Time	≈ 15mins
Charging Time	≈ 2.5H
Photo Resolution	1920 x 1080
Video Resolution	1080P@25fps
Photo Format	JPG
Video Format	MP4
Storage	Save to the mobile device and memory card(support up to 128G)
Mobile App Requirement	Android 5.1 and later; iOS 9.0 and later