## Material Cutting Guide

Cricut Mini® machine

	Material	Blade Depth	Pressure	Speed	Number of Image Cuts	Blade Assembly
0.07 mm ——	Vinyl (kiss cut)	3	2	High	1	Regular
0.12 mm ——	Light Cardstock (< 60 lbs)	3	3	Max	1	Regular
0.14 mm ——	Medium Cardstock (60-80 lbs)	4	4	Max	1	Regular
0.16 mm ——	Heavy Cardstock (> 80 lbs)	5	4	Max	1	Regular
0.40 mm ——	Cricut® Stencil Material	6	5	Medium	1	Regular
Varies	Fabric (use with fabric stabilizer)	4	4	Medium	1	Regular
0.88 mm	Cricut® Magnet Material	6	5	Medium	2	Deep Cut
1.00 mm	Cricut® Stamping Material	5	4	Medium	1	Deep Cut
1.50 mm	Chipboard	6	4	Medium	2	Deep Cut

SPEED GUIDE: 1 = Min 2 = Low 3 = Med 4 = High 5 = Max

Machines may vary. Always do a test cut to verify settings. (#27769)

