

2. Restart charging after it is turned off automatically by simply pressing the power button.

### LED Flashlight Function

Press the power button two times to turn on the LED flashlight. Press it again two times to turn off.

### Low Battery Warning

Press the power button. If the LED indicators blink, the battery level is low, indicating charging is necessary.

### Package Content

- Jackery Bar Battery Pack
- USB-micro Charging Cable
- User Guide
- Warranty Card



#### Warning

Read all instructions and warnings prior to using this product. Failure to read and follow these safety instructions could result in fire, explosion, electrical shock or other hazard, causing serious and/or fatal injury and/or property damage.

1. Do not modify, disassemble, open, drop, crush, puncture or shred the product.
2. Do not expose the product to rain or water.
3. Keep away from open flame or sunlight to prevent heat build-up.
4. Keep away from high voltage devices.
5. This product is not a toy, keep away from children. Ensure that all persons who use the product read and follow these warnings and instructions.



# Jackery Bar User Guide

## Contents

### Part 1: Product Overview


Product Layout  
Technical Specifications

### Part 2: Getting Started

Check the Battery Level  
Charge the Battery  
Charge Your Devices  
LED Flashlight Function  
Low Battery Warning  
Package Content

### Part 3: Warnings

#### Product Layout



1. Micro USB input port 5V / 1A
2. USB output port 5V / 2.1A
3. LED Flashlight x 2
4. LED light indicators
5. Power button

#### Technical Specifications

Capacity: 5600mAh  
Dimensions: 3.8 x 1.8 x 0.9 inch  
Weight: 5.5 oz  
Input: Micro USB 5V / 1A Output: USB 5V / 2.1A

Power indication: Three groups x 2 LED indicators


### Check the Battery Level

Press the power button to check the battery level  
LED indicators light from right to left


- |                             |                              |
|-----------------------------|------------------------------|
| 1 LED blinking: level < 10% | 1 LED on: level in 10%-33%   |
| 2 LEDs on: level in 33%-66% | 3 LEDs on: level in 66%-100% |

### Charge the Battery

To charge the battery, use the USB-micro charging cable to connect the battery to a USB AC adapter or computer USB port. Charging starts when the LED indicator is blinking. When all three LEDs are on, it means charging is completed. It takes about 6 hours to be fully charged.



or



### Charge Your Devices

1. To charge your device from the battery, use a USB data charging cable to connect your device to the battery, then press the power button. The charging will turn off automatically when complete.