

TECKNET


TeckNet X373 Bluetooth Keyboard



Welcome

Thank you for choosing this TeckNet product. To ensure optimum performance and safety, please read these instructions carefully before operating this product. It is strongly recommended you keep this manual for future reference.

Product Layout



Product Specifications

Interface:	Bluetooth 3.0 interface standard
Operating Distance:	10 M
Modulating System:	GFSK
Keyboard Size:	240 x 175 x 7.5mm
Operating Voltage:	3.0-4.2V
Operation Current:	<2.5mA
Standby Current:	0.3mA
Sleeping Current:	<40uA
Charging Current:	>200uA
Standby Time:	>100 days
Charging Time:	<2 hours
Battery Capacity:	500mA
Continuous Working Time:	100 hours
Lithium Battery Life:	3years
Key Strength:	50g~80g
Key Life:	<3 million strokes
Operating Temperature:	-10+55° C

Package Contents























- 1 x X373 Bluetooth Keyboard
- 1 x Micro-USB Cable
- 1 x User Manual
- 1 x Warranty Card

Operation Instructions

FN+FKeys

These provide shortcuts to useful functions. Firstly, press and hold the FN key, then press the "F" key you want to use. Press and hold "FN" and combination media keys will simplify computer operation.

Function Keys

	Home		Decrease brightness		Increase brightness
	Virtual Keyboard		Copy		Paste
	Language Exchange		Previous Track		Play/Pause
	Next Track		Mute		Volume Down
	Volume Up		Lock		Select all
	Paste		Switch language		Copy
	Page up		End		Page down
	Home				

Note: The functions of combination key may be different due to different keyboard version.

Bluetooth Pairing

1. Turn on the keyboard "On/Off" switch, the "Status" indicator will illuminate for 4 seconds before it turns off.
2. Press the "Connect" button, the Bluetooth indicator will start flashing. Now the keyboard is ready for pairing.
3. Access to the settings and click on "Bluetooth" to turn on the connection. The tablet PC will automatically search for a Bluetooth-enabled device. When the wireless keyboard is searched, click on the device name "TeckNetX373" to connect.
4. Enter the password shown on tablet screen and click "Enter" on the X373.
5. When the wireless keyboard is successfully connected, the Bluetooth indicator will turn off.

Note: For other Bluetooth enabled devices, please verify the Bluetooth standard & compatibility before attempting to connect to the keyboard.

Keyboard Indicators

1) Status indicator:

- It will show blue light and illuminate for 5 seconds when you turn on the keyboard.
- It will show blue light and flash about 3 minutes for pairing; the light will turn off if the pairing is complete or no available device for pairing.

2) Power indicator:

- It will show blue light and keep flashing if the voltage is less than 3.3V.
- It will show red light when charging the keyboard; the light will turn off when it's completed.

Battery Life

The rechargeable battery can last for several weeks. With no memory effect, the lithium battery can be charged at any time. In order to extend service life, we recommend you turn the keyboard off when it's not in use for a long time.

Battery Charging

Turn on the Bluetooth keyboard. If the "Status" indicator shows green, it means the battery has enough power. If the "Status" indicator shows red, it means the battery needs to be charged and please follow the steps below.

1. Plug the Micro-USB charging cable into the keyboard.
2. Plug the USB end into an empty port of your computer or a power adapter.
3. Charge for about 2 hours or until the battery status light turns off.

Energy-Saving Sleep Mode

The keyboard's long-life battery lasts for several weeks of normal use. The keyboard will go into sleep mode if left on and not being used. Press any key and wait a second or two to wake it up.

Cleaning

Clean the keyboard with a damp cloth moistened with water, alcohol or alcohol based disinfectant.

Troubleshooting

Unable to connect

- 1) Make sure the keyboard is on (the power indicator light will be on).
- 2) Make sure the keyboard is in operating distance (within 10 metres).
- 3) Check that the battery is working (if the power indicator is red when keyboard is connected to a power source, the battery needs to recharge).
- 4) Make sure the Bluetooth setting on the tablet computer is turned on.
- 5) Press the "Connect" button to check the Bluetooth status.

Unable to charge the keyboard

- 1) Make sure the USB power cable is connected properly to the keyboard and the power source.
- 2) Make sure the wall charger is plugged into the power outlet.

Note: The output voltage and current of the power adapter must not exceed DC 5.0V, 500mA. Otherwise, the keyboard will be damaged.

Disposal of waste batteries

Insert a flat-head screwdriver between the keyboard's plastic top and metal case, pry the plastic top open and remove it completely. This action destroys the keyboard by separating the battery from the circuit board. It is your responsibility to hand the battery over to an appropriate collection and recycling center to help conserve natural resources and prevent potential negative consequences for human health and the environment, due to the possible presence of hazardous chemicals in batteries and electronic equipment.

IMPORTANT SAFETY INSTRUCTIONS-CAREFULLY FOLLOW THESE INSTRUCTIONS.

- 1.SAVE THESE INSTRUCTIONS - This sheet contains important safety and operating instructions.**
- 2.Before using the product, read all instructions and caution markings on the product, accessories and device using our product.**
- 3.This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**
- 4.Children should be supervised to ensure that they do not play with the appliance.**
- 5.Keep the product away from fire or explosion may occur.**
- 6.For indoor use only. Do not expose to rain, water, excess moisture or snow. 7.Do not place product in or near inflammable, explosive or hazardous object. 8.Do not place in or near water, rain, excess moisture or extreme heat.**
- 9.Do not operate product with damaged cord or plug.**
- 10.Do not operate product if it has been damaged in any way.**
- 11.Do not disassemble the product. Disassembly may result in a risk of safety hazards.**
- 12.Do not throw or shake the product**
- 13.To reduce the risk of electric shock, unplug the product from the power supply when not in use or switch off the power supply**

Limited 18-Month Warranty:

What this warranty covers.

Shenzhen Unchain Technology Co., LTD. (Manufacturer: "Unchain") warrants to the original purchaser of this TeckNet product that the product shall be free of defects in design, assembly, material, or workmanship.

What the period of coverage is.

Unchain warrants the TeckNet product for 18 Months.

What will we do to correct problems?

Unchain will repair or replace, at its option, any defective product free of charge (except for shipping charges for the product).

What is not covered by this warranty?

All above warranties are null and void if the TeckNet product is not provided to Unchain for inspection upon Unchain's request at the sole expense of the purchaser, or if Unchain determines that the TeckNet product has been improperly installed, altered in any way, or tampered with. The TeckNet Product Warranty does not protect against acts of God such as flood, earthquake, lightning, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low voltage disturbances (i.e. brownouts or sags), non-authorized program, or system equipment modification or alteration.

How to claim the warranty

Please contact retailers or visit TeckNet website www.tecknet.co.uk for more information

Disclaimer

Every effort has been made to ensure that the information and procedures in this guide are accurate and complete, no liability can be accepted for any errors or omissions and we reserve the right to make any changes without further notice to any products mentioned herein.

Warranty

We warrant that products purchased from authorised distributors will meet the applicable product specifications and be free from all defects in design, assembly, materials and workmanship. Please contact TECKNET retailers, or visit our website(www.tecknet.co.uk) for more information about the product.

TECKNET

TeckNet
P.O. BOX 122
Liverpool
L9 7WQ
www.tecknet.co.uk