






READ ALL WARNINGS AND INSTRUCTIONS BEFORE USING PRODUCT. INJURY CAN RESULT FROM IMPROPER USE. SAVE THESE INSTRUCTIONS. A WARNING





. Screw the (Figure I)





Firmly push the completely asse until secured. (Figure III)

HOW TO USE

- To clean up a mess, push the Hurricane® Spin Broom™ forward while applying a slight amount of downward force. (Figure IV)
 - The Hurricane" Spin Broom" only works when being pushed forward. Your Hurricane" Spin Broom" will no work if it is used in a back and forth motion.

 The Hurricane" Spin Broom" works best on hard surfaced floors, it is not designed to work on carpets, even lov pile carpets.



To empty the Hurricane* Spin B dust bin, hold it over a garbage can and push in the dust bin button to allow all of the contents to fall out. (Figure V) After everything has fallen out make sure to close the dust bin door.



HOW TO CLEAN

- Periodically clean the center brush with the included brush cleaning tool. (Figure VI)
- You can also clean the exterior and inside of the dust bin with a soft damp cloth.



IIIBrands

LIMITATION OF LIABILITY
ne purchase price of this product. Telebrands
able for any incidental or consequential dama
anty on this product. Some states do not allow
itation of incidental or consequential damage
ion or exclusion may not apply to you.