

Ultra Micro WiFi Camera Manual

This product is a lightweight, high performance WiFi FPV camera with a resolution of 1280x720px video at 30fps. The video is transmitted directly to your smartphone device and recorded by your phone. Still photos can also be captured on your smartphone. Suitable for the Ethos QX130 and the Shadow 240. For the Shadow 240, please refer to the instruction manual supplied with your guad.

- To mount the camera to your QX-130 without modification, slide the front camera mount into the front slot on the QX-130 leaving the rear mount to rest on the outside of the rear slot. The camera is adequately secure with only the front mount engaged.
- 2. If you wish to mount the camera into both slots you will need to shorten the right rear leg mount so that it doesn't interfere with the camera's WiFi antenna. Even if you cut the leg mount there will still be enough socket remaining so that the accessory legs can still be mounted when other accessories are used.
- 3. The QX-130 has a 4-pin camera socket, the WiFi camera only has a 3-pin plug. Plug the 3-pin plug onto the left 3 pins of the 4-pin socket and with the red wire to the left.
- 4. Go to the App Store for your device and look up the WiFi UFO app and download it to your smart device.
- 5. Plug the LiPo battery into the quadcopter.
- Open your WiFi settings location and locate the WiFi "LG" and connect to it.
- 7. Open the App WiFi_UFO and press "Play" to enter the operation mode.
- If the gimbal graphics are showing press "ON" to hide the graphics. The WiFi camera does not utilize these functions
- Install the smartphone holder onto the front of your transmitter and clip smartphone in holder.
- Control the flight of the quad with your 2.4GHz transmitter.
- 11. Record video on your smartphone by tapping the video icon.
- 12. Record still photo by tapping the photo icon.
- 13. Access your recordings by tapping the open file icon.











WARRANTY + CONFORMITY



Limited Warranty

Ares products are covered by the currently valid statutory warranty regulations. If you wish to make a claim under the limited warranty, please contact the model shop where you originally purchased the unit.

The limited warranty does not cover:

Damage due to commercial use, negligence, misuse, abuse, accident, or acts of God:

Damage due to improper installation, operation or maintenance:

Normal wear and tear:

Cosmetic damage:

Modifications or repairs not carried out by Ares or by an authorised Ares Service Centre;

Product not purchased from an authorized Ares dealer:

The use of accessories other than original Ares items:

Use of the unit outside the stated specification:

Ares and its authorised representatives accept no liability for loss, damage or costs which are caused by the incorrect or incompetent use of the product.

UK Distribution

Ares is distributed in the UK by:

J Perkins Distribution Ltd. Lenham, Kent, ME17 2DL www.jperkins.com



 $\mathsf{CEConformity}$ $\mathsf{JPerkins} \ (\mathsf{Distribution}) \ \mathsf{confirms} \ \mathsf{this} \ \mathsf{product} \ \mathsf{is} \ \mathsf{in} \ \mathsf{compliance} \ \mathsf{with} \ \mathsf{the} \ \mathsf{relevant}$ harmonised European directives relating to its safe operation.

To see a copy of the relevant Declaration of Conformity visit: http://www.ares-rc.com/support



This appliance is labelled in accordance with European Directive 2012/19/EU concerning Waste Electrical and Electronic Equipment (WEEE).

The WEEE Directive came into force to reduce the disposal of domestic waste and promote recycling. Any electrical item that carries the crossed out wheelie bin logo must not be disposed of in domestic waste but should be taken to a designated collection facility. J Perkins (Distribution) are a member of an approved compliance scheme to encourage consumers to recycle unwanted items. Your local authority will be able to provide details of your nearest approved waste disposal site.