






GolfBuddy Application Quick Guide (Android)

VTX


1. [GolfBuddy Application Installation](#)
2. [Running GolfBuddy Application](#)
3. [Connecting your VTX](#)
4. [Course update](#)
6. [Find your VTX](#)
7. [Setting](#)

GolfBuddy Installation






The login screen features the GolfBuddy logo at the top with the tagline "ACCURACY MATTERS™". Below the logo are two input fields for "USERNAME" and "PASSWORD". A blue "LOGIN" button is positioned below the password field. At the bottom, there is a "Forgot Password" link and a "Sign Up" button highlighted with a red box.



The app home screen shows a blue header with a hamburger menu icon, the text "Device Not Connected", and a settings gear icon. Below the header is the GolfBuddy logo. A "Notice" section contains five items, each with a plus sign on the right: "COURSE UPDATE INFO" (May 24, 2018), "GolfBuddy Course Manager Update for Mac and Windows" (May 17, 2018), "COURSE UPDATE INFO" (May 10, 2018), "GolfBuddy Course Manager Update for Mac and Windows" (May 10, 2018), and "COURSE UPDATE INFO" (May 03, 2018). At the bottom, there is a "COURSE UPDATE INFO" (April 26, 2018) item. Two buttons at the bottom are "Do not display again today" and "Close".



The device selection screen has a blue header with a hamburger menu icon, the text "Device Not Connected" (highlighted with a red box), and a settings gear icon. Below the header are tabs for "All", "Handheld", "Wearable", "Voice", and "Laser". The main area displays several device cards, each with a "NEW" badge: "VTX" (a handheld device), "Voice X on Wristband" (a wristband), "VOICEX" (a handheld device), "VOICE2" (a handheld device), and a "Need Help?" button (a question mark icon). At the bottom right, there are two more wearable device cards.

1. Input your account information : USERNAME/PASSWORD

2. If you do not have an account, you can create one by clicking “Sign Up”.


※ You can use the existing account which you have been using in GolfBuddy website

※ Device : Not Connected


You need to find and connect your VTX before using the features of GolfBuddy App.



> Tap **Menu** button



> Tap **Find My GolfBuddy**



> Tap **+** to search your VTX




> Select your VTX in the found list



> Connection Complete


F974




You can recognize your VTX watch in the list by checking the LE address in Setting -> About




> Tap **Menu**





> Tap **Course Manager**



> Select the course which you want to update



> Update Process



Bookmark

Select a course from all of courses you have downloaded via GB app. This list of courses will be sorted by time when you downloaded the course date.



Location

Show you the list of the nearest golf courses from your current location, based on GPS information.




Search


Select a course from the existing list of golf courses. After selecting the country, search for the course by typing the name of golf course in the input box




> Tap **Menu**



> Tap **Find Me**




> Tap **Start**




> Tap **Stop** after finding your VTX

> Your VTX within range will make vibration and turn on the screen.





> Tap **Setting** button



> Select your preferred unit among YARD or METER
> Version information

**Thanks
for
your
attention !**