




Instructions


In the Box

- 2 x FreeBuds
- 1 x Charging Case
- 4 x Eartips (L,M,S,XS)
- 1 x USB-C Charging Cable
- 1 x Quick Start Guide
- 1 x Warranty Card
- 2 x Skin-friendly silicone rings (included,L&R)



- Microphone decoration surface is covered by insulating coating.


Bluetooth Pairing



1




2



3

Press and hold the function button for 2s to start Bluetooth pairing (with both FreeBuds inside).

Call Function



Double-tap either Freebuds to answer an incoming call.

Music Function



Double-tap your RIGHT FreeBud to play / pause music.



Instructions

Voice Assistant



Double-tap your LEFT FreeBuds to activate voice assistant.

Sleep & Charge



Put both FreeBud inside and close the charging case to sleep & charge.

Bluetooth Paring

1. 1st Time Pairing

- Open the charging case (with both FreeBuds inside). Press and hold the function button for 2s to start Bluetooth pairing (the indicator will blink in blue).
- Enable Bluetooth on your smartphone, select "HUAWEI FreeBuds" from the Bluetooth device list, and tap to connect.

(i) Due to the characteristics of all Bluetooth headsets, electromagnetic waves from close vicinities may interfere with your Bluetooth connection, causing your FreeBuds to become silent or disconnected.

2. Auto Reconnect

- Reopen the charging case, the FreeBuds will reconnect to your previous device(s) automatically.

Smart Control

1. Call Function

- Double-tap either FreeBud to answer an incoming call & double-tap again to end it.

(i) Ensure to wear your FreeBuds properly. If you experience an abnormality during a call, adjust your headset to the proper position.



Instructions

2. Music Function

- Double-tap your right FreeBud to play / pause music, or simply take out either FreeBud to pause music.

3. Voice Assistant

- Double-tap your left FreeBud to activate voice assistant (requires voice assistant enabled smartphone).

Sleep & Charge

- Put both FreeBuds inside and close the charging case to sleep & charge.
- If the indicator remains red, it indicates that the charging case is still charging; if the indicator turns green, it indicates that the charging case is fully charged.


Restore Factory Settings

- Open the charging case, put both FreeBuds inside, and leave the charging case open.
- Press and hold the function button for 10s or more. After the indicator blinks in red, green, and blue, your FreeBuds are restored to their factory settings.



FreeBuds update

1. Make sure that the earphones have sufficient power.
2. Put your earphones into the case. Close then re-open the cover. The earphones will then be ready for updating.
3. Do not close the cover during the update. Otherwise, the update will fail.



Update



FreeBuds update

Keep the case close to your phone so that your phone can detect your earphones.




Preparing update... 



FreeBuds update

Keep the case close to your phone so that your phone can detect your earphones.



Current version:V1.165

Update version:V1.185

Upgrade log:

- 1.Optimize system stability of the headphone
- 2.Improve functional sensibility of keys
- 3.Perfect sound quality of the headphone

Cancel

Update

Check FreeBuds upgrade 

Erasing flash. Do not use your earphones during this process.

Time taken 09:16

- 1.The update may take around 15 minutes.
- 2.Do not use your earphones during the update. Otherwise, the update may fail.
- 3.If the update fails, please try again;



100%

Note: Do not lock the screen or leave this screen

Time taken 09:26

- 1.The update may take around 15 minutes.
- 2.Do not use your earphones during the update.
Other
- 3.If th

Update successful

OK

Not

een