

COMAG	4288, 4295, 4576, 4580
DREAMBOX	4234, 4284, 4285, 4362, 5358
FERGUSON	0378, 0619, 0630, 0660, 0672, 0694, 4438, 4507, 4584, 6192
EDISION	4290, 5442
HUMAX	0797, 4189, 4196, 4219, 4228, 4277, 4541, 4549, 4584, 5307, 5329, 5342, 5345, 5350, 5360, 5371, 5380, 5424, 5816
KATHREIN	0619, 0625, 0674, 0703, 0705, 0771, 4127, 4196, 4205, 4214, 4239, 4242, 4278, 4295, 4296, 4333, 4351, 4361, 4384, 4394, 4415, 4423, 4434, 4445, 4456, 4465, 4584, 4545, 5340, 5347, 5348, 5349, 5353, 5354, 5357, 5364, 5945

LG	4247, 5427, 5443, 5496
MEDION	4318, 4565, 5359, 5408
MEGASAT	0703, 4127, 4584, 5376
OCTAGON	0621
PANASONIC	0733, 0769, 4562, 4574, 5339, 5343
PEARL	6002, 6003, 6004, 6005, 6006, 6007, 6008, 6010, 6014, 6015, 6016, 6023, 6024, 6025, 6026, 6027, 6029
PHILIPS	0414, 0629, 0630, 0694, 0697, 0703, 0733, 0749, 0771, 0785, 2345, 4141, 4161, 4127, 4214, 4257, 4309, 4333, 4365, 4422, 4465, 4545, 4553, 4565, 4584, 4589, 5303, 5305, 5338, 5361, 5402, 5418, 5809, 5950
PROTEK	4239, 4317, 4406, 4426, 5348

SAMSUNG	0646, 0733, 0797, 4146, 4225, 4226, 4227, 4266, 4267, 4291, 4292, 4322, 4328, 4361, 4418, 4422, 4467, 4512, 4528, 5339, 5343, 5344, 5349, 5353, 5403, 5419, 5472, 5807, 5808, 6284
SCHWAIGER	0694, 0797, 0919, 4141, 4161, 4148, 4166, 4189, 4193, 4218, 4234, 4258, 4260, 4261, 4262, 4263, 4264, 4290, 4296, 4303, 4314, 4352, 4365, 4384, 4438, 4509, 4514, 4529, 4541, 4547, 4565, 4581, 5100, 5101, 5102, 5103, 5104, 5105, 5106, 5107, 5108, 5109, 5110, 5111, 5408, 6048, 6049, 6050, 6051, 6272, 6214, 6260, 6273, 6274, 6275, 6276
SKYMASTER	0697, 4204, 4327, 4352, 4518, 4526, 4541, 4565, 5340, 5347, 5354, 5364

SONY	0733, 0785, 4587
TECHNISAT	0676, 0703, 0741, 0797, 1343, 4127, 4142, 4189, 4214, 4218, 4386, 4408, 4422, 4440, 4465, 4500, 4561, 4565, 4584
TELESTAR	4214, 4465, 4541, 4550, 4565
THOMSON	0051, 0630, 0694, 0697, 0732, 0735, 0785, 0917, 1445, 4141, 4161, 4452, 4415, 4356, 4559, 4582, 5332, 5333, 5339, 5343, 5351, 5368, 5930, 5935, 6286, 6290
(RE)PLAYBOX	5024
253	5501
@MEDIA	4505
@SKY	4541
@SAT	4303, 4234, 4177
441250	5027, 5373, 5359

@STAR	4271
AB COM	5489, 06150, 6152, 6199
AB SAT	0794
441408	5016
ACCESS MEDIA	0733, 4505, 5330
ACCESS BOX	5017
ACEC (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 4257, 4309, 4422, 4465, 4545, 4589, 4553, 2345
ADB	0917, 4305, 4356, 5304, 5319, 5332, 5333, 5334, 5335, 5336, 5854
ADL	4541
ADR	4218
AGASHI	4413
AEGYR	0684
AGB (SABA)	0630, 0694, 0718, 4204, 4452, 4566

AGEF (BRUNS)	0697, 4437, 4460
AIRIS	4296, 4298, 5309, 5358, 5853, 5854, 5930, 6154
AITECH	5332, 5333
AKAI	0703, 4127, 4251, 4505, 4584, 5316, 5388, 5559, 5875, 5860
AKIRA	5930
AKTRON (TOSHIBA)	0630, 4306
ALBA	0621, 0629, 0697, 0739, 4223, 4251, 4297, 4339, 4433, 4448, 4450, 4452, 4458, 5307, 5359, 5479, 5839, 5864
ALDES	0629, 0684, 4223, 4337
ALICE	5339, 5343, 5937, 5938, 6285
ALKOS (TOSHIBA)	0630, 4306
ALITEK	5520, 5533

ALLSAT	0664, 0703, 4127, 4584
ALLSONIC	0629
ALLTECH	0725, 4406
ALLVISION	5408
ALPHA	3125
ALTAI	4386
ALTEK	5331, 5383
ALTERBOX	5059, 5072
AMIKO	5944, 6180
AMITONIKA	4367
AMPERE (ARCON)	0614, 0919, 4331, 4418, 4507, 4571

AMSTRAD	0647, 0656, 0660, 0672, 0676, 0733, 0797, 4141, 4142, 4149, 4150, 4161, 4189, 4300, 4305, 4329, 4367, 4386, 4388, 4396, 4418, 4508, 4533, 5304, 5327, 5337, 5340, 5347, 5358, 5359, 5379, 5364, 5945
ANDERSSON	5465
ANIKO	5465
ANITECH	0697
ANKARO	0608, 0629, 0676, 4142, 4318, 4337, 4386, 4460, 4446, 5360
ANSONIC	5479
ANTARES	4415, 4296, 5358, 5469, 5487
ANTTRON	0621, 0694

ANVIMUR	4281, 4538, 4575, 5340, 5347, 5349, 5353, 5364
APOLLO	0321
AQP (GRUNDIG)	0531, 0619, 0630, 0772, 0741, 0749, 0785, 4389, 4592, 4593
ARCENCIEL (THOMSON)	0051, 0630, 0694, 0697, 0732, 0735, 0917, 1445, 4452, 4559, 4582
ARCON	0614, 0919, 4418, 4331, 4507, 4571, 5346, 5360
ARIASAT	5350, 5357, 5358, 5408, 5489
ARION	0919, 4186, 4507, 5360
ARISTONA (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4589, 4553

ARIZA	5348
ARMSTRONG	0703, 4402, 4413
ARNION	4303
ARROX	4296
ARTHURMARTINI (SALORA)	0672, 4340, 4341
ASAHI	5346, 5357, 5358
ASCI	4541
ASHIN	4418
ASSCOM	0785
AST	0669, 0672, 4454, 4481
ASTEL	4347, 4455
ASTI	0725
ASTON	0624, 0664, 0676, 4142, 4334, 4386, 4556

ASTRA	0672, 0676, 0694, 0703, 4127, 4142, 4386, 4394, 4413, 4427, 4436, 4446, 4564, 4473, 4584
ASTRASAT	5358
ASTRATEC	5307
ASTRELL	4141, 4161, 4529, 5856, 5930
ASTRO	0619, 0625, 0684, 0741, 0771, 4218, 4288, 4339, 4352, 4538, 4545, 4595, 5340, 5347
ASTROVOX	5358
ATLANTA	4149, 4237, 4298, 4299, 4352, 4508, 4533, 5324
ATLANTIC (FORMENTI)	0608
ATLANTIS	0621, 0701

AUDIOLA	5324, 5326, 5363, 5466, 5479, 5485, 5491, 5600, 5801, 5854
AUDIOLINE	4581
AUDIOTON	0664
AUNA	4276
AURIGA	0630, 0684, 0917, 4305, 5304, 5332, 5333, 5346, 5365, 5370, 5345
AUTOVOX	5324, 5359, 5363, 5383, 5466, 5810, 5853, 5946
AVALON	0676, 4142, 4386
AVION	0919, 4166
AXIL	4237, 4293, 4295, 4296, 4297, 4321, 4367, 5324, 2337, 5357, 5338, 5359, 5363, 5373, 5479, 5485, 5802, 5854, 5935, 6194

AXIS	0608, 4318, 5307
AXOSAT	0697, 0743
AXITRONIC	4367
BAFF	5357
BALMET	4233, 4234, 4235, 4295, 4296, 4528, 5503, 5521, 5530, 5533, 5539, 5357, 5358, 5362
BEC	4510
BEKO	5489
BELSON	4201
BENJAMIN	4474, 4506, 5489
BEST	0608, 0629, 5360
BEST BUY	5324, 5325, 5363, 5466, 5815, 5933, 6131, 6140, 6146
BETA	0703, 4127, 4584
BIG SAT	4281, 4296, 5358

BINATONE	4491
BLACK DIAMOND	4438, 5307, 5359
BLANK	5524
BLAUPUNKT	0619
BLUESKY	4149, 4508, 4522, 4533
BLUESTAR	5864
BLUETINUM	5356, 5373
BLUSENS	5802
BOCA (AMSTRAD)	0647, 0656, 0660, 0733, 4149, 4150, 4300, 4305, 4329, 4365, 4367, 4388, 4396, 4413, 4418, 4446, 4508, 4533
BOSHMANN	5357
BOSTON	4149, 4237, 4296, 4297, 4331, 4365, 4367, 4508, 4533, 5358, 5479
BOTECH	4236

BOX	4557
BOX ALTERBOX	5071
BOX NEUF	5068
BOX ORANGE	5067
BQS	5945
BRAIN WAVE	0752, 4210, 4403, 4414, 4496, 4580, 4545, 4581, 5354
BRAND- TELETRONIQUE (THOMSON)	0051, 0630, 0694, 0697, 0732, 0735, 0785, 0917, 1445, 4452, 4582, 4459
BRAVO	4289, 5346, 5409, 5456, 5463, 5493
BRUNS	0697, 4437, 4460
BSB	0703, 4127, 4584
BT	4251
BUSH	0630, 0739, 4438, 4448, 4452
BW	4581

CALE	5490
CALIFORNIA (FORMENTI)	0608
CAMBRIDGE	0741, 4251, 4413
CANAL SAT	0785
CANAL +	0785, 4184, 4185
CANALERA	9006, 9009
CANDEL (LG)	4247
CARDMANIA	5365, 5370, 5377, 5435
CARYONSE (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4553, 4545, 4589
CASEMA	4582, 5369
CASONIO (OCEANIC)	0706, 0785, 4341, 4506
CDV	4577, 5337, 5464
CERT	0672

CENTURY	4383
CGV	4295, 4538, 5340, 5347, 5357, 6137
CHANNEL MASTER	4250
CHAPARRAL	4249
CHEROKEE	0735, 0745, 4137, 4294, 4321, 4338, 4399, 4572, 5368
CHESS	4288
CITIZEN	0674
CITY COM	0674, 4196, 4295, 4314, 4333, 4351, 4352, 4384, 4415, 4434, 4551, 5350, 5357, 5408
CLARKE - TECH	4286, 4578
CLATRONIC	4403, 4496, 5313, 5374, 5485, 5880

CLEMENS CAMPUS (HUTH)	0629, 4123, 4149, 4153, 4169, 4193, 4204, 4232, 4352, 4413, 4460
CME	0627, 0630, 0706, 0739, 0748, 0768, 0769, 0771, 0774, 5945
CMR	0697, 4248
CMX	5933
COBRA	0676, 0731, 0778, 4142, 4252, 4305, 4311, 4318, 4352, 4386, 4512, 4540, 5304, 5312, 5327, 5356, 5358, 5362, 5376, 5383, 5554, 5800, 5802, 5805, 5815, 5933, 6139, 6146
COFADEL (THOMSON)	0051, 0630, 0694, 0697, 0732, 0735, 0917, 1445, 4452, 4559, 4582
COLORADO	0697

COLUMBUS	0735, 0745, 4178, 4321, 4399, 4572, 5368
COMAG	4288, 4295, 4576, 4580
COMMLINK	0629
COMSAT	0718, 5340, 5347, 5357, 5364, 5430, 5945
COMTEC	4394
COMWELL	4571, 5346
CONAX	5346
CONCERTO (LG)	4247
CONCORD	4542
CONDOR	0608
CONNEXIONS SAT	4368
CONTEC	4361
CONRAD	5342, 5345, 5350, 5351, 5408

CONTIN: EDIS: (THOMSON)	0051, 0630, 0694, 0697, 0732, 0735, 0917, 1445, 4452, 4559, 4582
CONTINENT	5343
COSAT	0666
COSHIP	4252, 4296, 5358, 5359, 5376
CPC	0672
CROWN	0734, 4413, 5307, 5359, 5864
CSN	5006
CYFRA PLUS	0785
DAEWOO	0621, 0697, 0748, 4348, 4361, 4585, 5307, 5450
DAK	4300
DANSAT	0694
DANTAX	5359
DANYSTAR	5338

DATCOM	4542
DARTY	6285, 6290
DATRONIC (DAEWOO)	0621, 0697, 0748, 4348, 4585
DAXIS	6110
DAYTONA	4149, 4508, 4533
DAYTRONIC (DAEWOO)	0621, 0697, 0748, 4348, 4585
D-BOX	0768
DBOX-DF1	0739
DDC	0621, 4450
DELFA	0797
DELSAT	4352
DELTA	5353
DELTALINE	5353
DELTASAT	4352
DENTAL (FORMENTI)	0608

DENVER	5440, 6128
DHS (ASTRA)	0694, 4394, 4427, 4436, 4473, 4564
DICRA	5405, 5854
DIEVO	5365, 5370
DIGIAN	4506
DIGICOM	5350
DIGIFOX	5342, 5345
DIGIFREE	5307
DIGIFUSION	4583, 5307
DIGIMASTER	5360, 5382
DIGIHOME	5359

DIGIQUEST	0797, 0919, 4166, 4189, 4196, 4242, 4290, 4296, 4303, 4305, 5304, 5316, 5349, 5350, 5353, 5358, 5360, 5362, 5365, 5367, 5370, 5400, 5435, 5466, 5485, 5853, 5590, 5930, 5944, 6131, 6139, 6196, 6197, 6198
DIGISAT	5352, 5362, 5400, 5410, 5465, 5466
DIGISKY	5358
DIGIT ALL	4512
DIGITAL	4288, 4351, 4367, 4541, 4550
DIGITAL BOX	5329, 5371
DIGITAL +	0732
DIGITRONIC	0800, 0919, 4149, 4166, 4170, 4508, 4533, 4573, 5360
DIGIX	4303

DIGIZAP	5307
DIKOM	5388, 5400, 5495, 5802, 5803
DIPRO	0917, 4356, 4305, 5304, 5332, 5333, 5346, 5362, 5365, 5370, 5435
DIRECTBOX2	5050
DIRECTBOX3	5051
DISCOVERY	4137, 4294, 5368
DISEQC	0731, 4140, 4149, 4508, 4533, 4550
DISISTRAT	0703, 4127, 4584
DISTRA	4338
DISTRATEL	4141, 4149, 4161, 4335, 4336, 4507, 4508, 4529, 4533, 4540, 5001, 5002, 5012, 5014, 5015, 5016, 5029, 5031, 5032, 5033
DISTRISAT	0703

DMSIS	4506, 5489
DNT	0676, 0703, 4127, 4142, 4386, 4584
DPM	5446
DRAGON BOX	4281
DRAKE	0614, 4269, 4338, 4351, 4399, 4412, 4541, 5335
DREAMBOX	4234, 4284, 4285, 4362, 5358
DTI 1000 (THOMSON)	5035
DTT	4546
DUALIS	5021
DUALISBOX	5048
DUAL- STREAMBOX	5058
DUNE	5373

DVB	4138, 4329, 4541, 5340, 5411, 5413, 5945
D-VISION	5359
DVR01 / EH-M1	5064
DYNASAT	0621, 0674, 4205, 4473
DYNATRON (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
EASY	5029
EASY 3	5047
EASY 2 / PREM 3	5046
EASY LIVING	5819, 5823, 5871
ECHOLITE	4541

ECHOSTAR	0627, 0656, 0697, 0732, 0774, 0791, 4273, 4296, 4305, 4315, 4329, 4354, 4386, 4392, 4399, 4457, 4488, 4562, 4563, 5304, 5339, 5340, 5343, 5347, 5358, 5364, 5945
EDISION	4290, 5442
EIF	4338
EINHELL	0621, 0672, 0734, 4413
ELAP	0697, 4329, 4550, 5340, 5347, 5348, 5364, 5404, 5945
ELBE	4237, 5324, 5359
ELIN	4341
ELIUM	4132
ELLIES	4357, 4407
ELSAT	0660, 5945

ELTA	0608, 0621, 0664, 0703
EMANON	0621
EMATEC (OCEANIC)	0706, 0768, 0785, 4341, 4506
EMCO (IMPERIAL)	4448, 4452
EMME ESSE	0608, 0674, 0706, 0718, 0774, 0785, 0917, 4128, 4205, 4254, 4271, 4331, 4356, 4399, 4445, 4458, 4473, 4511, 4513, 4517, 4523, 4548, 5332, 5333, 5438, 5954
EMTECH	4511, 4544
EMTEC	5479

ENGEL	0621, 0785, 4237, 4291, 4292, 4293, 4295, 4297, 4299, 4365, 4367, 5324, 5337, 5340, 5347, 5354, 5357, 5358, 5359, 5360, 5363, 5364, 5479, 5802, 5854, 5945
EP SAT (PACE)	0630, 0694, 0733, 0745, 0769, 0785, 4133, 4274, 4347, 4358, 4412, 4414, 4448, 4554
EQUATOR	0694
ERRES (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
E-SPACE	0919, 4297, 4537, 5360, 5373, 5388, 5400, 5478, 5479, 5805
ETCO	0703, 4127, 4584

EULANDER (ELBE)	4237
EUROCOM	4564
EURIELT	4141, 4161, 4335, 4338
EURODEC	4519, 4520, 4521, 4522
EUROPA	0703, 0797, 4127, 4189, 4211, 4412, 4427, 4436, 4473, 4584
EUROPHON	5376, 5408
EUROPLUS	4572
EUROSAT	0664, 0919, 4166, 4413, 4519, 5347, 5945
EUROSKY	4413, 4149, 4367, 4508, 4533, 5408
EUROSTAR	0730, 4333
EUTELSAT	4140, 4508, 4533
EUTRA	0725, 4525

EXITV	5946
FAIRMATE	0697, 4198, 4242, 4544, 4575, 5322, 5353, 5485, 5602, 6141
FAIT	0674, 0697, 4384, 4386, 4413, 5315, 5853, 6132
FALCON	0745, 5368
FENNER	0608, 0621, 0697, 0725, 4224, 4251, 4381, 4412, 4460, 4489, 4514, 4518, 4564, 4550, 4558, 5307, 5359
FERGUSON (THORN)	0378, 0619, 0630, 0660, 0672, 0694, 4438, 4507, 4584, 6192
FIDELITY	0660, 4459
FILMNET	0703, 0771, 0785, 4127, 4584
FINLUX	4341, 4458, 4555

FIRST 1.0	5075
FIRST LINE	5359
FLYCOM	5358, 5376
FM	0664, 0666
FMD	4295, 4296, 4367
FONESTAR	4295, 4307, 5881
FORCE	4176, 4245
FORGESTONE (THORN)	0378, 0619, 0630, 0660, 0694, 0919, 4438, 4507, 4584
FORTEC STAR	0919, 4166, 4287, 5304, 5360
FOXTEL (AU)	4492
FORMENTI	0608

FRACARRO	0621, 0674, 0684, 0697, 0745, 0774, 0778, 0785, 0794, 0800, 0917, 4203, 4210, 4305, 4327, 4329, 4336, 4339, 4367, 4403, 4414, 4422, 4455, 4494, 4496, 4534, 4541, 4557, 5304, 5332, 5333, 5340, 5347, 5357, 5359, 5364, 5385, 5804, 5853, 5945
FRANCE TEL	5351
FRANCE TELECOM	0703, 0771, 4127, 4582, 4584, 5351, 6285
FREE WAVE	4329, 4511, 4550, 5340, 5347, 5364, 5945
FREEBOX	4183, 6287, 6291
FREECOM	0621, 4223, 4247
FREEONE	4327, 5945

FREESAT	0621, 4412
FTE MAXIMAL	0664, 0666, 0674, 0725, 0794, 4211, 4331, 4342, 4361, 4403, 4406, 4412, 4417, 4496, 4567, 4580, 5340, 5347, 5945, 6147
FUBA	0608, 0619, 0621, 0647, 0672, 0676, 0718, 4142, 4149, 4251, 4164, 4301, 4321, 4329, 4338, 4339, 4367, 4384, 4386, 4399, 4408, 4508, 4513, 5317, 5340, 5347, 5354, 5355, 5359, 5364, 5482, 5562, 5563, 5603, 5812, 5930, 5941, 5945, 5953, 6129, 6136, 6138
FUJI ONKYO	0800, 4536, 4550, 5316, 5475, 5484
FUSION	4583, 5307
FUST	0629

GALAXI (FORMENTI)	0608
GALAXIS	5307
GALAXY	5307, 5312, 5322, 5340, 5346, 5347, 5354, 5364, 5382, 5383, 5461, 5945, 5951
GALAXY - GALAXIS	0629, 0664, 0666, 0731, 0785, 0797, 4189, 4196, 4318, 4322, 4415, 4438, 4442, 4516, 4571, 4590, 5457, 5458, 5459, 5460, 5461
GBC	5350, 5357, 5465, 5473, 5479, 5485, 5608
GE SER	4314
GEANTCASINO (OCEANIC)	0706, 0768, 0785, 4341, 4506
GECCO	4322
GEENTECH	4137, 4294

GENERAL	5426
GESER	5431
GF	4318
GLOBAL	4569
GLOBAL SPHERE	5356, 5952
GLOBO	4137, 4288, 4550, 4569
GMI	4413
GOLDBOX	0785
GOLD TOP	4438, 4505, 5307, 5330
GOLDEN INTERSTAR	4128, 4239, 4281
GOLDEN MEDIA	5944
GOLDMASTER	5382
GOLDSTAR (LG)	4247, 4251, 4338
GOODMANS	0703, 4127, 4438, 4584, 5307, 5359
GRADIENTE	4326, 4383

GR 15	4326
GRAETZ (ITT)	0669, 4302
GRANADA	0630, 0672, 4358
GRANDE (FORMENTI)	0608
GRANDIN	4141, 4161, 4335, 4336, 4338, 5359, 5964
GRANPRIX	54508
GREENTECH	5357
GROTHUSEN	0621, 4247
G-SAT	0694
GRUNDIG	0351, 0619, 0630, 0697, 0703, 0741, 0772, 4127, 4389, 4564, 4584, 4592, 4593, 5307, 5607
HAIER	5474
HANSEATIC	0660, 4408, 4565

HANTAREX	5328
HANTOR	0621
HANURI (LA SAT)	0608, 4400, 4402, 4415, 4446
HB	4221, 4220, 4314, 4329, 4575, 5340, 5349, 5353, 5359, 5364, 5374, 5945
HD80	0619
HD80-2T	5043
HD-Z1	5065
HEIRU	0619
HE@D	0919, 4256, 5360, 6133
HELECTRONIC (FORMENTI)	0608
HELIOCOM	4331

HIFIVOX (THOMSON)	0051, 0630, 0694, 0697, 0732, 0733, 0735, 0785, 0917, 1445, 4452, 4559, 4582
HINARI	0621, 0694, 5864
HIRSCHMANN	0608, 0619, 0672, 0674, 0676, 0718, 0800, 4142, 4196, 4205, 4288, 4301, 4386, 4394, 4422, 4423, 4440, 4445, 4526, 4538, 4555, 5307, 5310, 5340, 5347, 5352, 5357, 5364, 5408, 5945
HISAWA	4210, 4403, 4496
HISHITO (TOSHIBA)	0630, 4306
HITACHI	0431, 0630, 4341, 4438, 5307
HIVISION	5353
HOMECAST	4187, 4198, 4241, 4242, 4544, 4575, 4579, 5353

HORIZONT (PHILIPS)	0414, 0540, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4589, 4553
HOT	4325
HR	4268
HOT CHIP	5310, 5352, 5366
HOUSTON	4210, 4403, 4484, 4496, 4507
HUMAX	0797, 4189, 4196, 4219, 4228, 4277, 4541, 4549, 4584, 5307, 5329, 5342, 5345, 5350, 5360, 5371, 5380, 5424, 5816
HUTH	0629, 0718, 4153, 4149, 4169, 4193, 4204, 4232, 4331, 4413, 4415, 4460, 4508, 4533
HYDRA	5945
HYPSON	4338

HYRO	5362
HYSIS	5019
HYSIS 400	5020
HYUNDAI	4348, 4352, 4469, 4506, 5359, 5387, 5429, 5489
I CAN	5304, 5319, 5332, 5333, 5334, 5336, 5555, 5854
I JOY	5373, 5378, 5470, 5480, 5559, 5946, 5947
IAMM	5936
IBEROSAT	6110
ICAN	0917, 4305, 5319, 6129, 6147
ICX INTERNATIONAL	4446, 4487
ICE	4442
ID DIGITAL	4196, 4277, 5350, 5471, 5859, 5954

ID SAT	4271, 4290, 4541, 4578, 5323, 5377, 5400, 5431, 5435, 5859
IKUSI	5601
ILLUSION SAT	4590, 5601
IMEX	0684, 4335, 4338
IMPERIAL	4448, 4452, 5492
INNO HIT	4367, 5327, 5359, 5407
INTERNATIONAL	0697, 0730, 4446
INTERSAT (JOHANSSON)	4403, 4496
INTERSTAR	4128, 4281, 4450, 4536, 5348, 5360
INTERVISION	0664, 4415, 4423
INTRONIC	4307
INVES	4438
IOTRONIC	4148, 5430

IRRADIO	4232, 4269, 4381, 4537, 4550, 4558, 5327, 5332, 5333, 5340, 5347, 5364, 5365, 5370, 5376, 5383, 5386, 5406, 5480, 5603, 5945
ISV (JOHANSSON)	4403, 4496
ITALTEL	0733, 0774
ITC	0697
ITC ITE ITV	0697, 4564, 4589
ITD66 (SAGEM)	5037
ITD70 (SAGEM)	5053
ITS	4403, 4496
ITT	0672, 4302
ITT / NOKIA	5324, 5340, 5347, 5349, 5353, 5359, 5363, 5374, 5823, 5945
JAEGER	4550

JEC (TOSHIBA)	0630, 4306
JEEMON	0664
JEEWON	0664
JEPSEN	4128, 4511, 4571, 5346, 5946
JERROLD	4487
JOHANSSON	4403, 4496
JSR	0664, 0666
JOK	4489
JUPITER	4210, 4403, 4496
JVC	0749
KAMM	0731, 4415
KAMOSONIC	5470
KAMP (FORMENTI)	0608
KANARY	0725
KANGSLEY (FORMENTI)	0608

KAON MEDIA	4303
KAOSHO (SAMSUNG)	0646, 0733, 0797, 4146, 4225, 4226, 4227, 4266, 4267, 4291, 4292, 4322, 4361, 4418, 4422, 4467, 4481, 4512, 4528
KAPSCH (ITT)	4302
KATHREIN	0619, 0625, 0674, 0703, 0705, 0771, 4127, 4196, 4205, 4214, 4239, 4242, 4278, 4295, 4296, 4333, 4351, 4361, 4384, 4394, 4415, 4423, 4434, 4445, 4456, 4465, 4584, 4545, 5340, 5347, 5348, 5349, 5353, 5354, 5357, 5364, 5945
KAWASHO (FORMENTI)	0608
KENNEX	0800
KENWOOD	0785

KEYWAT	5310, 5352, 5821, 5823
KIOWA	4558
KITON	5359
KIZUKI	0676
KONIG	4570, 4136, 4352
KOOLTEK	5858
KOSCOM	4271, 4318, 5340, 5346, 5347, 5945
KOSMOS	0718, 4247, 4361, 4423, 5945
KPN	5353
KREILING	4320, 4321
KR	0725
KRIESELMEYER	0619, 4450
KRIESLER (PHILIPS)	0414, 0540, 0630, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589

KRONOS	4361
KTD	4296
KUCCAI	0748
KURO (SANYO)	4367
KYOSTAR	0621, 0800, 4168, 4211, 4339, 4423, 4508, 4533, 5347, 5359, 5945
L&S	4318
LAEMEX	5945
LA SAT	0608, 4400, 4402, 4415, 4446, 5408
LABGEAR	4585
LAEM SAT	0664, 0666
LASAT	0684, 4210, 4384, 4400, 4402, 4403, 4413, 4415, 4446, 4496
LAUSON	5802, 5855
LAZER	4541

LEADER	4338
LEGEND	0627, 0656, 0697, 0774, 0785, 4231, 4273, 4315, 4329, 4386, 4392, 4399, 4488, 4562, 4563, 5340, 5343, 5347, 5364, 5945
LEICO	4564
LEIKO	4367, 4546, 05354
LEMON	4320, 4541
LENCO	0621, 0672, 4247, 4415, 4564, 4565
LENG	4496
LENNOX	0608
LENOIR	4242, 5349, 5353
LENSON	4321, 4367
LEYCO	4251
LEXUS	0703, 4127, 4584

LG	4247, 5427, 5443, 5496
LIBERTY	5052
LIFE	5475
LINE@TECH	5930, 6129, 6146, 6147
LINQ	5939
LJOY	5373, 5378, 5470, 5480, 5559, 5947
LOGIK	4438, 5307
LODOS	4438
LORENZEN	0752, 0771, 4137, 4288, 4320, 4413, 4322, 4442, 4500, 4541, 5382, 5408, 5489
LOVE (ELBE)	4237
LTV (OCEANIC)	0706, 0768, 0785, 4341, 4506
LUPUS (ANKARO)	0608, 0629, 4446, 4460

LUXOR	0672, 0706, 0768, 4340, 4341
LUXORIT	4135
LYONNAISE CABLE	4582, 5351
LYOTRON (LG)	4247
MACAB	0785, 4160, 4173, 4210, 4403, 4406, 4496, 4567, 4582, 5343
MAESTRO	0735, 0745, 4321, 4399, 4572
MAGAVOX (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
MAGELLAN	4540
MAGIC SAT	4530
MAGIKE	4174, 4351
MAGNEX	0697

MAGSAT	4384
MAJESTIC	4237, 4297, 5324, 5326, 5327, 5466, 5477, 5478, 5479, 5485, 5491, 5600, 5801, 5854, 6146
MANATA	4149, 4338, 4431, 4508, 4533
MANHATTAN	0630, 0664, 0684, 0697, 0718, 0721, 0796, 0798, 0919, 4157, 4166, 4195, 4210, 4251, 4303, 4318, 4403, 4414, 4496, 4506, 5360
MARANN	4210, 4403, 4496
MALIGNE TV	6285, 6290
MARANTZ	0703
MASCOM	0684
MASPRO	0625, 0697, 0725, 4394
MASTER SAT	4211

MASTERS	0621, 0739, 4333, 4526
MATAV	4361
MATSUI	0703, 0749, 4127, 4251, 4438, 4564, 4584, 4591, 5307
MAXDOME	6294
MAXIMUM	5324, 5382
MAXTRONIC	4196
MCMICHEAL (PHILIPS)	0630, 0694, 0733, 0749, 0771, 0785, 0414, 2345, 4257, 43094422, 4465, 4545, 4553, 4589
MEDIABOX	0785
MEDIACOM	4450, 5315, 5327, 5358, 5383, 5431, 5485, 5814, 5878, 6149
MEDIAMARKT	4413
MEDIAMASTER	0739

MEDIAPRICE	5009, 5045, 5046, 5048, 5054, 5324, 5363, 5855, 5856
MEDIASAT	0739, 0785
MEDIASET	0785, 0917, 5304, 5332, 5333, 5482, 5555
MEDION	4318, 4565, 5359, 5408
MEGASAT	0703, 4127, 4584, 5376
MEGHA	0703
MELECTRONIC	0147, 0431, 4340
MELITA	4487
MEMPHIS	4249

METRONIC	0621, 0684, 0697, 0750, 0919, 4141, 4182, 4214, 4239, 4311, 4333, 4335, 4336, 4338, 4465, 4507, 4508, 4527, 4529, 5000, 5001, 5002, 5003, 5004, 5005, 5008, 5009, 5010, 5011, 5012, 5014, 5015, 5016, 5017, 5018, 5019, 5020, 5021, 5024, 5027, 5028, 5029, 5030, 5031, 5032, 5033, 5034, 5040, 5041, 5042, 5043, 5046, 5047, 5048, 5049, 5050, 5051, 5052, 5055, 5056, 5057, 5058, 5059, 5064, 5073, 5074, 5075, 5320, 5324, 5326, 5337, 5339, 5340, 5343, 5349, 5353, 5357, 5359, 5360, 5363, 5369, 5375, 5382, 5479, 5848, 5855, 5856, 5945, 5952
METZ	0619, 0625

MG ITEX	5411, 5465
MICROSAT	4318, 4537
MICRONIK	4171
MICROTECHNOG OLIE	0730
MIKRO DIGITAL	0752
MINERVA (GRUNDIG)	0619, 0630, 0741, 0749, 0772, 0785, 4389, 4564, 4592, 4593
MIRASAT	4295, 5357
MITSUBISHI	0378, 0619, 0630, 0660, 0694, 0919, 4438, 4507, 4584
MOLGAR	0703, 4127, 4584
MONTEREY	0735, 0745, 4321, 4399, 4572
MORGANS	4149, 4153, 4365, 4413, 4415, 4418, 4446, 4508, 4533
MOSER	0619

MOTOROLA	4305
MP MAN	5316, 5383, 5471, 5475
MULTICHOICE	0630, 0772, 0917, 4357, 5332, 5333
MULTISTAR	0741, 4361, 4394, 4400
MURATO	4481
MURPHY	4452
MVISION	4198, 4590, 5488, 5931, 5932
MWC	0619
MY SAT	0697
MY SKY	5300
MY SKY HD	5301
NAGRAVISION	5342, 5345, 5371
MAONIS (SELECO)	0414, 0621, 0697, 0774, 4569

NASSA NAGEL (ENGEL)	0621, 0785, 4237, 4291, 4292, 4293, 4295, 4297, 4299, 4365, 4367
NAVEX	4210, 4403, 4496
NEAHAUSAT	0697
NEC	4483
NEOM	5320, 5324, 5363
NEOM NM400HD	5070
NEOSAT	6145
NEOTION	4541, 4550
NETA	4253, 4309, 4553
NET BOX HD	5060
NETWORK	0694
NEUF TELECOM	4180, 6289, 6293
NEUF TV	6289, 6293
NEUHAUS	4193
NEUSAT	0697, 4210, 4318, 4403, 4496, 5348

NEVELING	4394, 4450, 4564
NEVIR	4199
NEWSTAR	5357
NEW WAVE	0750, 4239, 4324, 4573
NEWTON	0676, 4112, 4386
NEXPRO	5944
NEXT WAVE	0750, 4123, 4323, 4351, 4319, 4352, 4512, 4528, 4573, 4569
NICAMAGIC (FORMENTI)	0608
NIKKEI	5320, 5321
NIKKO	4212, 4402
NIMO	4280
NINBUS	0666
NODA	4529, 5029, 5032, 5033

NOGAMATIC (THOMSON)	0051, 0630, 0694, 0697, 0732, 0735, 0917, 1445, 4452, 4559, 4582
NOKIA	0383, 0630, 0672, 0706, 0739, 0748, 0768, 0785, 4149, 4275, 4302, 4332, 4338, 4340, 4508, 4533, 4555
NOOS	0732, 4582, 5343, 6283, 6285, 6286, 6292
NORDMENDE	0621, 0684, 4198, 4242, 4418, 4450, 4452, 4544, 4575, 5349, 5359, 5415, 5486, 5492, 5813, 5819, 5823, 5832, 5833, 5864, 5871, 6188, 6203
NORDTON (SELECO)	0414, 0621, 0697, 0774, 4569
NORKABEL	0672, 4487
NOT ONLY	5411

NOT ONLY TV	5325, 5411, 5412, 5478, 5926, 6140, 6146
NOVA	0751, 0772
NOVATRONIC	0629
NOVIS	4210, 4403, 4496
NPG	6131
NTC	0629, 0718
NTECH	5930, 6193
NUMERI CABLE	0785, 4582, 5351
OCEANIC	0672, 0706, 0785, 0768, 4341, 4406, 4506, 5489
OCTAGON	0621
OCTAL	0752, 5343
OCTAN (PHIKIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589

ODEON (AGASHI)	4413
OFFEL	6629, 0796
OKANO	4361, 4413
OLYMPUS	0697, 4399
OLYMPIC	0608, 0629, 4460
OLYMPUS	0697, 4399
ON DIGITAL	0769, 4306, 4589
ONDIAL	4508
OPENTEL	4314
OPENBOX	5346, 5360, 5951, 6143

OPTEX	0664, 0697, 0745, 4148, 4210, 4295, 4296, 4234, 4317, 4318, 4319, 4320, 4322, 4323, 4330, 4321, 4327, 4335, 4338, 4367, 4384, 4399, 4403, 4475, 4496, 4507, 4550, 4573, 5340, 5347, 5354, 5357, 5358, 5359, 5364, 5501, 5503, 5504, 5505, 5506, 5507, 5508, 5509, 5510, 5511, 5512, 5513, 5514, 5515, 5516, 5517, 5518, 5519, 5522, 5523, 5526, 5527, 5528, 5529, 5531, 5532, 5533, 5534, 5535, 5536, 5538, 5541, 5945, 6030, 6031, 6032, 6047
OPTEX TINTSAT	5069
OPTEX / BALMET	5525
OPTEX / STYX	5542
OPTIBOX	5951, 6137

OPTIMA	4198, 4237, 4506, 4569, 5331, 5340, 5484, 5489, 5601, 5943, 5944, 5946, 5951, 6147;0718
OPTUS (AU)	4492
ORANGE	4181, 6285, 6290, 6292
ORAVA	0703, 0771
ORBISAT	0697
ORBIT	0697, 4439, 4481, 4564
ORBITECH	0621, 0697, 0741, 4214, 4218, 4408, 4465
ORDA	4323
ORIGO	4448
OSAT	4459

OTHER	5006, 5007, 5035, 5036, 5037, 5038, 5044, 5046, 5053, 5060, 5061, 5062, 5069, 5070, 5072
OTTO VERSAND	0619, 4408
OURALIS EV 2	5018
OXFORD	4251
PACE	0630, 0694, 0725, 0733, 0745, 0769, 0785, 4133, 4274, 4358, 4412, 4414, 4554, 5340, 5347, 5364
PACIFIC	4406, 4540, 4573
PALCOM	4399, 4524, 4546, 4550, 5404
PALLADIUM	0621
PALSAT	0741, 4392, 4399, 4440, 4564
PANASAT	0772, 4562, 5339, 5343

PANASONIC	0733, 0769, 4562, 4574, 5339, 5343
PANDA	0660, 0672, 4318, 4396
PATH MARCONI (THOMSON)	0051, 0630, 0697, 0694, 0732, 0735, 0917, 1445, 4452, 4559, 4582
PATRICK	5465
PATRIOT	4140, 4149, 4251, 4508, 4533
PEARL	6002, 6003, 6004, 6005, 6006, 6007, 6008, 6010, 6014, 6015, 6016, 6023, 6024, 6025, 6026, 6027, 6029
PEEKTON	5927, 5929

PHILIPS	0414, 0629, 0630, 0694, 0697, 0703, 0733, 0749, 0771, 0785, 2345, 4141, 4161, 4127, 4214, 4257, 4309, 4333, 4365, 4422, 4465, 4545, 4553, 4565, 4584, 4589, 5303, 5305, 5338, 5361, 5402, 5418, 5809, 5950
PHILIPS (F) (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
PHOENIX	0694, 4413, 4448
PHONOLA (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
PHONOTREND	0929, 0664, 0718, 0751, 0797, 4173, 4189

PIONEER	0043, 0464, 0785, 0918, 5817, 5820
PIXX	4148, 4547
PK SAT (HIRSCHMANN)	0608, 0619, 0674, 4131, 4288, 4314, 4422, 4423, 4440, 4445, 4526, 4538, 4555
PLANET	4448, 5304
PLAYER	5055
PLUG IN	5040
PLUG IN 2	5057
PMB	0697, 0917, 4137, 4294, 4327, 4328, 4366, 4546, 5333, 5340, 5347, 5349, 5353, 5354, 5945
POLARIS	0676, 4142, 4386
POLLIN	5408
POLSAT	0752

POLYTRON (KATHREIN)	0625, 4240, 4295, 4351, 4361, 4384, 4394, 4423, 4434, 4445, 4456, 4465, 4545
PORTLAND	4585
POWER SKY	0919, 5360
PREDKI	4414, 4210, 4403, 4496
PREISNER	0676, 4142, 4149, 4193, 4386, 4446, 4508, 4533
PREMIER	0629, 0718, 0768, 4257
PREMIER 2	5041
PROBASIC	4280, 5337, 5356, 5374, 5435, 5802
PROCYON (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
PRODX	4169

PROFILINE	5359
PROMAX (PACE)	0630, 0694, 0733, 0745, 0769, 0785, 4133, 4274, 4347, 4358, 4412, 4414, 4448, 4554
PROSAT	0629, 0908, 4399, 4452, 4541
PROTEC	4406
PROTECH	4406, 4433, 5348
PROTEK	4239, 4317, 4406, 4426, 5348
PROVISAT	4223, 4433
PROVISION	0684, 0743, 0778, 0796
PYE (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
PYXIS	4318, 4324

QUADRAL	0621, 0629, 4193, 4450
QUADRO	4573, 5356, 5359
QUALI-TV	4200
QUENNFIDELITY (DAEWOO)	0621, 0697, 0748, 4348, 4585
QUELLE	0619, 0660, 4361, 4415
QUIERO TV	4582
QVISION	4590
RADIOLA (PHILIPS)	0414, 0630, 0694, 0749, 0733, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
RADIX	0676, 4142, 4384, 4386, 4529, 4564, 4573

RAINBOW (PACE)	0630, 0694, 0725, 0733, 0745, 0769, 0785, 4133, 4274, 4339, 4347, 4358, 4412, 4414, 4448, 4554
RCS	4278
RE	0664
REBOX	4511, 5340, 5945
REC	4484
REDBELL	5314
RED STAR	0608
REDO	4338
RENDER	5415, 5485
REX (SELECO)	0414, 0621, 0697, 0774, 4569
RFT (BRUNS)	0629, 0672, 0697, 4318, 4437, 4460, 4573

RITAR	0672, 0697, 4242, 4402, 5349, 5353, 5445
ROADSTAR	0697, 0730, 0785, 0919, 4327, 5340, 5347, 5359, 5360, 5364, 5945
ROCH	4338
ROMSAT	0621
RT850S:ORT8800	5308
ROVER	4367
RUEFACH (LENCO)	0621, 4564, 4565
SAB	4571, 5346
SABA	0630, 0672, 0684, 0694, 0718, 4141, 4161, 4204, 4223, 4415, 4433, 4452, 4489
SABC	4360

SABRE (PACE)	0630, 0694, 0733, 0745, 0769, 0785, 4133, 4274, 4347, 4358, 4412, 4414, 4448, 4554
SAGEM	0758, 4160, 4184, 4257, 4354, 4457, 4519, 4520, 4521, 4582, 5339, 5343, 5351, 5369, 5372, 5375, 5376, 5942, 6283, 6285, 6288
SAGEMCOM	5942, 6193
SAGEM TNSAT	5601
SAITO (OCEANIC)	0706, 0785, 4341, 4506
SAIVOD	4237, 5309, 5324
SAKURA	4448
SALORA	0672, 4340, 4341
SAMSAT	4314, 6155

SAMSUNG	0646, 0733, 0797, 4146, 4225, 4226, 4227, 4266, 4267, 4291, 4292, 4322, 4328, 4361, 4418, 4422, 4467, 4512, 4528, 5339, 5343, 5344, 5349, 5353, 5403, 5419, 5472, 5807, 5808, 6284
SANDOR (OCEANIC)	0706, 0785, 4341, 4506
SANSUI	5559, 5606, 6148
SANWA (SANYO)	4367
SANYO	4367, 5359
SAT	4388, 4481
SAT FORD	4484
SAT ITALIA (WISI)	0619, 0679, 0741, 4129, 4163, 4208, 4386, 4428, 4429, 4439, 4454, 4458, 4482, 4489, 4566, 4567, 4568
SAT MASTER	4190, 4460, 4484

SAT PARTNER	0703, 4127, 4247, 4403, 4496, 4584
SAT PLUS	4254, 4327, 4329, 4546, 4550
SAT+	0774, 4327, 4329, 4367, 4506, 4546, 4550, 5340, 5347, 5359, 5364, 5489, 5945
SATCOM	0621, 4484
SATEC	0694, 4484
SATECO	0621, 0664, 4565
SATELLITE	4440
SAT-URNE	5357
SBR (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4553, 4545, 4589
SCHAUB LORENZ	0672, 0697, 0768, 4220, 4237, 4329, 4341, 4511, 4575

SCHNEIDER	0674, 0697, 0703, 4127, 4327, 4333, 4365, 4413, 4454, 4482, 4514, 4565, 4584
SCHNEIDER (F) (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4545, 4589, 4553, 4465
SCHWAIGER	0694, 0797, 0919, 4141, 4161, 4148, 4166, 4189, 4193, 4218, 4234, 4258, 4260, 4261, 4262, 4263, 4264, 4290, 4296, 4303, 4314, 4352, 4365, 4384, 4438, 4509, 4514, 4529, 4541, 4547, 4565, 4581, 5100, 5101, 5102, 5103, 5104, 5105, 5106, 5107, 5108, 5109, 5110, 5111, 5408, 6048, 6049, 6050, 6051, 6272, 6214, 6260, 6273, 6274, 6275, 6276

SCOTLAND (PORMENTI)	0608
SCOTT	0778
SEARS (SANYO)	4367
SECTOR	4460
SEDEA	0621, 0674, 0800, 0919, 4140, 4149, 4166, 4170, 4263, 4323, 4450, 4508, 4527, 4533, 4535, 4536, 4573
SEELTECH	5309
SEEMAN	4386, 4413, 4491, 0676, 4142, 4386, 4251, 4413
SEG	0608, 0621, 0730, 4280, 4367, 4403, 4496, 4550, 4565, 5337, 0697, 4138, 5408, 5347, 5356, 5359, 5364, 5479, 5945

SEIGA (MITSUBISHI)	0619
SENYU	0674, 4589
SELECO	0414, 0621, 0697, 0774, 4569, 5359
SEPTIMO	4141, 4161, 4336, 4527, 4540, 5014, 5017, 5018, 5021
SERVIMAT	0697, 4327, 4546, 4575, 5340, 5347, 5349, 5353, 5354, 5364, 5404, 5479, 5945
SERVISAT	4415, 4338, 4367, 4550
SET ONE	5340, 5411, 5412, 5413, 5465, 5484, 5557, 5945, 6200
SHADOW	5362
SHARK	5346, 5432, 5455
SHOP+	5930

SHINELCO	5320, 5324, 5325, 5327, 5331, 5365, 5370, 5383, 5388, 5400, 5410, 5485, 5606, 5801
SICANTIC (LUXOR)	0672, 0706, 0768, 4340, 4341
SIGMATEK	6151
SIEMENS	0619, 4188, 4431, 4491, 4505, 4541, 5330
SILVERCREST	4202, 4595, 5359
SILVA	4247
SINGLE	5032
SINGLE 4.3	5074
SKANTIC (LUXOR)	0672, 0706, 0768, 4340, 4341
SKR	0697
SKT	4138, 5408
SKY	5302

SKY BIRO	0664, 0666
SKY BOX	6143
SKY BARSIL	4356, 4383
SKY ENGLAND	4308
SKY HD	5306
SKY IRELAND	4308
SKY LINE	0634
SKY MASTER	0629, 0697, 0731, 4204, 4327, 4337, 4352, 4518, 4541, 4526, 4550, 4565, 4518, 5945
SKY NEW ZELAND	4326, 4344, 4345, 4560
SKY PLUS	4322, 4550, 5945
SKY+	5390
SKYMASTER	0697, 4204, 4327, 4352, 4518, 4526, 4541, 4565, 5340, 5347, 5354, 5364

SKYMAX	0703
SKYVISION (HUTH)	0629, 4149, 4153, 4169, 4193, 4204, 4232, 4413, 4460
SL	4140, 4149, 4508, 4533
SM ELECTRONICS	0697, 4329, 5347, 5945
SMART	4140, 4149, 4215, 4295, 4314, 4365, 4508, 4533, 4538, 4550, 5056, 5340, 5347, 5357, 5604
SOLARIS	0724, 4196, 4507, 5350
SONORO (AGASHI)	4413
SONSTIGE	4320
SONY	0733, 0785, 4587
SONYSAT	5348
SPORTGENEXXA (FORMENTI)	0608

SR	4413
SRT5119+ SYSTEC	5036
SSANGYONG (SAMSUNG)	0646, 0733, 0797, 4146, 4225, 4226, 4227, 4267, 4291, 4292, 4322, 4328, 4361, 4422, 4418, 4467, 4512
STAB	0656
STABO	4234
STAR	5383, 5470, 5475
STAR DIJITAL	5339, 5343
STAR TRACK	0728, 0919, 4166
STARBOX	5358
STARCOM	4321, 4338, 5502, 5519, 5533, 5537, 5540, 5541
STARK	4296
STARRING	4210

STARLAND	0697, 4179, 4328, 4366, 4525, 4509
STARSAT	0697, 0919, 4270, 4301, 5358, 5360, 5805
STASSFURT (BRUNS)	0697, 4437, 4460
STELLA (CONNEXIONS SAT)	4386
STERN (SELECO)	0414, 0621, 0697, 0774, 4569
STREAM	0733, 0774

STRONG	0621, 0634, 0674, 0683, 0684, 0724, 0743, 0778, 0785, 0796, 0800, 0917, 4196, 4279, 4327, 4329, 4336, 4339, 4347, 4351, 4356, 4367, 4399, 4413, 4438, 4450, 4455, 4481, 4494, 4503, 4506, 4513, 4536, 4550, 4564, 5304, 5307, 5324, 5332, 5333, 5340, 5347, 5351, 5358, 5359, 5363, 5364, 5377, 5385, 5404, 5467, 5489, 5804, 5852, 5935, 5945
STRONG TINTSAT	5062
STVI	0785, 4338
STYX	4324, 4573, 5526, 5543
SUCCESS	4317
SUNKAI	4336
SUNMOONSTAR	0772, 0917, 5332, 5333

SUNNY	4303
SUNSTAR	0608, 4140, 4149, 4361, 4508, 4533
SUNSTECH	4237, 4298, 5309, 5324, 5327, 5363, 5478, 5485, 5491, 5854, 5946
SUPERJACK	4272
SYNCRO	4352
SYSTEC	4403, 4140, 4149, 4210, 4496, 4541, 4508, 4533, 4543, 4595
SYTEC SAT	4210
SYVO	0629
T HOME	6295
T LOGIC	5316
TAEYOUNG	0621, 0684
TAGASHI	4413
TAHNON	4529, 5029, 5032

TANTEC	4399
TATUNG	0619
TBOSTON	4237, 4296, 4297, 4362, 5357, 5358, 5377, 5479, 5854
TEAC / TEAK	0908, 5337, 6156
TECHNEMA (FORMENTI)	0608
TECHNIBOX	0771
TECHNICAL	4367
TECHNIKA	4220
TECHNISAT	0676, 0703, 0741, 0797, 1343, 4127, 4142, 4189, 4214, 4218, 4386, 4408, 4422, 4440, 4465, 4500, 4561, 4565, 4584
TECHNOSAT	0664, 0666, 4352, 4537
TECHNOSONIC	4220
TECHNOWELT	4141, 4161

TECHONMATE	4254, 4314
TECHWOOD	0703, 4127, 4438, 4367, 4584, 5359
TECO (AMSTRAD)	0647, 0656, 0660, 0733, 4413, 4149, 4150, 4300, 4305, 4329, 4367, 4388, 4396, 4418, 4564
TECSAT	0697
TECSOFT	5485
TELE+	0785
TELE 2BOX	6289
TELEAVIA (THOMSON)	0051, 0630, 0697, 0694, 0732, 0735, 0917, 1445, 4452, 4559, 4582
TELECIEL	4331, 4559
TELECO	0771, 0917, 4356, 4530, 5331, 5332, 5333, 5602
TELECOM	0664, 0666, 5937, 5938

TELEFUNKEN	0621, 4452
TELEKA	0676, 0718, 4142, 4318, 4339, 4361, 4386, 4413, 4418, 4423, 4439, 5340, 5347
TELEMASTER	0684, 0796
TELEMANN	4148
TELEMAX	0796, 4402
TELESERVICE	0785
TELESTAR	4214, 4465, 4541, 4550, 4565

TELESYSTEM	0674, 0731, 0785, 4327, 4329, 4367, 4381, 4546, 4550, 4565, 5310, 5311, 5318, 5340, 5347, 5352, 5354, 5355, 5359, 5364, 5366, 5381, 5384, 5400, 5401, 5404, 5408, 5435, 5482, 5489, 5555, 5556, 5560, 5561, 5562, 5563, 5603, 5812, 5930, 5941, 5945, 5953, 6129, 6136, 6138, 6144
TELETECH	0731
TELEVES	4134, 4148, 4149, 4153, 4223, 4508, 4511, 4533, 4541, 4543, 4573, 4595, 5425, 5430, 5470, 5881, 5889, 6154
TELEWIRE	0664, 0666, 4314, 4494, 4516, 4525, 4526, 5485, 6141, 6156

TELSEY	5435, 5485, 5555, 5854, 6142
TELKOM	4367, 5945
TEMAL	0697, 0703
TERMINAL NUMERIQUE	4294
TETHYS	5357
TEVION	4327, 4581, 5340, 5347, 5945
THES	5433, 5434, 5437, 5476, 5952
THOMSON	0051, 0630, 0694, 0697, 0732, 0735, 0785, 0917, 1445, 4141, 4161, 4452, 4415, 4356, 4559, 4582, 5332, 5333, 5339, 5343, 5351, 5368, 5930, 5935, 6286, 6290
THORENS	4426, 4406, 4452

THORN	0378, 0630, 0694, 0619, 0660, 0919, 4438, 4507, 4584, 5307
THORN FERGUSON	0660, 0672, 0703, 4127, 4394, 4396, 4584
THUNDERMAX	0624, 0676, 0703, 0706, 0785, 4127, 4142, 4211, 4386, 4399, 4504, 4534, 4584
TIVU BOX	4197, 5329, 5371
TM	4280
TMELECTRON	6131
TMX	0624, 0785, 4322, 4504, 4534
TOKAI	0703, 4127, 4584
TOKO (KATHREIN)	4545, 0619, 0625, 0771, 4238, 4240, 4242, 4295, 4351, 4361, 4384, 4394, 4423, 4434, 4445, 4465, 4456

TONBURY	4532, 4573
TONEBURST	4141, 4161
TONNA	0703, 4127, 4141, 4161, 4525, 4584, 4550
TONNA ELECTR.	0664, 0697, 4323, 4522
TONNA ELECTRONICS	5354
TOPFIELD	4301, 4322, 4442, 5341, 5382, 5524
TOPSAT	5358
TORRE (THOMSON)	0051, 0630, 0694, 0697, 0732, 0732, 0735, 0785, 0917, 1445, 4452, 4559, 4582
TOSHIBA	0630, 4306, 5488
TOUCHBOX	5028
TOUCHBOX 2	5030

TPS	4354, 4457, 4531, 5339, 5343, 6285, 6289, 6290
TPS / 441630	5007
TREVI	4237, 5324, 5327, 5363, 5374, 5388, 5470, 5485, 5600, 5854, 5878, 5879, 5880, 5881, 5882, 5889, 5946
TRIAD	0697, 4208, 4247, 4439, 4481
TRIASAT (WISI)	0619, 0697, 0741, 4129, 4163, 4208, 4386, 4428, 4429, 4454, 4458, 4567, 4482, 4489, 4566, 4568
TRIAX	0676, 0741, 4122, 4214, 4123, 4142, 4149, 4164, 4301, 4367, 4386, 4440, 4508, 4529, 4533, 4539, 4585, 5349, 5353, 5357, 5359, 5955, 5956, 6191
TRICAL	0184

TRIDENT	5358
TV CABO	0752, 4196
TV HOME	4500, 5369
TWINNER	0697, 0751, 4149, 4173, 4338, 4508, 4533, 4541, 4546
TWINSAT	0735, 0745, 4321, 4399, 4572
ULTIMATEBOX	5049
ULTRAVOX	0664, 0666, 0797
UNIDEN	4318, 4392, 4470
UNITED	5308, 5309, 5325, 5326, 5359, 5365, 5370, 5383, 5422, 5454, 5466, 5556, 5854, 5940, 5954
UNITOR	4210, 4403, 4496
UNIVERS	4342
UNIVERSUM	5408

UNIVERSUM (QUELLE)	0619, 0660, 4361, 4415, 4564
UNIXBOX	6135
UPC	6283, 6285, 6286
UTEK	5373
VARIOSAT (WISI)	0619, 0697, 0741, 4129, 4163, 4208, 4386, 4428, 4429, 4454, 4458, 4482, 4567, 4489, 4566, 4568
VENTANA	0703
VERSATEL	6284
VESTEL	4280, 4367, 5337, 5356, 5359
VETA	4253
VIA	0732, 0791, 4582
VIDEO LINK	4473
VIDEOTON	5359
VISA ELECTR:	0198

VISIONIC	0728, 0800, 0919, 4166, 4168, 4170, 4263, 4323, 4450, 4507, 4527, 4533, 4536, 4573, 4595
VISIONNET	4590
VISIONPLUS	0734
VISIOSPACE	0703, 4127, 4584
VISIOSAT	0664, 0697, 0800, 4142, 4148, 4149, 4210, 4295, 4296, 4321, 4334, 4403, 4414, 4489, 4496, 4509, 4525, 4547, 4595, 5357, 5358
VISTA (THORN)	0378, 0619, 0630, 0660, 0919, 0694, 4438, 4507, 4584
VORTEC	0621, 0697, 0797, 4418, 4422, 4538, 4539
VTECH	0697, 4247, 4333, 4439, 4454, 4482, 4489

WEGENER	4415
WELA	4193
WELKIN	0414
WESTWOOD	5359
WINBOX	4329, 5340, 5347, 5364, 5377, 5603, 5945
WINDSOR	5359
WINDSTAR (THORN)	0378, 0630, 0619, 0660, 0694, 0919, 4438, 4507, 4584
WINERSAT	4414, 4210, 4403, 4469
WINNER	4223, 4433, 4339, 4472
WINTERNITZ	0660, 4396

WISI	0619, 0676, 0697, 0741, 4129, 4142, 4163, 4193, 4208, 4386, 4415, 4428, 4429, 4439, 4454, 4458, 4482, 4489, 4566, 4568, 4567, 5408
WISIORBIT	4193
WITTENBERG	0694, 4388
WIZZ	4229
WOORISAT	0684
WORLDSAT	0735, 0745, 0751, 0917, 4141, 4137, 4149, 4161, 4173, 4247, 4251, 4294, 4356, 4367, 4399, 4508, 4533, 4572, 5332, 5333, 5368
WOXTER	4300, 4237, 5337, 5363
XCOM	0745, 0794
XORO	5356

XSAT	0745, 0794, 4141, 4161
XTREME	4303
YAMADA	5324, 5363
YEOMAN	5383, 5389
YES	4326
YUMATU	4569, 5489
ZANUSSI (SELECO)	0414, 0621, 0697, 0774, 4569
ZAPMASTER	5408
ZAPP	5346, 5349, 5350, 5353, 5358, 5359, 5376, 5382, 5383, 5461
ZAPPER	5802

ZEHNDER	0608, 0684, 4148, 4210, 4295, 4314, 4321, 4322, 4329, 4361, 4367, 4381, 4384, 4403, 4415, 4434, 4454, 4496, 4541, 4528, 4545, 5357, 5359, 6156
ZEM	5350, 5357, 5358, 5360, 5382, 5461, 5489
ZEPHIR	5383
ZINWELL	4515
ZODIAC	4550, 0621, 0676, 0731, 0919, 4165, 4166, 4223, 4295, 4310, 4318, 4327, 4329, 4433, 4339, 4381, 4460, 4472, 4550, 4558, 5340, 5346, 5347, 5357, 5358, 5360, 5362, 5364, 5365, 5370, 5373, 5374, 5376, 5378, 5383, 5386, 5470, 5482, 5603, 5802, 5811, 5862, 5889, 5945

ZOTA	0703, 4127, 4584
ZWERNASE	4413

COMAG	4288, 4295, 4576, 4580
DREAMBOX	4234, 4284, 4285, 4362, 5358
FERGUSON	0378, 0619, 0630, 0660, 0672, 0694, 4438, 4507, 4584, 6192
EDISION	4290, 5442
HUMAX	0797, 4189, 4196, 4219, 4228, 4277, 4541, 4549, 4584, 5307, 5329, 5342, 5345, 5350, 5360, 5371, 5380, 5424, 5816
KATHREIN	0619, 0625, 0674, 0703, 0705, 0771, 4127, 4196, 4205, 4214, 4239, 4242, 4278, 4295, 4296, 4333, 4351, 4361, 4384, 4394, 4415, 4423, 4434, 4445, 4456, 4465, 4584, 4545, 5340, 5347, 5348, 5349, 5353, 5354, 5357, 5364, 5945

LG	4247, 5427, 5443, 5496
MEDION	4318, 4565, 5359, 5408
MEGASAT	0703, 4127, 4584, 5376
OCTAGON	0621
PANASONIC	0733, 0769, 4562, 4574, 5339, 5343
PEARL	6002, 6003, 6004, 6005, 6006, 6007, 6008, 6010, 6014, 6015, 6016, 6023, 6024, 6025, 6026, 6027, 6029
PHILIPS	0414, 0629, 0630, 0694, 0697, 0703, 0733, 0749, 0771, 0785, 2345, 4141, 4161, 4127, 4214, 4257, 4309, 4333, 4365, 4422, 4465, 4545, 4553, 4565, 4584, 4589, 5303, 5305, 5338, 5361, 5402, 5418, 5809, 5950
PROTEK	4239, 4317, 4406, 4426, 5348

SAMSUNG	0646, 0733, 0797, 4146, 4225, 4226, 4227, 4266, 4267, 4291, 4292, 4322, 4328, 4361, 4418, 4422, 4467, 4512, 4528, 5339, 5343, 5344, 5349, 5353, 5403, 5419, 5472, 5807, 5808, 6284
SCHWAIGER	0694, 0797, 0919, 4141, 4161, 4148, 4166, 4189, 4193, 4218, 4234, 4258, 4260, 4261, 4262, 4263, 4264, 4290, 4296, 4303, 4314, 4352, 4365, 4384, 4438, 4509, 4514, 4529, 4541, 4547, 4565, 4581, 5100, 5101, 5102, 5103, 5104, 5105, 5106, 5107, 5108, 5109, 5110, 5111, 5408, 6048, 6049, 6050, 6051, 6272, 6214, 6260, 6273, 6274, 6275, 6276
SKYMASTER	0697, 4204, 4327, 4352, 4518, 4526, 4541, 4565, 5340, 5347, 5354, 5364

SONY	0733, 0785, 4587
TECHNISAT	0676, 0703, 0741, 0797, 1343, 4127, 4142, 4189, 4214, 4218, 4386, 4408, 4422, 4440, 4465, 4500, 4561, 4565, 4584
TELESTAR	4214, 4465, 4541, 4550, 4565
THOMSON	0051, 0630, 0694, 0697, 0732, 0735, 0785, 0917, 1445, 4141, 4161, 4452, 4415, 4356, 4559, 4582, 5332, 5333, 5339, 5343, 5351, 5368, 5930, 5935, 6286, 6290
(RE)PLAYBOX	5024
253	5501
@MEDIA	4505
@SKY	4541
@SAT	4303, 4234, 4177
441250	5027, 5373, 5359

@STAR	4271
AB COM	5489, 06150, 6152, 6199
AB SAT	0794
441408	5016
ACCESS MEDIA	0733, 4505, 5330
ACCESS BOX	5017
ACEC (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 4257, 4309, 4422, 4465, 4545, 4589, 4553, 2345
ADB	0917, 4305, 4356, 5304, 5319, 5332, 5333, 5334, 5335, 5336, 5854
ADL	4541
ADR	4218
AGASHI	4413
AEGYR	0684
AGB (SABA)	0630, 0694, 0718, 4204, 4452, 4566

AGEF (BRUNS)	0697, 4437, 4460
AIRIS	4296, 4298, 5309, 5358, 5853, 5854, 5930, 6154
AITECH	5332, 5333
AKAI	0703, 4127, 4251, 4505, 4584, 5316, 5388, 5559, 5875, 5860
AKIRA	5930
AKTRON (TOSHIBA)	0630, 4306
ALBA	0621, 0629, 0697, 0739, 4223, 4251, 4297, 4339, 4433, 4448, 4450, 4452, 4458, 5307, 5359, 5479, 5839, 5864
ALDES	0629, 0684, 4223, 4337
ALICE	5339, 5343, 5937, 5938, 6285
ALKOS (TOSHIBA)	0630, 4306
ALITEK	5520, 5533

ALLSAT	0664, 0703, 4127, 4584
ALLSONIC	0629
ALLTECH	0725, 4406
ALLVISION	5408
ALPHA	3125
ALTAI	4386
ALTEK	5331, 5383
ALTERBOX	5059, 5072
AMIKO	5944, 6180
AMITONIKA	4367
AMPERE (ARCON)	0614, 0919, 4331, 4418, 4507, 4571

AMSTRAD	0647, 0656, 0660, 0672, 0676, 0733, 0797, 4141, 4142, 4149, 4150, 4161, 4189, 4300, 4305, 4329, 4367, 4386, 4388, 4396, 4418, 4508, 4533, 5304, 5327, 5337, 5340, 5347, 5358, 5359, 5379, 5364, 5945
ANDERSSON	5465
ANIKO	5465
ANITECH	0697
ANKARO	0608, 0629, 0676, 4142, 4318, 4337, 4386, 4460, 4446, 5360
ANSONIC	5479
ANTARES	4415, 4296, 5358, 5469, 5487
ANTTRON	0621, 0694

ANVIMUR	4281, 4538, 4575, 5340, 5347, 5349, 5353, 5364
APOLLO	0321
AQP (GRUNDIG)	0531, 0619, 0630, 0772, 0741, 0749, 0785, 4389, 4592, 4593
ARCENCIEL (THOMSON)	0051, 0630, 0694, 0697, 0732, 0735, 0917, 1445, 4452, 4559, 4582
ARCON	0614, 0919, 4418, 4331, 4507, 4571, 5346, 5360
ARIASAT	5350, 5357, 5358, 5408, 5489
ARION	0919, 4186, 4507, 5360
ARISTONA (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4589, 4553

ARIZA	5348
ARMSTRONG	0703, 4402, 4413
ARNION	4303
ARROX	4296
ARTHURMARTINI (SALORA)	0672, 4340, 4341
ASAHI	5346, 5357, 5358
ASCI	4541
ASHIN	4418
ASSCOM	0785
AST	0669, 0672, 4454, 4481
ASTEL	4347, 4455
ASTI	0725
ASTON	0624, 0664, 0676, 4142, 4334, 4386, 4556

ASTRA	0672, 0676, 0694, 0703, 4127, 4142, 4386, 4394, 4413, 4427, 4436, 4446, 4564, 4473, 4584
ASTRASAT	5358
ASTRATEC	5307
ASTRELL	4141, 4161, 4529, 5856, 5930
ASTRO	0619, 0625, 0684, 0741, 0771, 4218, 4288, 4339, 4352, 4538, 4545, 4595, 5340, 5347
ASTROVOX	5358
ATLANTA	4149, 4237, 4298, 4299, 4352, 4508, 4533, 5324
ATLANTIC (FORMENTI)	0608
ATLANTIS	0621, 0701

AUDIOLA	5324, 5326, 5363, 5466, 5479, 5485, 5491, 5600, 5801, 5854
AUDIOLINE	4581
AUDIOTON	0664
AUNA	4276
AURIGA	0630, 0684, 0917, 4305, 5304, 5332, 5333, 5346, 5365, 5370, 5345
AUTOVOX	5324, 5359, 5363, 5383, 5466, 5810, 5853, 5946
AVALON	0676, 4142, 4386
AVION	0919, 4166
AXIL	4237, 4293, 4295, 4296, 4297, 4321, 4367, 5324, 2337, 5357, 5338, 5359, 5363, 5373, 5479, 5485, 5802, 5854, 5935, 6194

AXIS	0608, 4318, 5307
AXOSAT	0697, 0743
AXITRONIC	4367
BAFF	5357
BALMET	4233, 4234, 4235, 4295, 4296, 4528, 5503, 5521, 5530, 5533, 5539, 5357, 5358, 5362
BEC	4510
BEKO	5489
BELSON	4201
BENJAMIN	4474, 4506, 5489
BEST	0608, 0629, 5360
BEST BUY	5324, 5325, 5363, 5466, 5815, 5933, 6131, 6140, 6146
BETA	0703, 4127, 4584
BIG SAT	4281, 4296, 5358

BINATONE	4491
BLACK DIAMOND	4438, 5307, 5359
BLANK	5524
BLAUPUNKT	0619
BLUESKY	4149, 4508, 4522, 4533
BLUESTAR	5864
BLUETINUM	5356, 5373
BLUSENS	5802
BOCA (AMSTRAD)	0647, 0656, 0660, 0733, 4149, 4150, 4300, 4305, 4329, 4365, 4367, 4388, 4396, 4413, 4418, 4446, 4508, 4533
BOSHMANN	5357
BOSTON	4149, 4237, 4296, 4297, 4331, 4365, 4367, 4508, 4533, 5358, 5479
BOTECH	4236

BOX	4557
BOX ALTERBOX	5071
BOX NEUF	5068
BOX ORANGE	5067
BQS	5945
BRAIN WAVE	0752, 4210, 4403, 4414, 4496, 4580, 4545, 4581, 5354
BRAND- TELETRONIQUE (THOMSON)	0051, 0630, 0694, 0697, 0732, 0735, 0785, 0917, 1445, 4452, 4582, 4459
BRAVO	4289, 5346, 5409, 5456, 5463, 5493
BRUNS	0697, 4437, 4460
BSB	0703, 4127, 4584
BT	4251
BUSH	0630, 0739, 4438, 4448, 4452
BW	4581

CALE	5490
CALIFORNIA (FORMENTI)	0608
CAMBRIDGE	0741, 4251, 4413
CANAL SAT	0785
CANAL +	0785, 4184, 4185
CANALERA	9006, 9009
CANDEL (LG)	4247
CARDMANIA	5365, 5370, 5377, 5435
CARYONSE (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4553, 4545, 4589
CASEMA	4582, 5369
CASONIO (OCEANIC)	0706, 0785, 4341, 4506
CDV	4577, 5337, 5464
CERT	0672

CENTURY	4383
CGV	4295, 4538, 5340, 5347, 5357, 6137
CHANNEL MASTER	4250
CHAPARRAL	4249
CHEROKEE	0735, 0745, 4137, 4294, 4321, 4338, 4399, 4572, 5368
CHESS	4288
CITIZEN	0674
CITY COM	0674, 4196, 4295, 4314, 4333, 4351, 4352, 4384, 4415, 4434, 4551, 5350, 5357, 5408
CLARKE - TECH	4286, 4578
CLATRONIC	4403, 4496, 5313, 5374, 5485, 5880

CLEMENS CAMPUS (HUTH)	0629, 4123, 4149, 4153, 4169, 4193, 4204, 4232, 4352, 4413, 4460
CME	0627, 0630, 0706, 0739, 0748, 0768, 0769, 0771, 0774, 5945
CMR	0697, 4248
CMX	5933
COBRA	0676, 0731, 0778, 4142, 4252, 4305, 4311, 4318, 4352, 4386, 4512, 4540, 5304, 5312, 5327, 5356, 5358, 5362, 5376, 5383, 5554, 5800, 5802, 5805, 5815, 5933, 6139, 6146
COFADEL (THOMSON)	0051, 0630, 0694, 0697, 0732, 0735, 0917, 1445, 4452, 4559, 4582
COLORADO	0697

COLUMBUS	0735, 0745, 4178, 4321, 4399, 4572, 5368
COMAG	4288, 4295, 4576, 4580
COMMLINK	0629
COMSAT	0718, 5340, 5347, 5357, 5364, 5430, 5945
COMTEC	4394
COMWELL	4571, 5346
CONAX	5346
CONCERTO (LG)	4247
CONCORD	4542
CONDOR	0608
CONNEXIONS SAT	4368
CONTEC	4361
CONRAD	5342, 5345, 5350, 5351, 5408

CONTIN: EDIS: (THOMSON)	0051, 0630, 0694, 0697, 0732, 0735, 0917, 1445, 4452, 4559, 4582
CONTINENT	5343
COSAT	0666
COSHIP	4252, 4296, 5358, 5359, 5376
CPC	0672
CROWN	0734, 4413, 5307, 5359, 5864
CSN	5006
CYFRA PLUS	0785
DAEWOO	0621, 0697, 0748, 4348, 4361, 4585, 5307, 5450
DAK	4300
DANSAT	0694
DANTAX	5359
DANYSTAR	5338

DATCOM	4542
DARTY	6285, 6290
DATRONIC (DAEWOO)	0621, 0697, 0748, 4348, 4585
DAXIS	6110
DAYTONA	4149, 4508, 4533
DAYTRONIC (DAEWOO)	0621, 0697, 0748, 4348, 4585
D-BOX	0768
DBOX-DF1	0739
DDC	0621, 4450
DELFA	0797
DELSAT	4352
DELTA	5353
DELTALINE	5353
DELTASAT	4352
DENTAL (FORMENTI)	0608

DENVER	5440, 6128
DHS (ASTRA)	0694, 4394, 4427, 4436, 4473, 4564
DICRA	5405, 5854
DIEVO	5365, 5370
DIGIAN	4506
DIGICOM	5350
DIGIFOX	5342, 5345
DIGIFREE	5307
DIGIFUSION	4583, 5307
DIGIMASTER	5360, 5382
DIGIHOME	5359

DIGIQUEST	0797, 0919, 4166, 4189, 4196, 4242, 4290, 4296, 4303, 4305, 5304, 5316, 5349, 5350, 5353, 5358, 5360, 5362, 5365, 5367, 5370, 5400, 5435, 5466, 5485, 5853, 5590, 5930, 5944, 6131, 6139, 6196, 6197, 6198
DIGISAT	5352, 5362, 5400, 5410, 5465, 5466
DIGISKY	5358
DIGIT ALL	4512
DIGITAL	4288, 4351, 4367, 4541, 4550
DIGITAL BOX	5329, 5371
DIGITAL +	0732
DIGITRONIC	0800, 0919, 4149, 4166, 4170, 4508, 4533, 4573, 5360
DIGIX	4303

DIGIZAP	5307
DIKOM	5388, 5400, 5495, 5802, 5803
DIPRO	0917, 4356, 4305, 5304, 5332, 5333, 5346, 5362, 5365, 5370, 5435
DIRECTBOX2	5050
DIRECTBOX3	5051
DISCOVERY	4137, 4294, 5368
DISEQC	0731, 4140, 4149, 4508, 4533, 4550
DISISTRAT	0703, 4127, 4584
DISTRA	4338
DISTRATEL	4141, 4149, 4161, 4335, 4336, 4507, 4508, 4529, 4533, 4540, 5001, 5002, 5012, 5014, 5015, 5016, 5029, 5031, 5032, 5033
DISTRISAT	0703

DMSIS	4506, 5489
DNT	0676, 0703, 4127, 4142, 4386, 4584
DPM	5446
DRAGON BOX	4281
DRAKE	0614, 4269, 4338, 4351, 4399, 4412, 4541, 5335
DREAMBOX	4234, 4284, 4285, 4362, 5358
DTI 1000 (THOMSON)	5035
DTT	4546
DUALIS	5021
DUALISBOX	5048
DUAL- STREAMBOX	5058
DUNE	5373

DVB	4138, 4329, 4541, 5340, 5411, 5413, 5945
D-VISION	5359
DVR01 / EH-M1	5064
DYNASAT	0621, 0674, 4205, 4473
DYNATRON (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
EASY	5029
EASY 3	5047
EASY 2 / PREM 3	5046
EASY LIVING	5819, 5823, 5871
ECHOLITE	4541

ECHOSTAR	0627, 0656, 0697, 0732, 0774, 0791, 4273, 4296, 4305, 4315, 4329, 4354, 4386, 4392, 4399, 4457, 4488, 4562, 4563, 5304, 5339, 5340, 5343, 5347, 5358, 5364, 5945
EDISION	4290, 5442
EIF	4338
EINHELL	0621, 0672, 0734, 4413
ELAP	0697, 4329, 4550, 5340, 5347, 5348, 5364, 5404, 5945
ELBE	4237, 5324, 5359
ELIN	4341
ELIUM	4132
ELLIES	4357, 4407
ELSAT	0660, 5945

ELTA	0608, 0621, 0664, 0703
EMANON	0621
EMATEC (OCEANIC)	0706, 0768, 0785, 4341, 4506
EMCO (IMPERIAL)	4448, 4452
EMME ESSE	0608, 0674, 0706, 0718, 0774, 0785, 0917, 4128, 4205, 4254, 4271, 4331, 4356, 4399, 4445, 4458, 4473, 4511, 4513, 4517, 4523, 4548, 5332, 5333, 5438, 5954
EMTECH	4511, 4544
EMTEC	5479

ENGEL	0621, 0785, 4237, 4291, 4292, 4293, 4295, 4297, 4299, 4365, 4367, 5324, 5337, 5340, 5347, 5354, 5357, 5358, 5359, 5360, 5363, 5364, 5479, 5802, 5854, 5945
EP SAT (PACE)	0630, 0694, 0733, 0745, 0769, 0785, 4133, 4274, 4347, 4358, 4412, 4414, 4448, 4554
EQUATOR	0694
ERRES (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
E-SPACE	0919, 4297, 4537, 5360, 5373, 5388, 5400, 5478, 5479, 5805
ETCO	0703, 4127, 4584

EULANDER (ELBE)	4237
EUROCOM	4564
EURIELT	4141, 4161, 4335, 4338
EURODEC	4519, 4520, 4521, 4522
EUROPA	0703, 0797, 4127, 4189, 4211, 4412, 4427, 4436, 4473, 4584
EUROPHON	5376, 5408
EUROPLUS	4572
EUROSAT	0664, 0919, 4166, 4413, 4519, 5347, 5945
EUROSKY	4413, 4149, 4367, 4508, 4533, 5408
EUROSTAR	0730, 4333
EUTELSAT	4140, 4508, 4533
EUTRA	0725, 4525

EXITV	5946
FAIRMATE	0697, 4198, 4242, 4544, 4575, 5322, 5353, 5485, 5602, 6141
FAIT	0674, 0697, 4384, 4386, 4413, 5315, 5853, 6132
FALCON	0745, 5368
FENNER	0608, 0621, 0697, 0725, 4224, 4251, 4381, 4412, 4460, 4489, 4514, 4518, 4564, 4550, 4558, 5307, 5359
FERGUSON (THORN)	0378, 0619, 0630, 0660, 0672, 0694, 4438, 4507, 4584, 6192
FIDELITY	0660, 4459
FILMNET	0703, 0771, 0785, 4127, 4584
FINLUX	4341, 4458, 4555

FIRST 1.0	5075
FIRST LINE	5359
FLYCOM	5358, 5376
FM	0664, 0666
FMD	4295, 4296, 4367
FONESTAR	4295, 4307, 5881
FORCE	4176, 4245
FORGESTONE (THORN)	0378, 0619, 0630, 0660, 0694, 0919, 4438, 4507, 4584
FORTEC STAR	0919, 4166, 4287, 5304, 5360
FOXTEL (AU)	4492
FORMENTI	0608

FRACARRO	0621, 0674, 0684, 0697, 0745, 0774, 0778, 0785, 0794, 0800, 0917, 4203, 4210, 4305, 4327, 4329, 4336, 4339, 4367, 4403, 4414, 4422, 4455, 4494, 4496, 4534, 4541, 4557, 5304, 5332, 5333, 5340, 5347, 5357, 5359, 5364, 5385, 5804, 5853, 5945
FRANCE TEL	5351
FRANCE TELECOM	0703, 0771, 4127, 4582, 4584, 5351, 6285
FREE WAVE	4329, 4511, 4550, 5340, 5347, 5364, 5945
FREEBOX	4183, 6287, 6291
FREECOM	0621, 4223, 4247
FREEONE	4327, 5945

FREESAT	0621, 4412
FTE MAXIMAL	0664, 0666, 0674, 0725, 0794, 4211, 4331, 4342, 4361, 4403, 4406, 4412, 4417, 4496, 4567, 4580, 5340, 5347, 5945, 6147
FUBA	0608, 0619, 0621, 0647, 0672, 0676, 0718, 4142, 4149, 4251, 4164, 4301, 4321, 4329, 4338, 4339, 4367, 4384, 4386, 4399, 4408, 4508, 4513, 5317, 5340, 5347, 5354, 5355, 5359, 5364, 5482, 5562, 5563, 5603, 5812, 5930, 5941, 5945, 5953, 6129, 6136, 6138
FUJI ONKYO	0800, 4536, 4550, 5316, 5475, 5484
FUSION	4583, 5307
FUST	0629

GALAXI (FORMENTI)	0608
GALAXIS	5307
GALAXY	5307, 5312, 5322, 5340, 5346, 5347, 5354, 5364, 5382, 5383, 5461, 5945, 5951
GALAXY - GALAXIS	0629, 0664, 0666, 0731, 0785, 0797, 4189, 4196, 4318, 4322, 4415, 4438, 4442, 4516, 4571, 4590, 5457, 5458, 5459, 5460, 5461
GBC	5350, 5357, 5465, 5473, 5479, 5485, 5608
GE SER	4314
GEANTCASINO (OCEANIC)	0706, 0768, 0785, 4341, 4506
GECCO	4322
GEENTECH	4137, 4294

GENERAL	5426
GESER	5431
GF	4318
GLOBAL	4569
GLOBAL SPHERE	5356, 5952
GLOBO	4137, 4288, 4550, 4569
GMI	4413
GOLDBOX	0785
GOLD TOP	4438, 4505, 5307, 5330
GOLDEN INTERSTAR	4128, 4239, 4281
GOLDEN MEDIA	5944
GOLDMASTER	5382
GOLDSTAR (LG)	4247, 4251, 4338
GOODMANS	0703, 4127, 4438, 4584, 5307, 5359
GRADIENTE	4326, 4383

GR 15	4326
GRAETZ (ITT)	0669, 4302
GRANADA	0630, 0672, 4358
GRANDE (FORMENTI)	0608
GRANDIN	4141, 4161, 4335, 4336, 4338, 5359, 5964
GRANPRIX	54508
GREENTECH	5357
GROTHUSEN	0621, 4247
G-SAT	0694
GRUNDIG	0351, 0619, 0630, 0697, 0703, 0741, 0772, 4127, 4389, 4564, 4584, 4592, 4593, 5307, 5607
HAIER	5474
HANSEATIC	0660, 4408, 4565

HANTAREX	5328
HANTOR	0621
HANURI (LA SAT)	0608, 4400, 4402, 4415, 4446
HB	4221, 4220, 4314, 4329, 4575, 5340, 5349, 5353, 5359, 5364, 5374, 5945
HD80	0619
HD80-2T	5043
HD-Z1	5065
HEIRU	0619
HE@D	0919, 4256, 5360, 6133
HELECTRONIC (FORMENTI)	0608
HELIOCOM	4331

HIFIVOX (THOMSON)	0051, 0630, 0694, 0697, 0732, 0733, 0735, 0785, 0917, 1445, 4452, 4559, 4582
HINARI	0621, 0694, 5864
HIRSCHMANN	0608, 0619, 0672, 0674, 0676, 0718, 0800, 4142, 4196, 4205, 4288, 4301, 4386, 4394, 4422, 4423, 4440, 4445, 4526, 4538, 4555, 5307, 5310, 5340, 5347, 5352, 5357, 5364, 5408, 5945
HISAWA	4210, 4403, 4496
HISHITO (TOSHIBA)	0630, 4306
HITACHI	0431, 0630, 4341, 4438, 5307
HIVISION	5353
HOMECAST	4187, 4198, 4241, 4242, 4544, 4575, 4579, 5353

HORIZONT (PHILIPS)	0414, 0540, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4589, 4553
HOT	4325
HR	4268
HOT CHIP	5310, 5352, 5366
HOUSTON	4210, 4403, 4484, 4496, 4507
HUMAX	0797, 4189, 4196, 4219, 4228, 4277, 4541, 4549, 4584, 5307, 5329, 5342, 5345, 5350, 5360, 5371, 5380, 5424, 5816
HUTH	0629, 0718, 4153, 4149, 4169, 4193, 4204, 4232, 4331, 4413, 4415, 4460, 4508, 4533
HYDRA	5945
HYPSON	4338

HYRO	5362
HYSIS	5019
HYSIS 400	5020
HYUNDAI	4348, 4352, 4469, 4506, 5359, 5387, 5429, 5489
I CAN	5304, 5319, 5332, 5333, 5334, 5336, 5555, 5854
I JOY	5373, 5378, 5470, 5480, 5559, 5946, 5947
IAMM	5936
IBEROSAT	6110
ICAN	0917, 4305, 5319, 6129, 6147
ICX INTERNATIONAL	4446, 4487
ICE	4442
ID DIGITAL	4196, 4277, 5350, 5471, 5859, 5954

ID SAT	4271, 4290, 4541, 4578, 5323, 5377, 5400, 5431, 5435, 5859
IKUSI	5601
ILLUSION SAT	4590, 5601
IMEX	0684, 4335, 4338
IMPERIAL	4448, 4452, 5492
INNO HIT	4367, 5327, 5359, 5407
INTERNATIONAL	0697, 0730, 4446
INTERSAT (JOHANSSON)	4403, 4496
INTERSTAR	4128, 4281, 4450, 4536, 5348, 5360
INTERVISION	0664, 4415, 4423
INTRONIC	4307
INVES	4438
IOTRONIC	4148, 5430

IRRADIO	4232, 4269, 4381, 4537, 4550, 4558, 5327, 5332, 5333, 5340, 5347, 5364, 5365, 5370, 5376, 5383, 5386, 5406, 5480, 5603, 5945
ISV (JOHANSSON)	4403, 4496
ITALTEL	0733, 0774
ITC	0697
ITC ITE ITV	0697, 4564, 4589
ITD66 (SAGEM)	5037
ITD70 (SAGEM)	5053
ITS	4403, 4496
ITT	0672, 4302
ITT / NOKIA	5324, 5340, 5347, 5349, 5353, 5359, 5363, 5374, 5823, 5945
JAEGER	4550

JEC (TOSHIBA)	0630, 4306
JEEMON	0664
JEEWON	0664
JEPSEN	4128, 4511, 4571, 5346, 5946
JERROLD	4487
JOHANSSON	4403, 4496
JSR	0664, 0666
JOK	4489
JUPITER	4210, 4403, 4496
JVC	0749
KAMM	0731, 4415
KAMOSONIC	5470
KAMP (FORMENTI)	0608
KANARY	0725
KANGSLEY (FORMENTI)	0608

KAON MEDIA	4303
KAOSHO (SAMSUNG)	0646, 0733, 0797, 4146, 4225, 4226, 4227, 4266, 4267, 4291, 4292, 4322, 4361, 4418, 4422, 4467, 4481, 4512, 4528
KAPSCH (ITT)	4302
KATHREIN	0619, 0625, 0674, 0703, 0705, 0771, 4127, 4196, 4205, 4214, 4239, 4242, 4278, 4295, 4296, 4333, 4351, 4361, 4384, 4394, 4415, 4423, 4434, 4445, 4456, 4465, 4584, 4545, 5340, 5347, 5348, 5349, 5353, 5354, 5357, 5364, 5945
KAWASHO (FORMENTI)	0608
KENNEX	0800
KENWOOD	0785

KEYWAT	5310, 5352, 5821, 5823
KIOWA	4558
KITON	5359
KIZUKI	0676
KONIG	4570, 4136, 4352
KOOLTEK	5858
KOSCOM	4271, 4318, 5340, 5346, 5347, 5945
KOSMOS	0718, 4247, 4361, 4423, 5945
KPN	5353
KREILING	4320, 4321
KR	0725
KRIESELMEYER	0619, 4450
KRIESLER (PHILIPS)	0414, 0540, 0630, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589

KRONOS	4361
KTD	4296
KUCCAI	0748
KURO (SANYO)	4367
KYOSTAR	0621, 0800, 4168, 4211, 4339, 4423, 4508, 4533, 5347, 5359, 5945
L&S	4318
LAEMEX	5945
LA SAT	0608, 4400, 4402, 4415, 4446, 5408
LABGEAR	4585
LAEM SAT	0664, 0666
LASAT	0684, 4210, 4384, 4400, 4402, 4403, 4413, 4415, 4446, 4496
LAUSON	5802, 5855
LAZER	4541

LEADER	4338
LEGEND	0627, 0656, 0697, 0774, 0785, 4231, 4273, 4315, 4329, 4386, 4392, 4399, 4488, 4562, 4563, 5340, 5343, 5347, 5364, 5945
LEICO	4564
LEIKO	4367, 4546, 05354
LEMON	4320, 4541
LENCO	0621, 0672, 4247, 4415, 4564, 4565
LENG	4496
LENNOX	0608
LENOIR	4242, 5349, 5353
LENSON	4321, 4367
LEYCO	4251
LEXUS	0703, 4127, 4584

LG	4247, 5427, 5443, 5496
LIBERTY	5052
LIFE	5475
LINE@TECH	5930, 6129, 6146, 6147
LINQ	5939
LJOY	5373, 5378, 5470, 5480, 5559, 5947
LOGIK	4438, 5307
LODOS	4438
LORENZEN	0752, 0771, 4137, 4288, 4320, 4413, 4322, 4442, 4500, 4541, 5382, 5408, 5489
LOVE (ELBE)	4237
LTV (OCEANIC)	0706, 0768, 0785, 4341, 4506
LUPUS (ANKARO)	0608, 0629, 4446, 4460

LUXOR	0672, 0706, 0768, 4340, 4341
LUXORIT	4135
LYONNAISE CABLE	4582, 5351
LYOTRON (LG)	4247
MACAB	0785, 4160, 4173, 4210, 4403, 4406, 4496, 4567, 4582, 5343
MAESTRO	0735, 0745, 4321, 4399, 4572
MAGAVOX (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
MAGELLAN	4540
MAGIC SAT	4530
MAGIKE	4174, 4351
MAGNEX	0697

MAGSAT	4384
MAJESTIC	4237, 4297, 5324, 5326, 5327, 5466, 5477, 5478, 5479, 5485, 5491, 5600, 5801, 5854, 6146
MANATA	4149, 4338, 4431, 4508, 4533
MANHATTAN	0630, 0664, 0684, 0697, 0718, 0721, 0796, 0798, 0919, 4157, 4166, 4195, 4210, 4251, 4303, 4318, 4403, 4414, 4496, 4506, 5360
MARANN	4210, 4403, 4496
MALIGNE TV	6285, 6290
MARANTZ	0703
MASCOM	0684
MASPRO	0625, 0697, 0725, 4394
MASTER SAT	4211

MASTERS	0621, 0739, 4333, 4526
MATAV	4361
MATSUI	0703, 0749, 4127, 4251, 4438, 4564, 4584, 4591, 5307
MAXDOME	6294
MAXIMUM	5324, 5382
MAXTRONIC	4196
MCMICHEAL (PHILIPS)	0630, 0694, 0733, 0749, 0771, 0785, 0414, 2345, 4257, 43094422, 4465, 4545, 4553, 4589
MEDIABOX	0785
MEDIACOM	4450, 5315, 5327, 5358, 5383, 5431, 5485, 5814, 5878, 6149
MEDIAMARKT	4413
MEDIAMASTER	0739

MEDIAPRICE	5009, 5045, 5046, 5048, 5054, 5324, 5363, 5855, 5856
MEDIASAT	0739, 0785
MEDIASET	0785, 0917, 5304, 5332, 5333, 5482, 5555
MEDION	4318, 4565, 5359, 5408
MEGASAT	0703, 4127, 4584, 5376
MEGHA	0703
MELECTRONIC	0147, 0431, 4340
MELITA	4487
MEMPHIS	4249

METRONIC	0621, 0684, 0697, 0750, 0919, 4141, 4182, 4214, 4239, 4311, 4333, 4335, 4336, 4338, 4465, 4507, 4508, 4527, 4529, 5000, 5001, 5002, 5003, 5004, 5005, 5008, 5009, 5010, 5011, 5012, 5014, 5015, 5016, 5017, 5018, 5019, 5020, 5021, 5024, 5027, 5028, 5029, 5030, 5031, 5032, 5033, 5034, 5040, 5041, 5042, 5043, 5046, 5047, 5048, 5049, 5050, 5051, 5052, 5055, 5056, 5057, 5058, 5059, 5064, 5073, 5074, 5075, 5320, 5324, 5326, 5337, 5339, 5340, 5343, 5349, 5353, 5357, 5359, 5360, 5363, 5369, 5375, 5382, 5479, 5848, 5855, 5856, 5945, 5952
METZ	0619, 0625

MG ITEX	5411, 5465
MICROSAT	4318, 4537
MICRONIK	4171
MICROTECHNOG OLIE	0730
MIKRO DIGITAL	0752
MINERVA (GRUNDIG)	0619, 0630, 0741, 0749, 0772, 0785, 4389, 4564, 4592, 4593
MIRASAT	4295, 5357
MITSUBISHI	0378, 0619, 0630, 0660, 0694, 0919, 4438, 4507, 4584
MOLGAR	0703, 4127, 4584
MONTEREY	0735, 0745, 4321, 4399, 4572
MORGANS	4149, 4153, 4365, 4413, 4415, 4418, 4446, 4508, 4533
MOSER	0619

MOTOROLA	4305
MP MAN	5316, 5383, 5471, 5475
MULTICHOICE	0630, 0772, 0917, 4357, 5332, 5333
MULTISTAR	0741, 4361, 4394, 4400
MURATO	4481
MURPHY	4452
MVISION	4198, 4590, 5488, 5931, 5932
MWC	0619
MY SAT	0697
MY SKY	5300
MY SKY HD	5301
NAGRAVISION	5342, 5345, 5371
MAONIS (SELECO)	0414, 0621, 0697, 0774, 4569

NASSA NAGEL (ENGEL)	0621, 0785, 4237, 4291, 4292, 4293, 4295, 4297, 4299, 4365, 4367
NAVEX	4210, 4403, 4496
NEAHAUSAT	0697
NEC	4483
NEOM	5320, 5324, 5363
NEOM NM400HD	5070
NEOSAT	6145
NEOTION	4541, 4550
NETA	4253, 4309, 4553
NET BOX HD	5060
NETWORK	0694
NEUF TELECOM	4180, 6289, 6293
NEUF TV	6289, 6293
NEUHAUS	4193
NEUSAT	0697, 4210, 4318, 4403, 4496, 5348

NEVELING	4394, 4450, 4564
NEVIR	4199
NEWSTAR	5357
NEW WAVE	0750, 4239, 4324, 4573
NEWTON	0676, 4112, 4386
NEXPRO	5944
NEXT WAVE	0750, 4123, 4323, 4351, 4319, 4352, 4512, 4528, 4573, 4569
NICAMAGIC (FORMENTI)	0608
NIKKEI	5320, 5321
NIKKO	4212, 4402
NIMO	4280
NINBUS	0666
NODA	4529, 5029, 5032, 5033

NOGAMATIC (THOMSON)	0051, 0630, 0694, 0697, 0732, 0735, 0917, 1445, 4452, 4559, 4582
NOKIA	0383, 0630, 0672, 0706, 0739, 0748, 0768, 0785, 4149, 4275, 4302, 4332, 4338, 4340, 4508, 4533, 4555
NOOS	0732, 4582, 5343, 6283, 6285, 6286, 6292
NORDMENDE	0621, 0684, 4198, 4242, 4418, 4450, 4452, 4544, 4575, 5349, 5359, 5415, 5486, 5492, 5813, 5819, 5823, 5832, 5833, 5864, 5871, 6188, 6203
NORDTON (SELECO)	0414, 0621, 0697, 0774, 4569
NORKABEL	0672, 4487
NOT ONLY	5411

NOT ONLY TV	5325, 5411, 5412, 5478, 5926, 6140, 6146
NOVA	0751, 0772
NOVATRONIC	0629
NOVIS	4210, 4403, 4496
NPG	6131
NTC	0629, 0718
NTECH	5930, 6193
NUMERI CABLE	0785, 4582, 5351
OCEANIC	0672, 0706, 0785, 0768, 4341, 4406, 4506, 5489
OCTAGON	0621
OCTAL	0752, 5343
OCTAN (PHIKIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589

ODEON (AGASHI)	4413
OFFEL	6629, 0796
OKANO	4361, 4413
OLYMPUS	0697, 4399
OLYMPIC	0608, 0629, 4460
OLYMPUS	0697, 4399
ON DIGITAL	0769, 4306, 4589
ONDIAL	4508
OPENTEL	4314
OPENBOX	5346, 5360, 5951, 6143

OPTEX	0664, 0697, 0745, 4148, 4210, 4295, 4296, 4234, 4317, 4318, 4319, 4320, 4322, 4323, 4330, 4321, 4327, 4335, 4338, 4367, 4384, 4399, 4403, 4475, 4496, 4507, 4550, 4573, 5340, 5347, 5354, 5357, 5358, 5359, 5364, 5501, 5503, 5504, 5505, 5506, 5507, 5508, 5509, 5510, 5511, 5512, 5513, 5514, 5515, 5516, 5517, 5518, 5519, 5522, 5523, 5526, 5527, 5528, 5529, 5531, 5532, 5533, 5534, 5535, 5536, 5538, 5541, 5945, 6030, 6031, 6032, 6047
OPTEX TINTSAT	5069
OPTEX / BALMET	5525
OPTEX / STYX	5542
OPTIBOX	5951, 6137

OPTIMA	4198, 4237, 4506, 4569, 5331, 5340, 5484, 5489, 5601, 5943, 5944, 5946, 5951, 6147;0718
OPTUS (AU)	4492
ORANGE	4181, 6285, 6290, 6292
ORAVA	0703, 0771
ORBISAT	0697
ORBIT	0697, 4439, 4481, 4564
ORBITECH	0621, 0697, 0741, 4214, 4218, 4408, 4465
ORDA	4323
ORIGO	4448
OSAT	4459

OTHER	5006, 5007, 5035, 5036, 5037, 5038, 5044, 5046, 5053, 5060, 5061, 5062, 5069, 5070, 5072
OTTO VERSAND	0619, 4408
OURALIS EV 2	5018
OXFORD	4251
PACE	0630, 0694, 0725, 0733, 0745, 0769, 0785, 4133, 4274, 4358, 4412, 4414, 4554, 5340, 5347, 5364
PACIFIC	4406, 4540, 4573
PALCOM	4399, 4524, 4546, 4550, 5404
PALLADIUM	0621
PALSAT	0741, 4392, 4399, 4440, 4564
PANASAT	0772, 4562, 5339, 5343

PANASONIC	0733, 0769, 4562, 4574, 5339, 5343
PANDA	0660, 0672, 4318, 4396
PATH MARCONI (THOMSON)	0051, 0630, 0697, 0694, 0732, 0735, 0917, 1445, 4452, 4559, 4582
PATRICK	5465
PATRIOT	4140, 4149, 4251, 4508, 4533
PEARL	6002, 6003, 6004, 6005, 6006, 6007, 6008, 6010, 6014, 6015, 6016, 6023, 6024, 6025, 6026, 6027, 6029
PEEKTON	5927, 5929

PHILIPS	0414, 0629, 0630, 0694, 0697, 0703, 0733, 0749, 0771, 0785, 2345, 4141, 4161, 4127, 4214, 4257, 4309, 4333, 4365, 4422, 4465, 4545, 4553, 4565, 4584, 4589, 5303, 5305, 5338, 5361, 5402, 5418, 5809, 5950
PHILIPS (F) (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
PHOENIX	0694, 4413, 4448
PHONOLA (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
PHONOTREND	0929, 0664, 0718, 0751, 0797, 4173, 4189

PIONEER	0043, 0464, 0785, 0918, 5817, 5820
PIXX	4148, 4547
PK SAT (HIRSCHMANN)	0608, 0619, 0674, 4131, 4288, 4314, 4422, 4423, 4440, 4445, 4526, 4538, 4555
PLANET	4448, 5304
PLAYER	5055
PLUG IN	5040
PLUG IN 2	5057
PMB	0697, 0917, 4137, 4294, 4327, 4328, 4366, 4546, 5333, 5340, 5347, 5349, 5353, 5354, 5945
POLARIS	0676, 4142, 4386
POLLIN	5408
POLSAT	0752

POLYTRON (KATHREIN)	0625, 4240, 4295, 4351, 4361, 4384, 4394, 4423, 4434, 4445, 4456, 4465, 4545
PORTLAND	4585
POWER SKY	0919, 5360
PREDKI	4414, 4210, 4403, 4496
PREISNER	0676, 4142, 4149, 4193, 4386, 4446, 4508, 4533
PREMIER	0629, 0718, 0768, 4257
PREMIER 2	5041
PROBASIC	4280, 5337, 5356, 5374, 5435, 5802
PROCYON (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
PRODX	4169

PROFILINE	5359
PROMAX (PACE)	0630, 0694, 0733, 0745, 0769, 0785, 4133, 4274, 4347, 4358, 4412, 4414, 4448, 4554
PROSAT	0629, 0908, 4399, 4452, 4541
PROTEC	4406
PROTECH	4406, 4433, 5348
PROTEK	4239, 4317, 4406, 4426, 5348
PROVISAT	4223, 4433
PROVISION	0684, 0743, 0778, 0796
PYE (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
PYXIS	4318, 4324

QUADRAL	0621, 0629, 4193, 4450
QUADRO	4573, 5356, 5359
QUALI-TV	4200
QUENNFIDELITY (DAEWOO)	0621, 0697, 0748, 4348, 4585
QUELLE	0619, 0660, 4361, 4415
QUIERO TV	4582
QVISION	4590
RADIOLA (PHILIPS)	0414, 0630, 0694, 0749, 0733, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4545, 4553, 4589
RADIX	0676, 4142, 4384, 4386, 4529, 4564, 4573

RAINBOW (PACE)	0630, 0694, 0725, 0733, 0745, 0769, 0785, 4133, 4274, 4339, 4347, 4358, 4412, 4414, 4448, 4554
RCS	4278
RE	0664
REBOX	4511, 5340, 5945
REC	4484
REDBELL	5314
RED STAR	0608
REDO	4338
RENDER	5415, 5485
REX (SELECO)	0414, 0621, 0697, 0774, 4569
RFT (BRUNS)	0629, 0672, 0697, 4318, 4437, 4460, 4573

RITAR	0672, 0697, 4242, 4402, 5349, 5353, 5445
ROADSTAR	0697, 0730, 0785, 0919, 4327, 5340, 5347, 5359, 5360, 5364, 5945
ROCH	4338
ROMSAT	0621
RT850S:ORT8800	5308
ROVER	4367
RUEFACH (LENCO)	0621, 4564, 4565
SAB	4571, 5346
SABA	0630, 0672, 0684, 0694, 0718, 4141, 4161, 4204, 4223, 4415, 4433, 4452, 4489
SABC	4360

SABRE (PACE)	0630, 0694, 0733, 0745, 0769, 0785, 4133, 4274, 4347, 4358, 4412, 4414, 4448, 4554
SAGEM	0758, 4160, 4184, 4257, 4354, 4457, 4519, 4520, 4521, 4582, 5339, 5343, 5351, 5369, 5372, 5375, 5376, 5942, 6283, 6285, 6288
SAGEMCOM	5942, 6193
SAGEM TNSAT	5601
SAITO (OCEANIC)	0706, 0785, 4341, 4506
SAIVOD	4237, 5309, 5324
SAKURA	4448
SALORA	0672, 4340, 4341
SAMSAT	4314, 6155

SAMSUNG	0646, 0733, 0797, 4146, 4225, 4226, 4227, 4266, 4267, 4291, 4292, 4322, 4328, 4361, 4418, 4422, 4467, 4512, 4528, 5339, 5343, 5344, 5349, 5353, 5403, 5419, 5472, 5807, 5808, 6284
SANDOR (OCEANIC)	0706, 0785, 4341, 4506
SANSUI	5559, 5606, 6148
SANWA (SANYO)	4367
SANYO	4367, 5359
SAT	4388, 4481
SAT FORD	4484
SAT ITALIA (WISI)	0619, 0679, 0741, 4129, 4163, 4208, 4386, 4428, 4429, 4439, 4454, 4458, 4482, 4489, 4566, 4567, 4568
SAT MASTER	4190, 4460, 4484

SAT PARTNER	0703, 4127, 4247, 4403, 4496, 4584
SAT PLUS	4254, 4327, 4329, 4546, 4550
SAT+	0774, 4327, 4329, 4367, 4506, 4546, 4550, 5340, 5347, 5359, 5364, 5489, 5945
SATCOM	0621, 4484
SATEC	0694, 4484
SATECO	0621, 0664, 4565
SATELLITE	4440
SAT-URNE	5357
SBR (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4465, 4553, 4545, 4589
SCHAUB LORENZ	0672, 0697, 0768, 4220, 4237, 4329, 4341, 4511, 4575

SCHNEIDER	0674, 0697, 0703, 4127, 4327, 4333, 4365, 4413, 4454, 4482, 4514, 4565, 4584
SCHNEIDER (F) (PHILIPS)	0414, 0630, 0694, 0733, 0749, 0771, 0785, 2345, 4257, 4309, 4422, 4545, 4589, 4553, 4465
SCHWAIGER	0694, 0797, 0919, 4141, 4161, 4148, 4166, 4189, 4193, 4218, 4234, 4258, 4260, 4261, 4262, 4263, 4264, 4290, 4296, 4303, 4314, 4352, 4365, 4384, 4438, 4509, 4514, 4529, 4541, 4547, 4565, 4581, 5100, 5101, 5102, 5103, 5104, 5105, 5106, 5107, 5108, 5109, 5110, 5111, 5408, 6048, 6049, 6050, 6051, 6272, 6214, 6260, 6273, 6274, 6275, 6276

SCOTLAND (PORMENTI)	0608
SCOTT	0778
SEARS (SANYO)	4367
SECTOR	4460
SEDEA	0621, 0674, 0800, 0919, 4140, 4149, 4166, 4170, 4263, 4323, 4450, 4508, 4527, 4533, 4535, 4536, 4573
SEELTECH	5309
SEEMAN	4386, 4413, 4491, 0676, 4142, 4386, 4251, 4413
SEG	0608, 0621, 0730, 4280, 4367, 4403, 4496, 4550, 4565, 5337, 0697, 4138, 5408, 5347, 5356, 5359, 5364, 5479, 5945

SEIGA (MITSUBISHI)	0619
SENYU	0674, 4589
SELECO	0414, 0621, 0697, 0774, 4569, 5359
SEPTIMO	4141, 4161, 4336, 4527, 4540, 5014, 5017, 5018, 5021
SERVIMAT	0697, 4327, 4546, 4575, 5340, 5347, 5349, 5353, 5354, 5364, 5404, 5479, 5945
SERVISAT	4415, 4338, 4367, 4550
SET ONE	5340, 5411, 5412, 5413, 5465, 5484, 5557, 5945, 6200
SHADOW	5362
SHARK	5346, 5432, 5455
SHOP+	5930

SHINELCO	5320, 5324, 5325, 5327, 5331, 5365, 5370, 5383, 5388, 5400, 5410, 5485, 5606, 5801
SICANTIC (LUXOR)	0672, 0706, 0768, 4340, 4341
SIGMATEK	6151
SIEMENS	0619, 4188, 4431, 4491, 4505, 4541, 5330
SILVERCREST	4202, 4595, 5359
SILVA	4247
SINGLE	5032
SINGLE 4.3	5074
SKANTIC (LUXOR)	0672, 0706, 0768, 4340, 4341
SKR	0697
SKT	4138, 5408
SKY	5302

SKY BIRO	0664, 0666
SKY BOX	6143
SKY BARSIL	4356, 4383
SKY ENGLAND	4308
SKY HD	5306
SKY IRELAND	4308
SKY LINE	0634
SKY MASTER	0629, 0697, 0731, 4204, 4327, 4337, 4352, 4518, 4541, 4526, 4550, 4565, 4518, 5945
SKY NEW ZELAND	4326, 4344, 4345, 4560
SKY PLUS	4322, 4550, 5945
SKY+	5390
SKYMASTER	0697, 4204, 4327, 4352, 4518, 4526, 4541, 4565, 5340, 5347, 5354, 5364

SKYMAX	0703
SKYVISION (HUTH)	0629, 4149, 4153, 4169, 4193, 4204, 4232, 4413, 4460
SL	4140, 4149, 4508, 4533
SM ELECTRONICS	0697, 4329, 5347, 5945
SMART	4140, 4149, 4215, 4295, 4314, 4365, 4508, 4533, 4538, 4550, 5056, 5340, 5347, 5357, 5604
SOLARIS	0724, 4196, 4507, 5350
SONORO (AGASHI)	4413
SONSTIGE	4320
SONY	0733, 0785, 4587
SONYSAT	5348
SPORTGENEXXA (FORMENTI)	0608

SR	4413
SRT5119+ SYSTEC	5036
SSANGYONG (SAMSUNG)	0646, 0733, 0797, 4146, 4225, 4226, 4227, 4267, 4291, 4292, 4322, 4328, 4361, 4422, 4418, 4467, 4512
STAB	0656
STABO	4234
STAR	5383, 5470, 5475
STAR DIJITAL	5339, 5343
STAR TRACK	0728, 0919, 4166
STARBOX	5358
STARCOM	4321, 4338, 5502, 5519, 5533, 5537, 5540, 5541
STARK	4296
STARRING	4210

STARLAND	0697, 4179, 4328, 4366, 4525, 4509
STARSAT	0697, 0919, 4270, 4301, 5358, 5360, 5805
STASSFURT (BRUNS)	0697, 4437, 4460
STELLA (CONNEXIONS SAT)	4386
STERN (SELECO)	0414, 0621, 0697, 0774, 4569
STREAM	0733, 0774

STRONG	0621, 0634, 0674, 0683, 0684, 0724, 0743, 0778, 0785, 0796, 0800, 0917, 4196, 4279, 4327, 4329, 4336, 4339, 4347, 4351, 4356, 4367, 4399, 4413, 4438, 4450, 4455, 4481, 4494, 4503, 4506, 4513, 4536, 4550, 4564, 5304, 5307, 5324, 5332, 5333, 5340, 5347, 5351, 5358, 5359, 5363, 5364, 5377, 5385, 5404, 5467, 5489, 5804, 5852, 5935, 5945
STRONG TINTSAT	5062
STVI	0785, 4338
STYX	4324, 4573, 5526, 5543
SUCCESS	4317
SUNKAI	4336
SUNMOONSTAR	0772, 0917, 5332, 5333

SUNNY	4303
SUNSTAR	0608, 4140, 4149, 4361, 4508, 4533
SUNSTECH	4237, 4298, 5309, 5324, 5327, 5363, 5478, 5485, 5491, 5854, 5946
SUPERJACK	4272
SYNCRO	4352
SYSTEC	4403, 4140, 4149, 4210, 4496, 4541, 4508, 4533, 4543, 4595
SYTEC SAT	4210
SYVO	0629
T HOME	6295
T LOGIC	5316
TAEYOUNG	0621, 0684
TAGASHI	4413
TAHNON	4529, 5029, 5032

TANTEC	4399
TATUNG	0619
TBOSTON	4237, 4296, 4297, 4362, 5357, 5358, 5377, 5479, 5854
TEAC / TEAK	0908, 5337, 6156
TECHNEMA (FORMENTI)	0608
TECHNIBOX	0771
TECHNICAL	4367
TECHNIKA	4220
TECHNISAT	0676, 0703, 0741, 0797, 1343, 4127, 4142, 4189, 4214, 4218, 4386, 4408, 4422, 4440, 4465, 4500, 4561, 4565, 4584
TECHNOSAT	0664, 0666, 4352, 4537
TECHNOSONIC	4220
TECHNOWELT	4141, 4161

TECHONMATE	4254, 4314
TECHWOOD	0703, 4127, 4438, 4367, 4584, 5359
TECO (AMSTRAD)	0647, 0656, 0660, 0733, 4413, 4149, 4150, 4300, 4305, 4329, 4367, 4388, 4396, 4418, 4564
TECSAT	0697
TECSOFT	5485
TELE+	0785
TELE 2BOX	6289
TELEAVIA (THOMSON)	0051, 0630, 0697, 0694, 0732, 0735, 0917, 1445, 4452, 4559, 4582
TELECIEL	4331, 4559
TELECO	0771, 0917, 4356, 4530, 5331, 5332, 5333, 5602
TELECOM	0664, 0666, 5937, 5938

TELEFUNKEN	0621, 4452
TELEKA	0676, 0718, 4142, 4318, 4339, 4361, 4386, 4413, 4418, 4423, 4439, 5340, 5347
TELEMASTER	0684, 0796
TELEMANN	4148
TELEMAX	0796, 4402
TELESERVICE	0785
TELESTAR	4214, 4465, 4541, 4550, 4565

TELESYSTEM	0674, 0731, 0785, 4327, 4329, 4367, 4381, 4546, 4550, 4565, 5310, 5311, 5318, 5340, 5347, 5352, 5354, 5355, 5359, 5364, 5366, 5381, 5384, 5400, 5401, 5404, 5408, 5435, 5482, 5489, 5555, 5556, 5560, 5561, 5562, 5563, 5603, 5812, 5930, 5941, 5945, 5953, 6129, 6136, 6138, 6144
TELETECH	0731
TELEVES	4134, 4148, 4149, 4153, 4223, 4508, 4511, 4533, 4541, 4543, 4573, 4595, 5425, 5430, 5470, 5881, 5889, 6154
TELEWIRE	0664, 0666, 4314, 4494, 4516, 4525, 4526, 5485, 6141, 6156

TELSEY	5435, 5485, 5555, 5854, 6142
TELKOM	4367, 5945
TEMAL	0697, 0703
TERMINAL NUMERIQUE	4294
TETHYS	5357
TEVION	4327, 4581, 5340, 5347, 5945
THES	5433, 5434, 5437, 5476, 5952
THOMSON	0051, 0630, 0694, 0697, 0732, 0735, 0785, 0917, 1445, 4141, 4161, 4452, 4415, 4356, 4559, 4582, 5332, 5333, 5339, 5343, 5351, 5368, 5930, 5935, 6286, 6290
THORENS	4426, 4406, 4452

THORN	0378, 0630, 0694, 0619, 0660, 0919, 4438, 4507, 4584, 5307
THORN FERGUSON	0660, 0672, 0703, 4127, 4394, 4396, 4584
THUNDERMAX	0624, 0676, 0703, 0706, 0785, 4127, 4142, 4211, 4386, 4399, 4504, 4534, 4584
TIVU BOX	4197, 5329, 5371
TM	4280
TMELECTRON	6131
TMX	0624, 0785, 4322, 4504, 4534
TOKAI	0703, 4127, 4584
TOKO (KATHREIN)	4545, 0619, 0625, 0771, 4238, 4240, 4242, 4295, 4351, 4361, 4384, 4394, 4423, 4434, 4445, 4465, 4456

TONBURY	4532, 4573
TONEBURST	4141, 4161
TONNA	0703, 4127, 4141, 4161, 4525, 4584, 4550
TONNA ELECTR.	0664, 0697, 4323, 4522
TONNA ELECTRONICS	5354
TOPFIELD	4301, 4322, 4442, 5341, 5382, 5524
TOPSAT	5358
TORRE (THOMSON)	0051, 0630, 0694, 0697, 0732, 0732, 0735, 0785, 0917, 1445, 4452, 4559, 4582
TOSHIBA	0630, 4306, 5488
TOUCHBOX	5028
TOUCHBOX 2	5030

TPS	4354, 4457, 4531, 5339, 5343, 6285, 6289, 6290
TPS / 441630	5007
TREVI	4237, 5324, 5327, 5363, 5374, 5388, 5470, 5485, 5600, 5854, 5878, 5879, 5880, 5881, 5882, 5889, 5946
TRIAD	0697, 4208, 4247, 4439, 4481
TRIASAT (WISI)	0619, 0697, 0741, 4129, 4163, 4208, 4386, 4428, 4429, 4454, 4458, 4567, 4482, 4489, 4566, 4568
TRIAX	0676, 0741, 4122, 4214, 4123, 4142, 4149, 4164, 4301, 4367, 4386, 4440, 4508, 4529, 4533, 4539, 4585, 5349, 5353, 5357, 5359, 5955, 5956, 6191
TRICAL	0184

TRIDENT	5358
TV CABO	0752, 4196
TV HOME	4500, 5369
TWINNER	0697, 0751, 4149, 4173, 4338, 4508, 4533, 4541, 4546
TWINSAT	0735, 0745, 4321, 4399, 4572
ULTIMATEBOX	5049
ULTRAVOX	0664, 0666, 0797
UNIDEN	4318, 4392, 4470
UNITED	5308, 5309, 5325, 5326, 5359, 5365, 5370, 5383, 5422, 5454, 5466, 5556, 5854, 5940, 5954
UNITOR	4210, 4403, 4496
UNIVERS	4342
UNIVERSUM	5408

UNIVERSUM (QUELLE)	0619, 0660, 4361, 4415, 4564
UNIXBOX	6135
UPC	6283, 6285, 6286
UTEK	5373
VARIOSAT (WISI)	0619, 0697, 0741, 4129, 4163, 4208, 4386, 4428, 4429, 4454, 4458, 4482, 4567, 4489, 4566, 4568
VENTANA	0703
VERSATEL	6284
VESTEL	4280, 4367, 5337, 5356, 5359
VETA	4253
VIA	0732, 0791, 4582
VIDEO LINK	4473
VIDEOTON	5359
VISA ELECTR:	0198

VISIONIC	0728, 0800, 0919, 4166, 4168, 4170, 4263, 4323, 4450, 4507, 4527, 4533, 4536, 4573, 4595
VISIONNET	4590
VISIONPLUS	0734
VISIOSPACE	0703, 4127, 4584
VISIOSAT	0664, 0697, 0800, 4142, 4148, 4149, 4210, 4295, 4296, 4321, 4334, 4403, 4414, 4489, 4496, 4509, 4525, 4547, 4595, 5357, 5358
VISTA (THORN)	0378, 0619, 0630, 0660, 0919, 0694, 4438, 4507, 4584
VORTEC	0621, 0697, 0797, 4418, 4422, 4538, 4539
VTECH	0697, 4247, 4333, 4439, 4454, 4482, 4489

WEGENER	4415
WELA	4193
WELKIN	0414
WESTWOOD	5359
WINBOX	4329, 5340, 5347, 5364, 5377, 5603, 5945
WINDSOR	5359
WINDSTAR (THORN)	0378, 0630, 0619, 0660, 0694, 0919, 4438, 4507, 4584
WINERSAT	4414, 4210, 4403, 4469
WINNER	4223, 4433, 4339, 4472
WINTERNITZ	0660, 4396

WISI	0619, 0676, 0697, 0741, 4129, 4142, 4163, 4193, 4208, 4386, 4415, 4428, 4429, 4439, 4454, 4458, 4482, 4489, 4566, 4568, 4567, 5408
WISIORBIT	4193
WITTENBERG	0694, 4388
WIZZ	4229
WOORISAT	0684
WORLDSAT	0735, 0745, 0751, 0917, 4141, 4137, 4149, 4161, 4173, 4247, 4251, 4294, 4356, 4367, 4399, 4508, 4533, 4572, 5332, 5333, 5368
WOXTER	4300, 4237, 5337, 5363
XCOM	0745, 0794
XORO	5356

XSAT	0745, 0794, 4141, 4161
XTREME	4303
YAMADA	5324, 5363
YEOMAN	5383, 5389
YES	4326
YUMATU	4569, 5489
ZANUSSI (SELECO)	0414, 0621, 0697, 0774, 4569
ZAPMASTER	5408
ZAPP	5346, 5349, 5350, 5353, 5358, 5359, 5376, 5382, 5383, 5461
ZAPPER	5802

ZEHNDER	0608, 0684, 4148, 4210, 4295, 4314, 4321, 4322, 4329, 4361, 4367, 4381, 4384, 4403, 4415, 4434, 4454, 4496, 4541, 4528, 4545, 5357, 5359, 6156
ZEM	5350, 5357, 5358, 5360, 5382, 5461, 5489
ZEPHIR	5383
ZINWELL	4515
ZODIAC	4550, 0621, 0676, 0731, 0919, 4165, 4166, 4223, 4295, 4310, 4318, 4327, 4329, 4433, 4339, 4381, 4460, 4472, 4550, 4558, 5340, 5346, 5347, 5357, 5358, 5360, 5362, 5364, 5365, 5370, 5373, 5374, 5376, 5378, 5383, 5386, 5470, 5482, 5603, 5802, 5811, 5862, 5889, 5945

ZOTA	0703, 4127, 4584
ZWERNASE	4413