



EJEAS

Bluetooth Intercom

V6-1200 User Manual





key function

1, Volume- 2, power on/pair A(functional key) 3, E Key
 4, The antenna 5, D key 6, Headset interface/ USB charger interface
 7, Volume+ 8, Phone key(receive calls, pair phone) 9, C key
 10, B key 11, power off

V6 is Stable performance of motorcycle bluetooth intercom , maximum talking distance is 1200 meters , in general , at outdoor environment the talking distance is 300 meters to 800 meters, at same time it is also as high performance bluetooth headset (range of 15meters).

It has functions of automatic- receive phone calls, using more convenient and safe. Surely, using newest production process and ultrasonic structure without screw. Also it has functions of 5 levels waterproof, HD-Voice. Professional designing for motorcycle riders and making sure safely riding.

The installation diagram



1. unscrew the clip's screw



2. set clip on side of helmet, tighten saable screw



3. inset the headset



4. set intercom on clip



5. put the velviro glue on the both side of the helmet



6. adjust microphone site, install completely

Clip of Installed

install clip at side of helmet

Put V6 device with clip

Completely install-ation

connect headset.

Operation manual :

Operation of phone:

1. Power on/power off

Power on :long press Key  about 2seconds then release,main device light flash,power on completely

Power off :Press fast power off-key at state of power on

2. Connect with phone (GPS/MP3) :

At power on state ,long press phone key 6 seconds until red&blue light flash then release ,turn on phone bluetooth and search bluetooth to connect V6 Remote, pairing

successfully,intercom' s blue light flash. (If GPS/MP3 support bluetooth function ,same operation way with phone)

3. Last number redial :

After connecting phone , long press Phone key 3 seconds, device will automatic dial phone of the final phone calling number.

4. receiving a call

When comes a call ,without operation 5 seconds ,phones will automatic receive

5. Refuse a call

When comes a call , press phone key to end call

6. Play/suspended music

Short press phone key ,(95% compatible with cell phone music play)

7. volume control

Add volume ,press volume +

Down volume ,press volume -

8. choose music

On the previous song, long press [volume +] for 2 seconds, next song, long press [volume -] for 2 seconds

9. charging tip

When it is charging ,red light steady,full charged ,red light will put out


二、 bluetooth intercom operation :

V6 support one main device pair with 5 devices, six riders use device together. The Main device can choose one to full duplex talk from A,B,C,D,E devices (Attention: The main device can not talk with other 5 devices at same time, it is main device which choose one to talk each other (choose from A,B,C,D,E,press main device's A,B,C,D,E key to switch and talk with each other, realize two riders talking)

1. Pairing with A group

Long press main device and A device's A(motor) key about 5 seconds together, then both device red & blue lights flash then release, press main device A(motor) key, then searching and pairing, two devices blue light flash together, two device pair successfully, but cannot talk because pairing records don't keep press main device or A device A(motor)key again, at time two device blue light is same with flash rhythm. Then two devices can normal talk and power off, pairing.

records will be kept automatically.



4

2. Pairing with B group

The main device power on until light flash, then release, press the main device's B key about 5 seconds, red & blue light flash then release, long press B device and power on until red & blue light flash then release, press the main device's B key again, at time two device pairs and two devices red light put out, blue light flash. After pairing successfully, press the main device's B key, then two devices can normal talk and power off, pairing records will be kept automatically.

3. Pairing with C group

The main device power on until light flash, then release, press the main device's C key about 5 seconds, red & blue light flash then release, long press C device and power on until red & blue light flash then release, press the main device's C key again, at time two device pairs and two devices red light put out blue light flash. After pairing successfully, press the main device's C key, then two devices can normal talk and power off pairing records will be kept automatically.

D group and E group have same pair way as above, pairing relative D and E key, simply saying: the main device key of A,B,C,D,E pair with other five devices' keys of A,B,C,D,E separately, after pairing, press main device keys of A,B,C,D,E separately with other five devices A,B,C,D,E to realize two riders full duplex talk function, but the other five devices of A,B,C,D,E can not talk.

Eg: The main device need talk with A device, press main device A key to connect A device directly and realize two riders full duplex talk function, if main device need talk with B device, press B key to switch and talk with B device, C,D,E exactly

Intercom accessories:



5

Parameters:

Bluetooth version:3.0ip:CSR Bc5
Intercom distance: up to 1200 meters
Bluetooth headset distance : 10 meters
Battery capacity: 850mAh
Battery Type: Polymer
Operating voltage: 3.3V -4.2 V
Talk time:12H
standby time: 450H
Charging time:2.5H
Speaker power:0.12W
Waterproof rating:IP65
Operating temperature range: -30° C to + 60° C
Charger Specifications: USB Charging(5V 0.5 ~ 2A)

Precautions for use:

- 1.please install correctly, under raining situation ,devices jack down, making sure headphone jack to fully inserted state with devices, to prevent the devices into the water.
- 2.in order to ensure the battery life, please use the standard charger.
- 3.in order to ensure the safety of riding,don't recommended to listen to music in the state of riding

4.in the riding state, do not manually operate the host button, pay attention to safety to ensure the communication distance, please try to use in open areas.



Erklärung der Taste:

1. Lautstärke – 2. Anschalten/auf A abstimmen (multifunktional)
3. Taste E 4. Antenne 5. Taste D 6. Schnittstelle des Kopfhörers
7. Lautstärke + 8. Telefontaste (Anruf erhalten, Handys abstimmen)
9. Taste C 10. Taste B 11. schnelle Ausschalten

V6-1200 ist eine stabile Bluetooth-Gegensprechanlage für Motorfahrer. Die maximale Distanz ist um 1200 Meter. Normalerweise wird die Anlage in der Entfernung von 300 bis 800 Meter im Grünen benutzt. Zudem ist V6 eine Hochleistungs-Bluetooth-Gegensprechanlage (in der Entfernung von 15 Meter).

Die Anlage ermöglicht automatische Erhaltung und benutzt aktuelle Technologie. V6-1200 verwendet Ultraschallwellen und nutzt keine Schraube. Die Anlage ist wasserdicht auf 5 Grad, und gibt klare Tonqualität. Die Anlage wird speziell für Motorrad entworfen und **schafft mehr Sicherheit!**

Einbauanweisung:



1. unscrew the clip's screw



2. set clip on side of helmet, tighten screw



3. inset the headset



4. set intercom onclip



5. put the velcro glue on the both side of the helmet



6. adjust microphone site, install completely

Einbauhinweise:

1. Einbauklammer 2. Hauptanlage einbauen
3. MIC Kopfhörer und MIC einbauen 4. Einbau schaffen
5. MIC Kopfhörer und MIC verbinden

Betriebshinweise:

Betrieb mit Handy:

1. Anschalten/Ausschalten: Anschalten: auf Schalte/Taste A für 2 Sekunde drücken. Leuchtet Mainframeanzeige steht Anschalten. Ausschalten: Im Betrieb, auf schnelle Ausschaltentaste drücken.

2. Mit Handy (GPS/MP3) verbinden: Im Betrieb auf Telefontaste für 6 Sekunde drücken bis das Wechselleuchten des Rotes und Blauen. Bluetooth ausschalten und Bluetooth-Kopfhörer reattachieren. V6 finden und auf Verbinden klicken. Nach der erfolgreichen Verbindung glimmt das blaue Anzeige. (Wenn GPS/MP3 Bluetooth unterstützt, braucht es die gleiche Schritte.)

3. Letzter Nummer wiederwählen; Nach der erfolgreichen Verbindung drücken auf Telefontaste für 3 Sekunde und wird es das letzte Nummer wiederwählen.


4. Musik spielen und aussetzen: auf Telefontaste kurz drücken (95% Handy-Musik sind kompatibel)

5. Lautstärke stellen; Um die Lautstärke lauter zu stellen, auf Lautstärke + drücken Um die Lautstärke leiser zu stellen, auf Lautstärke - drücken
6. Musik auswählen; Um die letzte Musik zu spielen, auf Lautstärke + für 2 Sekunde drücken Um die nächste Musik zu spielen, auf Lautstärke - für 2 Sekunde drücken

二、Betrieb für Gegensprechen

V6 unterstützt 1 Hauptanlage für 5 Kindanlage. Durch der Sprechen zwischen die Hauptanlage und 5 Kindanlage zu gleicher Zeit ist nicht möglich.

Auf Taste A, B, C, D und E drücken, um mit der entsprechenden Kindanlage zu sprechen.)



10

1. Verbindung der Gruppe A Auf Anschalt der Hauptanlage und Taste A zu gleicher Zeit drücken (für 5 Sekunde) bis das rote und blaue Anzeige glimmern. Auf Taste A der Hauptanlage drücken, um die Verbindung zu beginnen.

Wenn nur das blaue Anzeige glimmert schafft die Verbindung. Falls Gegensprechen ist nicht erreichbar und das Protokoll der Verbindung ist nicht speichert, auf der Hauptanlage oder Taste A noch einmal drücken.

Hauptanlage kann es mit A, B, C oder D intersprechen. (Achtung Dann normalerweise werden die blaue Anzeige der zwei Anlage synchronisierend glimmern. Gegensprechen durch A Kindanlage der Hauptanlage ist erreichbar und wird das Protokoll der Verbindung automatisch nach dem Ausschalt speichert.

2. Verbindung der Gruppe B

Auf Schalte der Hauptanlage (bis das Anzeige leucht) und Taste B für 5 Sekunde (bis das rote und blaue Anzeige glimmern) drücken.

Auf Schalte der Kindanlage B (bis die rote und blaue Anzeige leucht) für 5 Sekunde drücken. Auf Taste B drücken noch einmal. Nachdem schafft die Verbindung.

Rote Anzeige der Hauptanlage und Kindanlage B werden nicht leuchten und nur blaue Anzeige glimmert.

Nach der Verbindung auf Taste B der Hauptanlage drücken, um die Gegensprechen zu beginnen. Das Protokoll

11

der Verbindung wird automatisch nach dem Ausschalten gespeichert.

3. Verbindung der Gruppe C

Auf Schalter der Hauptanlage (bis die Anzeige leuchtet) und Taste C für 5 Sekunden (bis die rote und blaue Anzeige glimmen) drücken. Auf Schalter der Kindanlage C (bis die rote und blaue Anzeige leuchtet) für 5 Sekunden drücken.

Auf Taste C drücken noch einmal. Nachdem die Verbindung hergestellt ist, leuchtet die rote Anzeige der Hauptanlage und die Kindanlage C nicht und nur die blaue Anzeige glimmt.

Nach der Verbindung auf Taste C der Hauptanlage drücken, um das Gespräch zu beginnen. Das Protokoll der Verbindung wird automatisch nach dem Ausschalten gespeichert. Die Verbindungswise der Gruppe D und E sind gleich.

Einfach zu sagen, A, B, C, D und E der Hauptanlage entsprechen den Tasten A bis E der Kindanlage. Nach der Verbindung ist das Gespräch durch das Drücken der Tasten A, B, C, D und E erreichbar. Das Gespräch zwischen den Kindanlagen ist nicht möglich.

Zubehörteil:



Spezifikation:

Bluetooth-Version: 3.0
 Chip: CSR BC5
 Distanz des Gesprächs: maximal 1200 Meter
 Distanz der Bluetooth-Kopfhörer: 10 Meter
 Sammlerkapazität: 850 Milliampere
 Typ der Batterie: Polymerisat
 Arbeitsspannung: 3.3V - 4.2 V
 Dauer des Gesprächs: 12 Uhr
 Standby-Dauer: 450 Uhr
 Ladedauer: 2.5 Uhr
 Trompetenleistung: 0.12W
 Wasserdicht-Niveau: IP65
 Arbeitstemperatur: -30°C bis +60°C
 Typ des Ladegeräts: USB (5V 0.5~2A)

GermanAchtung:

1. Bitte richtig einbauen. Wenn es regnet, stellt die Schnittstelle des Kopfhörers nach unten. Die Schnittstelle des Kopfhörers steckt vollständig hinein, um wasserdicht zu sein.
2. Um die Batterie zu schützen, bitte das standardmäßige Ladegerät nutzen.
3. Um die Fahrsicherheit zu garantieren, das Musikhören ist nicht angedeutet.
4. Beim Fahren bitte nicht manuell die Hauptanlage bedienen.
5. Für eine günstige Distanz bitte auf dem Freiland nutzen.