# **User Manual of SKMEI Model #1251**



#### A. Features:

- ◆ 13 Digits, Hour, Minutes, Seconds, Month, Day and Week
- ◆ Daily Alarm , Chime Hourly and Snooze Function
- ♦ 2 / 24H format selectable , Auto Calendar
- ◆ 1/100 second Chronograph with split functions
- ◆ Count Down (Upper limit: 24H)
- ◆ Dual Time
- ◆ EL backlight

## **B. Operational Manual:**



1.At any state, press A key EL backlight for 3s.

#### 2.Real Time:

◆ Time Setting

a)Press and hold C key for 2s to time setting state and "Second" flashing, press D key to zero; Press B key to select item as following sequence:

- b). Press D key to adjust the flashing item,
- c). Press C key to return to Real Time Mode.
- d). Press D key while the seconds are in the range of 30 to 59 resets them to 00 and adds 1 to the minutes . In the range of 00 to 59 resets them to 00 and adds to the minutes. In the range of 00 to 29, the minutes are unchanged.
- e) 12/24-Hour format :In the timekeeping Mode, Use D to toggle between 12-hour (12H) and 24-hour (24H) timekeeping.

## 3. Daily Alarm:

In Real Time Mode, press B key enter into Alarm Mode

- ◆ Press C key to turn on/off Alarm(♠) and Snooze(Snz), In Alarm Mode, press button D, then C to turn on/off (♠) hourly chime
- Alarm setting

Press and hold C key for 2s to select "Hour" setting; Press B key to select "Minute" setting; Press D key to adjust the flashing item.

´Hour ⊂ → Minute

## 4. Chronograph:

In Real Time Mode, press B key twice enter into Chronograph Mode

Press D key to Start/Stop running; When stop, press C key to zero.

• When running ,press C key to split Counting. Then press D key to exit split count ,and stop counting ; When exit split count ,press C key to zero.

#### 5. Dual Time:

◆ Dual Time setting
In Real Time mode, Press B key 3 times to enter Dual Time Mode, Press and hold C key for 2s to select " Hour " setting, Press B key to select " Minute " setting, Press D key to adjust the flashing item, Press C key again to finish setting, and return to Dual Time displaying mode.

#### 6.Timer Mode:

- ◆ In Real Time Mode, press B key four times enter into Timer mode
- ◆ Press D key to Start/Stop countdown
- When stop the countdown, press C key back to the first setting time
- ▶ Timer alarm sounds for about 10s when counting down to 0:00:00. The timer is automatically reset to its starting value after the alarm stops.
- ◆ Press C key 2s enter into countdown time setting
  - a).Press B key to adjust "Hour" and then "Minute"

Hour → Minute

- b).Press D key to adjust the flashing item
- c). Press C key to confirm