User Manual of SKMEI Model #1251



- 13 Digits, Hour, Minutes, Seconds, Month, Day and Week Daily Alarm, Chime Hourly and Snooze Function 2 / 24H format selectable, Auto Calendar 1/100 second Chronograph with split functions Count Down (Upper limit: 24H) Dual Time

- EL backlight

B. Operational Manual:



1.At any state ,press A key EL backlight for 3s .

2.Real Time:

Time Setting
a)Press and hold C key for 2s to time setting state and "Second" flashing, press D key to zero; Press B key to select item as following sequence:

Second → Hour → Minute → Year → Month → Day

b). Press D key to adjust the flashing item, c). Press C key to return to Real Time Mode. d). Press D key while the seconds are in the range of 30 to 59 resets them to 00 and adds 1 to the minutes . In the range of 00 to 59 resets them to 00 and adds to the minutes. In the range of 00 to 29, the minutes are unchanged.
e) 12/24-Hour format: In the timekeeping Mode, Use D to toggle between 12-hour (12H) and 24-hour

(24H) timekeeping.

3. Daily Alarm:

In Real Time Mode, press B key enter into Alarm Mode
Press C key to turn on/off Alarm (4) and Snooze(Snz), In Alarm Mode, press button D, then C to turn on/off () hourly chime

Alarm setting
Press and hold C key for 2s to select "Hour" setting; Press B key to select "Minute" setting; Press D key to adjust the flashing item.

Hour

→ Minute

4.Chronograph:

In Real Time Mode, press B key twice enter into Chronograph Mode
Press D key to Start/Stop running; When stop, press C key to zero.
When running, press C key to split Counting. Then press D key to exit split count, and stop counting; When exit split count, press C key to zero.

5.Dual Time:

Dual Time setting In Real Time mode, Press B key 3 times to enter Dual Time Mode, Press and hold C key for 2s to select " Hour " setting, Press B key to select " Minute " setting, Press D key to adjust the flashing item, Press C key again to finish setting ,and return to Dual Time displaying mode .

6.Timer Mode:

- In Real Time Mode, press B key four times enter into Timer mode
 Press D key to Start/Stop countdown
 When stop the countdown, press C key back to the first setting time
 Timer alarm sounds for about 10s when counting down to 0:00:00.The timer is automatically reset to
 its starting value after the alarm stops.
 Press C key 2s enter into countdown time setting
 a).Press B key to adjust "Hour" and then "Minute"
 Hour → Minute
 b).Press D key to adjust the flashing item

Hour → Minute b).Press D key to adjust the flashing item c).Press C key to confirm