




©2013 Mattel. All Rights Reserved. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Malaysia. Tel:03-78803817, Fax:03-78803867.


APPLY LABELS

Helpful Hint: Apply labels before assembly by number as indicated.












ASSEMBLY





GET READY TO PLAY


- Fill water to top of container for best performance.
- Overfilling of reservoir may cause
- To avoid burns do not use water that is too hot, above 120°F(48°C).
- Water toys sometimes get messy. Protect play surfaces before use.
- For best performance of color change feature, please use icy water under 50°F/10°C.



WARM WATER


Under 50°F/10°C Around 86°F/30°C

TO PLAY (A)




2. Lower into dunk tank to change color. Car transforms to cold water color.

3. Lift and release onto track.




Speed by the shark to change color in the pool.





- Color change will last longer if you do not expose this toy to intense heat or direct sunlight for prolonged periods of time.
- Drain, rinse, clean and dry all items thoroughly before storing. Do not immerse set in water.


5 TO PLAY (B)




4. Second car goes to the rescue.










MORE WAYS TO PLAY



TROUBLESHOOTING

- Q. The car lift keeps jamming. Canit move more smoothly?
- A. Hold the set down with your other hand and the car lift will move up and down smoothly.
- Q. My car keeps slowing down by itself on the tracks.
- A. Lint may collect around your car's axles. This may cause the car to run slowly. Use tweezers or a toothpick to remove lint.

