RIWBOX®

# WIRELESS HEADPHONES XBT-80

USER MANUAL

Designed & Produced by Riwbox
www.riwbox.com

## INTRODUCTION

RIWBOX bluetooth stereo bass headphones are designed base on the advanced bluetooth V5.0,providing maximum 10 meter operating range, An auxiliary input cable also included for use as a wired headphones with non-Bluetooth audio sources, or in case of the internal rechargeable battery is exhausted.

## BOX CONTENTS

- LED Wireless stereo headphone XBT-80
- USB to micro USB cable
- 3.5 mm ( 1/8" ) audio cable
- User guide
- Warranty Card

## SPECIFICATIONS

Supported Bluetooth profiles:AVRCP1.3,A2DP1.0,HFP1.5,HSP1.0
Frequency range:2.402Hz - 2.480GHz
Transmission range:up to 10 m (33')
Power:lithium battery, 4.2 V / 300 mAh (rechargeable)
Driver size: 40mm
Frequency response: 20 Hz - 20 kHz
Charge time about 2 hours
Play time ≤10 hours
Standby ≥160 hours

## OVERVIEW AND KEYS FUNCTION

| Button | Function |
|---|---|
| Play/ pause ▶II | Short press (while playing music) - play / pause |
| ON/OFF /pair<br>Answer/ end call<br>Reject call<br>Redial last number | Long press to open ON/OFF Switch<br>Short press (while calling) - answer / end call<br>Long press to hang up the call when phoning<br>Short press twice - redial last number |
| Volume up (+) / Next ⏮ | Short press and go to increase volume While Calling and playing music<br>Long press to go to next track while playing music |
| Volume down (-) / Previous ⏭ | Short Press and go to decrease volume While Calling and playing music<br>Long press to go to previous track while playing music |
| MODE | "MODE":Mode swich(Bluetooth mode/Card mode) |

## USING YOUR HEADPHONE

We are very happy you own this Bluetooth headphone, We are here show you how to use it, youwill easy to use this headphone after reading this instructions.

Note: Some of the functions described below may not be supported on your specific smartphone. Check with your smartphone owner 's manual to confirm the features supported by your phone.

### 1 .Pairing Operation

A.For the first time pairing:start up the bluetooth headset. It will boot Bluetooth Mode automatically voice prompts "Bluetooth Mode" LED indicator light rapidly alternating flashes with blue and red colors.Please open the smart device's Bluetooth searching function,and select the device "XBT-80" , no password required, after successful pairing, Voice prompts"Bluetooth Connected successfully",LED indicator light flashes once 2 seconds.

B.Re-pairing:turn off the attached smart device's Bluetooth fuction Voice prompts"Bluetooth Disconnected"If cannot search and pair with the last connected smart device within 3 seconds, the headset will automatically re-enter pairing mode.Voice prompts"Bluetooth Mode"LED indicator light rapidly alternating flashes with blue and red colors.Open another smart device searching function and select the device"XBT-80", no password required.After successful pairing,voice prompts"Bluetooth Connected successfully"LED indicator light flashes once for 2 seconds.

C.Follow-up pairing:aotomatically pair the last connected device in 3 seconds after boot.

D.Bluetooth mode match, when the device can not search the headset model, can reset Bluetooth function update method:
①. Open the switch ;
②. Insert the audio wire into the AUX interface, the headphone automatically turn off ;
③. Restart the switch to complete the reset function.

### 2. Answer Calls:

Short press " " when calls' coming.

### 3. Hang up phone calls:

Short press" " after calling.

### 4.Reject Calls:

Long press" "

### 5. Redial the last outgoing number:

Double-click " ".

### 6. Music Play:

Short press▶|| after connected with the smart device.

## Line-in Mode:

When the headset is on, insert the Line-in cable, voice prompts "Line-in Mode". Then it plays smart device's media automatically.

1. Maximum volume warning voice prompts "du du".
2. Supports MP3, WAV, WNA format playback.




## 7.Charge

Before charge,turn off the headphones,the headset charging cable connect to the computer USB pilot lamp turn in green,it means connect with USB successfully,headphones is charging. Built-in battery capacity overload protection detection system, no need worryingabout the battery long,piolt lamp turns off means charge finished.




## 8.LED indicator light Status

| | |
|---|---|
| Charge Status | Charge StatusSteady red LED. When fully charged, the LED indicator light turns off. |
| Power on Status | BlueLED indicator light turns on |
| Power off Status | Blue LED indicator light turns off |
| Pairing Status | Blue LED indicator light turns on |
| Standby Status | Blue and Red LED indicator lights rapidly alternating flash |
| Connected Status | Blue LED indicator light turns on |
| Using Status | Bluetooth Mode, Blue LED indicator light flashes every two seconds |
| | AUX-in Mode, the headset automatically turns off, LED light goes out |
| | TF Mode, Green LED indicator light flashes every three seconds. |

## Note:

If no pairing connection after the Bluetooth headset enters the pairing mode, please turn off theheadset as for power savingDo not perform other. operations when searching Bluetooth to prevent the program errorPlease select the appropriate volume in use to prevent damage to your earsPlease note that a good environment while using the Bluetooth headset can avoid damage to the headphone.
Please charging the headset after a long time none-use.

## FAQ

★ Sign up at www.riwbox.com to learn more about Riwbox new products

**FC This device complies with Part 15 of the FCC Rules.**

Operation is subject to the following two conditions:
★ this device may not cause harmful interference, and
★ this device must accept any interference received, including interference that may cause undesired operation.

## More About Us

Riwbox
@Riwbox001
Riwbox001


Designed & Producted by: Riwbox INC.
Manufacturer: Ruiboshi Technology (Shenzhen) Co.,Ltd
Sale@riwbox.com
Web:www.riwbox.com
Add : 506 N Garfield ave ste 210 alhambra,CA 91801


CE FC RoHS
FCC ID: 2ARGL-RIWBOX

## 中文

| 按键 | 功能 |
|---|---|
| | 打开电源/关闭电源 |
| ▶II | 播放音乐时,短按暂停/播放<br>通话时,短按接听/接听电话<br>长按拒绝来电<br>按两下可重播最后一个电话号码 |
| ⏭/V+ | 长按下一首歌<br>短按增加音量 |
| ⏮/V- | 长按上一首歌<br>短按减小音量 |
| MODE | 短按进行模式切换(蓝牙模式/插卡模式) |

| | |
|---|---|
| 充电模式 | 红色LED指示灯长亮,满电时,指示灯熄灭 |
| 开机提示 | 蓝色LED指示灯常亮 |
| 关机提示 | LED指示灯熄灭 |
| 配对状态 | 蓝色LED指示灯长亮 |
| 待机状态 | 蓝球LED指示灯交替闪烁 |
| 连接状态 | 蓝色LED指示灯长亮 |
| 使用状态 | 蓝牙模式,蓝色LED指示灯两秒闪一次 |
| | AUX-in Mode,其机自动关机,LED指示灯熄灭 |
| | TF模式,绿色LED指示灯两秒闪一次 |

## Español

| Button | Function |
|---|---|
| | Encendido / apagado |
| ▶II | Al reproducir música, presione brevemente para pausar / reproducir<br>Durante una llamada, presione brevemente para colgar / contestar la llamada<br>Mantenga pulsado para rechazar la llamada<br>Haga doble clic para reproducir el último número de teléfono |
| ⏭/V+ | Mantenga presionada una canción<br>Pulse brevemente para aumentar el volumen |
| ⏮/V- | Mantenga presionada la canción anterior<br>Pulse brevemente para bajar el volumen |
| MODE | Pulsación corta para cambiar entre modos (modo Bluetooth / modo tarjeta) |

| | |
|---|---|
| Modo de carga | La luz LED roja siempre está encendida y la luz LED está apagada cuando está completamente cargada |
| Arrancar rápido | El indicador LED azul está siempre encendido |
| Aviso de apagado | El indicador LED está apagado |
| par estado | La luz indicadora LED azul está encendida |
| modo de espera | Los indicadores LED azul y verde parpadean alternativamente |
| Estado de conexión | La luz indicadora LED azul está encendida |
| estado de uso | Modo Bluetooth, el indicador LED azul parpadea una vez cada dos segundos |
| | AUX-en el modo, el auricular se apaga automáticamente, y el indicador LED está apagado |
| | Modo TF, el indicador LED verde parpadea una vez cada dos segundos |

## Deutsche

| Taste | Eigenschaften |
|---|---|
| | Einschalten/Ausschalten |
| ▶II | Drücken Sie beim Abspielen von Musik kurz, um anzuhalten / abzuspielen<br>Kurz drücken, um aufzulegen / den Anruf anzunehmen<br>Lang drücken, um den Anruf abzulehnen<br>Zweimal drücken Sie, um die letzte Telefonnummer wiederzugeben |
| ⏭/V+ | Drücken Sie lange ein Lied<br>Kurz drücken, um die Lautstärke zu erhöhen |
| ⏮/V- | Drücken Sie lange auf das vorherige Lied<br>Kurz drücken, um die Lautstärke zu verringern |
| MODE | Kurz drücken, um zwischen den Modi (Bluetooth-Modus / Kartenmodus) |

| | |
|---|---|
| Lademodus | Die rote LED-Anzeige leuchtet immer auf, und das LED-Licht ist ausgeschaltet, wenn voll aufgeladen |
| Startaufforderung | Die blaue LED leuchtet immer |
| Shutdown Prompt | LED-Anzeige ist aus |
| Pairing-Status | Blaue LED-Kontrollleuchte leuchtet |
| Standby Modus | Blaue und grüne LED-Anzeigen blinken abwechselnd |
| Verbindungsstatus | Blaue LED-Kontrollleuchte leuchtet |
| Nutzungsstatus | Im Bluetooth-Modus blinkt die blaue LED alle zwei Sekunden |
| | Im AUX-In-Modus schaltet sich das Headset automatisch aus und das LED-Licht erlischt |
| | Im TF-Modus blinkt die grüne LED-Anzeige alle zwei Sekunden |

## français

| bouton | traits |
|---|---|
| | Marche / arrêt |
| ▶II | Lors de la lecture de musique, appuyez brièvement pour mettre en pause/lire<br>Pendant un appel, appuyez brièvement pour raccrocher / répondre à l'appel<br>Appuyez longuement pour rejeter l'appel<br>Double-cliquez pour rejouer le dernier numéro de téléphone |
| ⏭/V+ | Appuyez longuement sur une chanson<br>Appuyez brièvement pour augmenter le volume |
| ⏮/V- | Appuyez longuement sur la chanson précédente<br>Appuyez brièvement pour diminuer le volume |
| MODE | Appui court pour basculer entre les modes (mode Bluetooth / mode carte) |

| | |
|---|---|
| Mode de charge | Le voyant LED rouge est allumé et le voyant est éteint lorsque la batterie est complètement chargée |
| Invite de démarrage | L'indicateur LED bleu est toujours allumé |
| Invite d'arrêt | Le voyant LED est éteint |
| Statut d'appariement | Le voyant LED bleu est allumé |
| mode veille | Les voyants LED bleu et vert clignotent en alternance |
| Statut de connexion | Le voyant LED bleu est allumé |
| statut d'utilisation | Mode Bluetooth, le voyant LED bleu clignote une fois toutes les deux secondes |
| | AUX-en mode, le casque est éteint automatiquement et le voyant est éteint |
| | Mode TF, le voyant LED vert clignote une fois toutes les deux secondes |

## italiano

| pulsante | Caratteristiche |
|---|---|
| | Accensione / spegnimento |
| ▶II | Durante la riproduzione di musica, premere brevemente per mettere in pausa/play<br>Durante una chiamata, premere brevemente per terminare/rispondere alla chiamata<br>Premere a lungo per rifiutare la chiamata<br>Fare doppio clic per riprodurre l'ultimo numero di telefono |
| ⏭/V+ | Premi a lungo una canzone<br>Pressione breve per aumentare il volume |
| ⏮/V- | Premi a lungo la canzone precedente<br>Pressione breve per diminuire il volume |
| MODE | Premere brevemente per passare da una modalità all'altra (Modo/scheda Bluetooth) |

| | |
|---|---|
| Modalità di ricarica | La spia LED rosso è acceso, e la spia è spenta quando la batteria è completamente carica |
| Prompt di avvio | L'indicatore LED blu è sempre acceso |
| Richiesta di arresto | L'indicatore LED è spento |
| paio stato | La spia LED blu è accesa |
| modalità standby | Gli indicatori LED blu e verde lampeggiano alternativamente |
| connessione stato | La spia LED blu è accesa |
| stato di utilizzo | Modalità Bluetooth, l'indicatore LED blu lampeggia una volta ogni due secondi |
| | AUX in modalità, l'auricolare si spegne automaticamente e l'indicatore LED è spento |
| | Modalità TF, l'indicatore LED verde lampeggia una volta ogni due secondi |

## Japanese

| ボタン | 特徴 |
|---|---|
| | 電源のオン/オフ |
| ▶II | 音楽を再生するときは、短押しして一時停止/再生します<br>通話中に短く押すと、電話を切る/電話に出る<br>通話を拒否するには長押しします<br>ダブルクリックして最後の電話番号を再生します |
| ⏭/V+ | 曲を長押しします<br>短く押すと音量が上がります |
| ⏮/V- | 前の曲を長押しします<br>短く押すと音量が下がります |
| MODE | 短押しでモードを切り替えます(Bluetoothモード/カードモード) |

| | |
|---|---|
| 充電モード | 赤色LEDインジケーターライトは常に点灯しており、完全に充電されるとインジケーターライトは消灯します |
| 起動プロンプト | 青色LEDインジケーターは常に点灯しています |
| シャットダウンプロンプト | LEDインジケータがオフです |
| ペアリングステータス | 青いLEDインジケーターライトが点灯している |
| スタンバイモード | 青と緑のLEDインジケーターが交互に点滅します |
| 接続ステータス | 青いLEDインジケーターライトが点灯している |
| 使用状況 | Bluetoothモードでは、青色のLEDインジケーターが2秒に1回点滅します |
| | AUX-inモードでは、イヤホンは自動的にオフになり、LEDライトはオフになります |
| | TFモードでは、緑色のLEDインジケーターが2秒に1回点滅します |

如果需要更详情的说明书
请发送邮件到Support@riwbox.com

Si necesita instrucciones más detalladas
Por favor envíe un correo a
Support@riwbox.com

Wenn Sie detailliertere Anweisungen benötigen
Bitte senden Sie eine E-Mail an
Support@riwbox.com

Si vous avez besoin d'instructions plus détaillées
Veuillez envoyer un courrier à
Support@riwbox.com

Se hai bisogno di istruzioni più dettagliate
Si prega di inviare una mail a
Support@riwbox.com

より詳細な手順が必要な場合
にメールを送ってください
Support@riwbox.com