

INSTRUCTION MANUAL


CARE OF YOUR WATCH

1. This watch contains precise electronic components. Never attempt to open the case or remove the back cover.
2. Do not operate push buttons below the surface of the water when swimming or diving.
3. Should water or condensation appear in the watch, immediately have the watch checked. Water can corrode electronic parts inside the case.
4. Avoid severe impact: The watch is designed to withstand impact under normal use, it is inadvisable to subject it to severe impact of rough usage or drop onto hard surface.
5. Avoid exposing the watch to temperature extremes.
6. Clean the watch with a soft cloth and clean water only. Avoid using chemicals, especially soap.
7. Keep your watch away from the conditions of strong electric field and static electricity.

FEATURES AND SPECIFICATION

1. Accuracy at normal temperature: not more than 30 seconds a month.
2. Time keeping mode: hours, minutes, seconds, month, date, day of week, "PM" (only available in 12 hour format).
Press S1 to read month and date.
3. Alarm Mode: daily alarm.
4. Timer Mode: Measuring unit: 1 second
Input range: from 1 second to 23:59'59"
5. Stop watch Mode: Measuring unit: 1/100 of second
measuring capacity: 23:59'59"
6. Normal operating temperature range: 10°C~40°C.
7. Battery type: CR2032.

While advancing, hold S1 can fasten the process.



HOW TO USE EL BACKLIGHT

In any mode press S4 button to illuminate the display for about 3 seconds.

- Note:** 1. The backlight of the watch employs an electro-luminescent (EL) light, which tends to lose illuminating power after very long use.
2. The illumination provided by backlight may be hard to see when viewed under direct sunlight.

HOW TO CHANGE DISPLAY MODE

- From the normal time display, 1st Press S3 to enter Chronograph
2nd Press S3 to enter Alarm
3rd Press S3 to enter Count down timer
4th Press S3 to enter Second zone time
5th Press S3 to return to normal time display

HOW TO SET NORMAL TIME/CALENDAR

From the normal time display, press S2 once, seconds are now flashing.

Press S1 to reset to 00 (if seconds in the range of 30 to 59, minutes will add 1; if seconds in the range of 00 to 29, minutes will not be changed.)

- 1st Press S3- hours will flash-advance by pressing S1
- 2nd Press S3- minutes will flash-advance by pressing S1
- 3rd Press S3- month will flash-advance by pressing S1
- 4th Press S3- date will flash-advance by pressing S1
- 5th Press S3- day will flash-advance by pressing S1
- 6th Press S3- 12/24 hour format will flash-change by pressing S1

While advancing, hold S1 can fasten the process. Press S2 at any stage to return to normal display.

HOW TO USE THE CHRONOGRAPH

From the normal time display, press S3 once to enter chronograph function.

Simple usage:

- Press S1 to start counting
- Press S1 again to stop counting
- Press S2 to reset to zero
- Press S3 to return to normal display (this can be done at any time with the chronograph still running)

Advanced usage (LAP function):

- Press S1 to start counting
- Press S2, first time split T1 (0 to T1) shows. The numbers stop flashing, but chronograph is still counting in fact.
- Press S2 again to continue counting
- Further press S2, the second split time T2 (0 to T2) shows. This operation can be repeated and the splits time can be read: 0 to T3, 0 to T4 etc.
- Press S1 to stop the time counting of the chronograph.
- Press S2, the last split time Tn (0 to Tn) shows.
- Press S2 again, the chronograph is reseted to zero. Press S3 to return to normal display.

HOW TO SET ALARM TIME

You can set alarm with hours and minutes. When the alarm is on, the alarm(BI-BI) sound for 20 seconds at the preset time. Press S1, S2 or S3 to stop the alarm after it starts sound. Alarm on is available in one zone time only(T1 or T2).

From the normal time display, press S3 twice to read the alarm time. To change the alarm setting:

- Press S2 once-hours will flash, Press S1 to advance
- Press S3-minutes will flash, Press S1 to advance
- Press S3-AL. T1/AL. T2 will flash, Change by pressing S1
- Press S2 to exit setting
- Press S3 to return to normal time display

ALARM & CHIME ON/OFF

From the normal time display, press S3 twice to read the alarm time. Press S1 to activate or turn off the alarm and/or chime. When chime is on, the chime signal appears and there is one beep every hour. When alarm is on, the alarm signal appears.

HOW TO USE TIMER

From the normal time display, press S3 three times to enter. To set countdown timer:

- Press S2-hours will flash-advance by pressing S1
- Press S3-minutes will flash-advance by pressing S1
- Press S3 again-seconds will flash-advance by pressing S1
- Press S2 to stop setting
- Press S1 to start countdown timer. Press S1 again to stop the countdown timer.
- While the timer is running, press S2 to reset the countdown time to its starting value.

Within the setting time 3 minutes, there is an alarm (BI-BI) when the seconds digit is "0" or "30".

Within the setting 10 seconds, there is an alarm (BI) per second.

When timer expired, the alarm (BI-BI) lasting 10 seconds, it will be silenced by press S1, S2 or S3. Press S3 to return to normal time display.

HOW TO SET SECOND ZONE TIME

From normal time display:

- Press S3 four times to read 2nd zone time. To set 2nd zone time:
- Press S2 once-hours will flash, Press S1 to advance (+1 hour)
- Press S3-minutes will flash, Press S1 to advance (+30 minutes or -30 minutes)
- Press S2 to exit setting
- Press S3 to return to normal time display