


Correctly set the stand in specially designed for it slot.



Use USB cable to connect alarm clock to computer - Use the adapter to an electricity network



Use batteries as a backup power source (if the electricity is down, no access to the network or computer; using the alarm clock in different locations, the batteries save all your setting).

To install the batteries:  
Used 2 batteries type AAA (not included).  
- Open the battery compartment, following the arrow on the battery cover to remove the cover.  
- Insert 2 AAA batteries, observe the polarity, which can be viewed inside the compartment.  
- Replace the battery cover

When only batteries are used, the product **functions are limited:**

\* Time display is switched off in 5 sec. Press any buttons on back side to switch on.

\* At the set alarm time sound is played for 2 minutes. Snooze is available. Press or touch any button except Snooze to stop the sound.

\* All light functions — are not available.

\* Radio is available.

### Setting the Sunset time

Touch ☀️ to switch on/off sunset mode

☀️/☀️ appears/dissappears on time display.



Hold 3 sec ☀️ to set:  
The hours indication starts to blink.

Use for setting hours ⏪⏩ to adjust and confirm ☀️  
setting minutes ⏪⏩ to adjust and confirm ☀️

If the indication stopped touch ☀️ again.

### Light

Touch ☀️ to switch on the light

Use ⏪⏩ to adjust the level (1-10) of the brightness

Second touch ☀️ is started automatically color changing mode

Use ⏪⏩ to select color: Green, Red, Blue, Purple Orange, Indigo

Third touch ☀️ to switch off the light

### Sunset light simulation

☀️ 30 min before sunset time, the light is turned on with 100% brightness whatever at any mode and then the brightness is reduced gradually and will turn off at sunset time.

During sunset light is turned on you may: Hold 3 sec ☀️ to turn off the light.

### Setting current time

When the plug is connected, the hours indication starts to blink.

Use for setting hours

⏪⏩ to adjust and confirm ☌

setting minutes


⏪⏩ to adjust and confirm ☌

If the indication stopped touch ☌ again.

### 12H- 24H- format

Press 12/24 backside.

12H  
AM or PM will appear on time display.



### Changing current time

Touch ☌  
The hours indication starts to blink.

Use for setting hours

⏪⏩ to adjust and confirm ☌


setting minutes

⏪⏩ to adjust and confirm ☌

If the indication stopped touch ☌ again.

### Intensity of time display

Press ⏪ backside



### Description

- \* Led time display in 12H-24H format
- \* Sunrise wake up light simulation
- \* Sunset light
- \* 5 Nature sounds to wake up
- \* Bedside lamp: White light flux : 96.56LM
- \* 1-10 levels of the brightness
- \* 7 colors of the light
- \* Automatically changing of color light
- \* Radio FM + antenna
- \* 15 volume levels
- \* Touch mode
- \* Power supply: DC 5V; 2xAAA batteries; USB cable.

Note: time display isn't indicated when Radio is turned on. When the radio is turned on, you may see the symbol of the radio station which broadcasts. This function was been designed to surf the desired radio station. You may touch FM to keep abreast of the current time and then touch FM again to continue listening to the radio.

# 6638 Wake up Light User Manual

### RADIO FM

Touch FM to turn on/off

Hold 3 sec FM  
All available FM channels will be scanned and saved automatically.

Touch ⏪⏩ to select FM station.

Press ⏪ backside to choose volume level 1-15.

Note: time display isn't indicated when Radio is turned on.

### Setting the alarm wake-up time

Touch ☌ to switch on/off alarm mode.

☌/☌ appears/disappears on clock display.



Hold 3 sec ☌ to set alarm.

The hours indication starts to blink.

Use for setting hours

⏪⏩ to adjust and confirm ☌

setting minutes

⏪⏩ to adjust and confirm ☌

If the indication stopped touch ☌ again.

### Nature sounds

Press 🎵 backside to select.

Use to adjust ⏪⏩ 1-7 sounds.

Each sound (1-6) will playing 10 sec before your choice.

7 — Radio last listened station will be as waking sound.  
Press ⏪ backside to select volume level 00-15



### Sunrise light simulation

☀️ 30 min before wake up time, light sunrise is started gradually to increase its brightness; At alarm time the nature sound or Radio the sound will be played for 2 minutes.

During sound playing you may:

- Touch ☌ the sound is stopped and in 5 min it will be played for 2 minutes. Press or touch any buttons except ☌ to stop sound.

- Hold 3 sec ☀️ to switch off wake up light.



- \* Don't press two or more keys at the same time
- \* To avoid failure, interval of every touch must be more than 1 second.
- \* If there is any malfunction, please unplug the unit for 3 seconds.
- \* If the batteries are not used for a long time, please remove.

