


Operation Manual


A. Features

- 12 Digits LCD Display, Display Hour, Minute, Second, Month, Day and Week
- Daily Alarm and Chime hourly
- 12 / 24H format, Auto Calendar
- 1/100 second Chronograph with split functions
- LED backlight



B. Operational Manual

- In any Mode Press A Key for LED light ON for 3s
- Press B key to convert the mode as following:



Chronograph function

In normal display mode: press B key once, enter Chronograph mode

- Press D to start, press D again to suspend, press D again to continue, press D to suspend again,.....when suspend, press C key back to 0:00:00.
- In Chronograph mode, press D key to start, press C key enter into split function. press C key again to get the first group record, but the second group still processing in the back ground, press C key again to continue the second group, press C key again to read the second group record.....when the final group finished, Press D key to stop the SPL function, press C key read the final group(SUM) record, press C key again to clear the record to zero.

Alarm Setting

- In normal display Mode, press B key twice to the Alarm mode
- Press C key the Hours will flash, press D key the adjust the Alarm Hours.
- Press C key again the Minutes will flash, press D key to adjust the Alarm Minutes
- Press B key to exit.

Alarm&Chime ON/OFF

In normal display mode press B key twice enter the alarm mode, press D key for Noise and ON/OFF the Alarm and Chime function, If only "ALM" icon means when the time is alarm time will chime, if only "CHM" icon ON, means every Hour will chime; if the two icon ON means in alarm time and every Hour will chime.

Time & Date Setting

In normal display Mode, press B key three times to enter time setting mode and the icon of seconds will flashing. Press D key to zero.

- Press C key and the icon of Hours will flash. Press D key to reach the correct Hours (Pay attention: AM/PM, "H" is 24 hour format)
- Press C key and the icon of the Minute will flash. Press D key to reach the correct Minutes.
- Press C key and the icon of the Month will flash. Press D key to reaches the current Month
- Press C key and the icon of the Date will flash. Press D key to reach the current date
- Press C key and the icon of the week will flash. Press D key to adjust the day
- Press B key to exit.