

According to the European WEEE directive, electrical and electronic equipment must not be disposed with consumers waste. Its components must be recycled or disposed apart from each other. Otherwise contaminative and hazardous substances can pollute our environment.

You as a consumer are committed by law to dispose electrical and electronic devices to the producer, the dealer, or public collecting points at the end of the devices lifetime for free. Particulars are regulated in national right. The symbol on the product, in the user's manual, or at the packaging alludes to these terms. With this kind of waste separation, application, and waste disposal of used devices you achieve an important share to environmental protection.

1.0 Safety Instruction

- Don't plug in an appliance where the load exceeds 16 Amp.
- Connect the device only directly to an outlet that has been approved for the device. Never use an extension cable or an adapter.
- The used outlet must always be easily accessible for unplug easily in an emergency Case.
- Always ensure the plug of any appliance is fully inserted into the timer outlet.
- The manufacturer recommends such appliances not be connected to timers
- Do not let the product come into contact with rain, moisture or other liquids to avoid damaging the device and to prevent injuries due to short circuits.
- Never use a defective device
- Never open the device.
- If cleaning of the timer is required, remove from outlet and wipe timer with a dry, lint-free cloth.
- Keep away from Children. Product is not a toy !!!

Congratulations to the Purchase of LogiLight Indoor Remote Power Socket Starter kit!

Please read the Manual and Safety Instructions before using the product for the first time. Otherwise damage can be the result.

2.0 Introduction

2.1 Specification:

■ Receiver:

- Intelligent learn function
- Manual on/off function
- Red Power indicator
- Power Supply: 230V AC, 50Hz
- Rating: 16A, 3680W max.
- Transmission range: 20m in open area

■ Transmitter:

- Receive range: >20m
- Frequency range: 433.92MHz
- Code: Self learning 1 million
- Battery (1 x 12 V)

2.2 Package Contents

■ EC0001

- 2 x Indoor Power Sockets
- 1 x Remote Control
- 1 x Remote Control battery

Logilight

■ EC0003

- 3 x Indoor Power Sockets
- 1 x Remote Control
- 1 x Remote Control battery



■ EC0005

• 1 x Indoor Power Socket



3.0 Installation

- 1. On the remote control, open the battery compartment and place the provided battery in the right position.
- Plug the receiver in a power plug. Press the ON button on the receiver, then LED will light. And LED flashes one time per second.
- 3. Press the ON button (lasting more than 2 seconds) of your choice (1 to 5) on the remote control. The receiver will then learn the code and store it in memory. When LED flashes continuously in 2 seconds, it means the receiver learns the code successfully.
- Repeat these last two operations for all receivers and select a different ON button for each receiver.

4.0 Operation

- Plug the device you want to remotely operate into a receiver.
- Press the corresponding ON or OFF button of the remote control to operate the plug or
- Press the direct ON/OFF switch on the receiver to activate or inactivate it.

5.0 Trouble Shooting

If a receiver does not react to the remote control operation it can be due to:

- Low battery in the remote control Replace it.
- Distance too large between the remote control and the receiver
- The pressing time on the buttons must be at least 2 seconds

6.0 How to Decode

- Press ON/OFF switch on receiver and last for 3 seconds.
 After the LED flashes from quickly to once per second, decoding is successful.
- Press ALL OFF switch on remote control and last for 3 seconds. After the LED flashes from quickly to once per second, decoding is successful.



CE Declaration:
This device corresponds to EU directive 2004/108/EC and 2006/95/EC: With the CE sign Logilink®, a registered trademark of the 2direct GmbH ensures, that the product is conformed to the basic standards and directives. These standards can be requested online on www.logilink.com. All trademarks and registered brands are the property of their respective owners.