

AICOK



**Aicok Home Essentials Live Comfortable
Shenzhen Impression E-commerce Co.,Ltd**

Add: Booth No.3H012,Trading Plaza,No.5,Huanan
city,Pinghu Street,Longgang District,Shenzhen,China

Facebook Page: <https://www.facebook.com/aicoks/>

Website:www.aicok.cc

Made In China



PLEASE RECYCLE
VEUILLEZ RECYCLER

ICE MAKER



Model No: YT-E-005C

Instruction Manual

AICOK

Thank you for purchasing our product

Make sure you have read and understand this manual before using the appliance and follow all instructions.

Please retain this instruction manual for future reference.

Basic Introduction

Ice maker is a professional product used to make ice cubes. With a luxurious appearance, Antiseptic internal material, it is suitable for long-term use. Automatic ice-making system works in high speed and always produces ice cubes in standard shape. Three different modes for ice cubes could be selected according to your preferred setting.



In order to keep the ice maker working efficiently and smoothly, please always follow our instructions.

I. Product Features

1. Adopting compressor refrigerating technology, the ice maker produces cubes efficiently.
2. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
3. The Ice making process can be viewed through the transparent window.
4. Push-button operation. LCD indicators - lights indicate the various functions.
5. Low water warning and warning for full storage box – remove ice to continue process


II. Components' List:

- ① Transparent window
- ② Cover
- ③ Operation panel
- ④ Air outlet
- ⑤ Air inlet
- ⑥ Power cord
- ⑦ Water outlet
- ⑧ Ice storage box
- ⑨ Evaporator
- ⑩ Ice making box



XI. Technical Parameters

Model no.:	YT-E-005C
Power supply	110-120V~60Hz 1.8A
Refrigerant	R134a/0.1pound
Climatic class	SN/N/ST
Ice making capacity	12kg
Max ice storage	0.8kg
Max water storage	2.2kg
Clock function	Yes
Time setting	Yes
Filling water alarm	Yes
Ice full alarm	Yes
Functions Achieve	Button
Display mode	LCD
Outer sizes	360*249*327mm
Net weight	10.2kg

unit will automatically go into stand-by mode; If water bucket is fail to turn over,  icon will be on, you need to long press ON/OFF button for more than 5 seconds to release self-cleaning mode to change for other operations.

X. Cleaning

1. Make sure to unplug the appliance before cleaning and long time off use.
2. Use a damp cloth to clean both the interior and exterior of the appliance.
3. Water tank cleaning.
 - 1). Unscrew the nut of water outlet, drain off the water.
 - 2). Pour clean water into the water tank, use a clean cloth to wipe water tank around. Pour clean water again until the flowing out water is clean, and then drain off water and grip the nut.
4. Do not use organic solvents, boiling water, cleaning agents, strong acids, strong acid and Alkali etc substances for cleaning.
5. If ice machine will be off use for a long time, you should unplug the appliance, drain off the water and dry the appliance with a clean cloth, store the ice maker in a clean place.

III. Safety precautions

- Check that the mains voltage corresponds to the rating of the appliance before operating
- Use handles or knobs when moving.
- Place on a flat stable surface for use.
- Do not use outdoors
- Do not use near or in the immediate vicinity of a bath or swimming pool or any source of liquid
- Unplug from socket outlet when not in use
- To protect against electric shock, do not immerse cord or plug in water or any other liquid
- The use of accessory attachments not recommended by the appliance manufacturer, may cause injury
- Do not locate this appliance immediately below a socket outlet
- Do not allow cord to overhang the counter top where it can be easily pulled by children
- Do not use this appliance for anything else other than its intended use
- Do not overfill as this may cause a hazard. Do not fill above the MAX or below MIN mark
- Ensure lid is closed when in operation
- To remove plug from outlet, do not pull on supply cord. Grasp plug firmly and pull to remove
- No liability can be accepted for any damage caused by non compliance with these instructions or any other improper use or mishandling

- This appliance is for household use only
- This appliance is not intended to be operated by means of an external timer or separate remote control system.
- This appliance is not intended to be immersed in water.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Please according to local regulations regarding disposal of the appliance for its flammable blowing gas.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- WARNING: fill with potable water only.
- WARNING: This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- This appliance is intended to be used in household and similar applications such as
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses and by clients in hotels, motels and other residential type environments;

IX. Self-Clean Mode Operating Instructions:

The self-clean mode should be put into operation before you use your ice maker for the first time and/or if there has been a long period without use.

Three Icons as Large, Medium and small Icons will be on at the same time when the ice maker is in self-clean mode.

Stage 1

1. Add equal parts of water and vinegar (1:1) to the ice maker's reservoir.
2. With the stand-by mode, keep pressing ON/OFF button at least 5 seconds to activate the self-clean mode. Please note that self-clean mode will start automatically after "Beep" sound.
3. During the self clean mode, the upper water bucket is filled and dumped. The pump will remain in continuous operation as it feeds water to the bucket and evaporator coils. This cycle will continuous for five times.
4. Upon completion, the unit automatically changes to stand-by mode.

Stage 2

1. Drain the cleaning solution from the internal reservoir by removing the rear drain cap and plug.
2. Add fresh water to the Max. permit water volume line.
3. With the stand-by mode, keep pressing ON/OFF button at least 5 seconds to activate the self-clean mode again which will now act as a rinse.
4. Upon completion of this final stage of the self clean process, the unit automatically changes to stand-by mode. Proceed to drain the water from the internal reservoir by removing the rear drain cap and plug. Leave the lid on the ice maker open to allow it to air dry.

Please note if there is a water shortage during Self-cleaning mode, the

VIII. Troubleshooting

Faults	Reason	Treatment
Power indicator is not lit.	Power Source is not switched on.	1. Check the power supply matches 2. Check the power cord is connected correctly 3. Internal components are damaged. Maintenance Required – seek professional help.
ICE FULL indicator is lit.	1. Ice box full. 2. low-temperature protection (temperature is lower than 5°C.).	1. Remove Ice cube. 2. Move the Ice maker to a warmer place, where the ambient temperature is higher than 5°C.
Malfunction indicator light flashes	Ice making box reset in bad condition	1. Check whether any foreign body obstructing the ice making box. 2. Internal components are damaged. Maintenance Required – seek professional help
Low Water indicator flashes	Absence of water	1. Fill water compartment with clean water, push the key to eliminate the failure. 2. water supply system or components damaged, send to professional service centre for repairs
Ice making performance is not good.	1. Check ventilation outlets. 2. Water temperature is too high. 3. Ambient temperature is too high. 4. Refrigerant leak.	1. Clean the dust on the cooling fan and air inlet/outlet. 2. Fill room temperature water. 3. Do not place the appliance in high temperature conditions. 4. Refrigerating system is damaged. Maintenance Required – seek professional help
Abnormal noise	Fan or pump is damaged.	1. Move appliance to a suitable location. 2. Maintenance Required – seek professional help

- bed and breakfast type environments;
- catering and similar non-retail applications.


IV. Place environment

1. Keep away from heating sources and avoid direct sunlight so as not to impact the ice-making process.
2. Ice maker should be situated in a well ventilated area. Ensure there is a minimum space of 20cm around the machine so not to obstruct air inlets and outlets.
3. Ambient temperature for Ice maker must not be less than 5°C.










V. Preparation before Use.

1. Remove all the package components.
2. Ensure all accessories correspond to that of the instructions.
3. Place the ice maker in a suitable / stable area.
4. Clean the machine and its components before use.

VI. Before Use

1. Plug into power source.
2. Do not turn on the Ice maker within 30 minutes after moving the machine.
3. Pour water into the water tank - use normal drinking water for making ice.
4. Press  key to start making ice.

VII. Operation Panel.

Buttons and Icon	Functions
 Button	Making Ice, Standby, Eliminating faults.
SELECT Button	Selecting Ice cube size: L, M, S three sizes.
▲ key	Power on or off time setting; power on and off time setting; three states setting switch
SET key	Clock-time setting, power off time setting, power on and off time setting switch
 Icon	Ice dropping fault indication, trouble-free flashing
 Icon	Water absence fault indication, fault-free flashing
 Icon	Large, medium, small size ice size instructions, the default Medium.
 Icon	Ice full instruction.
 Icon	Real-time indicator icon
 Icon	Power on time setting function indicator
 Icon	Clock icon indicates real time(24 hour system), set real time, regular time, in hours and minutes respectively blinking, no time setting display real-time, the default time display 12:00
 Icon	Ice working status indicator, flashing while ice making time, still while standby.



- 1) Real Time Setting: Press the SET button one time, **88** hour blinking, press the ▲ button to set hour, press the SET button one time, **88** minutes flash, press the ▲ button to set minutes.
- 2) The timing for the machine start on time setting: press the SET button 3 times, **88** hour blinking, press the ▲ button to set hour, press the SET button one time, **88** minutes flash, press the ▲ button to set minutes;
- 3) Set the machine power off time: Press the SET button 5 times, **88** hour blinking, press the ▲ button to set hour, press the SET button one time, **88** minutes flash, press the ▲ button to set minutes;
- 4) The timer functions take on use: Press ▲ to set timer, set the cycle timer function mode: time power on→time power off→time off power on and off, power on default time is 8:00, power off default time is 12:00.